

# EWRC 300/500/5000 NT

## Hardware Guide

9MA10258.04  
02/2022



---

## Legal Information

The Schneider Electric brand and any trademarks of Schneider Electric SE and its subsidiaries referred to in this guide are the property of Schneider Electric SE or its subsidiaries. All other brands may be trademarks of their respective owners.

This guide and its content are protected under applicable copyright laws and furnished for informational use only. No part of this guide may be reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), for any purpose, without the prior written permission of Schneider Electric.

Schneider Electric does not grant any right or license for commercial use of the guide or its content, except for a non-exclusive and personal license to consult it on an “as is” basis. Schneider Electric products and equipment should be installed, operated, serviced, and maintained only by qualified personnel.

As standards, specifications, and designs change from time to time, information contained in this guide may be subject to change without notice.

To the extent permitted by applicable law, no responsibility or liability is assumed by Schneider Electric and its subsidiaries for any errors or omissions in the informational content of this material or consequences arising out of or resulting from the use of the information contained herein.

As part of a group of responsible, inclusive companies, we are updating our communications that contain non-inclusive terminology. Until we complete this process, however, our content may still contain standardized industry terms that may be deemed inappropriate by our customers.

© 2022 Eliwell. All rights reserved.

---

# CONTENTS

---



<b>1. INTRODUCTION .....</b>	<b>9</b>
1.1. GENERAL DESCRIPTION .....	9
1.2. MODELS .....	9
<b>2. TECHNICAL SPECIFICATIONS .....</b>	<b>10</b>
2.1. TECHNICAL DATA (EN 60730-2-9:2010, EN 61439-1:2011 / 61439-2:2011 / EN 60204-1:2006) .....	10
2.2. ELECTRICAL SPECIFICATIONS.....	10
2.3. FURTHER INFORMATION.....	11
2.3.1. INPUT CHARACTERISTICS .....	11
2.3.2. OUTPUT CHARACTERISTICS.....	11
2.3.3. MECHANICAL CHARACTERISTICS .....	12
<b>3. MECHANICAL INSTALLATION .....</b>	<b>13</b>
3.5. INSTALLATION PROCEDURE .....	15
<b>4. ELECTRICAL CONNECTIONS.....</b>	<b>20</b>
4.1.1. WIRING GUIDELINES .....	20
4.1.2. RULES FOR SCREW-TYPE TERMINAL BOARDS .....	21
4.1.3. ANALOGUE INPUTS-PROBES .....	22
4.1.4. SERIAL CONNECTIONS.....	23
4.1.5. RS-485 CONNECTION .....	23
4.1.6. TTL CONNECTION .....	23
4.2. WIRING DIAGRAM.....	24
4.2.1. TERMINALS .....	24
4.3. WIRING DIAGRAM FOR MODELS WITH MAGNETOTHERMAL SWITCH INSTALLED .....	25
4.3.1. TERMINALS .....	25
<b>5. USER AND START-UP INTERFACE.....</b>	<b>26</b>
5.1. DISPLAY .....	26
5.1.1. KEYS.....	26
5.1.2. DISPLAY MEANING.....	27
5.1.3. CONNECTION TO HACCP MODULE .....	27
5.1.4. ICONS.....	28
5.1.5. PRELIMINARY CONFIGURATIONS.....	29
5.1.6. OPERATION IN DEFAULT CONFIGURATION.....	29
5.1.7. NAVIGATION .....	30
5.1.8. FUNCTIONS MENU AND KEY-ENABLED FUNCTIONS .....	31
5.1.9. PASSWORDS.....	32
5.1.10. SETPOINT PROGRAMMING.....	33
5.1.11. VIEWING PROBE VALUES .....	34
5.1.12. HOW TO MODIFY THE DATE AND TIME.....	35
5.1.13. DISPLAYING ALARMS .....	36

5.1.14. SYSTEM ALARMS EXAMPLE.....	37
5.1.15. MODIFYING A PARAMETER.....	38

## **6. FUNCTIONS AND REGULATORS..... 40**

6.1. SETTINGS .....	40
6.1.1. PROBE SETTING AND CALIBRATION.....	40
6.1.2. DISPLAY SETTINGS.....	40
6.2. FUNCTIONS .....	41
6.2.1. UPLOAD, DOWNLOAD, FORMAT .....	41
6.2.2. UNICARD .....	42
6.3. BOOT LOADER FIRMWARE .....	43
6.4. COMPRESSOR.....	44
6.4.1. COMPRESSOR CONFIGURATION .....	44
6.4.2. SECOND COMPRESSOR CONFIGURATION .....	44
6.4.3. COMPRESSOR OPERATING CONDITIONS.....	44
6.5. COMPRESSOR/GENERAL PROTECTIONS .....	45
6.5.1. COMPRESSOR SAFETY TIMINGS .....	46
6.6. DEFROST/DRIPPING.....	47
6.6.1. DEFROST TYPE AND ACTIVATION.....	47
6.6.2. AUTOMATIC DEFROSTING .....	48
6.6.3. MANUAL DEFROST .....	48
6.6.4. EXTERNAL DEFROST .....	49
6.6.5. DEFROST WITH REMOTE START/STOP.....	50
6.7. DEFROST MODE .....	51
6.7.1. DEFROST WITH ELECTRIC HEATERS.....	51
6.7.2. INVERSE DEFROST .....	52
6.7.3. DOUBLE EVAPORATOR DEFROST.....	53
6.8. EVAPORATOR FANS.....	55
6.8.1. EVAPORATOR FAN OPERATING CONDITIONS.....	55
6.8.2. FAN OPERATION IN TEMPERATURE CONTROL MODE.....	56
6.8.3. FAN OPERATION IN DUTY-CYCLE MODE.....	57
6.8.4. FAN OPERATION IN DEFROST .....	58
6.8.5. FAN FUNCTION DURING DRIPPING .....	59
6.8.6. POST-VENTILATION .....	59
6.9. DEEP COOLING CYCLE - DCC.....	60
6.10. PREHEAT .....	60
6.11. PRESSURE SWITCH.....	61
6.11.1. AUXILIARY OUTPUT (AUX/LIGHT).....	62
6.12. DOOR/EXTERNAL ALARM MANAGEMENT .....	63
6.13. DEMISTING HEATERS (FRAME HEATERS).....	65
6.14. CONDENSER FANS.....	66
6.15. STAND-BY.....	67

6.16. PUMP DOWN.....	67
6.16.1. SERVICE STOPPAGE.....	67
<b>7. PARAMETERS .....</b>	<b>68</b>
7.1. HOW TO MODIFY THE USER PARAMETERS .....	68
7.2. HOW TO EDIT THE INSTALLER PARAMETERS.....	68
7.3. PARAMETER TABLE .....	69
7.3.1. PARAMETER H60.....	79
<b>8. ALARMS .....</b>	<b>80</b>
8.1. ALARMS AND SIGNALS TABLE .....	80
8.2. ALARM CAUSE/EFFECT TABLE .....	81
8.3. DESCRIPTION OF ALARMS.....	83
8.3.1. PROBE ALARM.....	83
8.3.2. MINIMUM AND MAXIMUM TEMPERATURE ALARM .....	84
8.3.3. END OF DEFROST DUE TO TIMEOUT ALARM .....	86
8.3.4. EXTERNAL ALARM.....	86
8.3.5. DOOR OPEN ALARM .....	87
8.3.6. PRESSURE SWITCH INPUT ALARM.....	87
8.3.7. PANIC ALARM .....	88
8.3.8. LEAK DETECTOR ALARM .....	89
<b>9. MODBUS MSK 554 /812 FUNCTIONS AND RESOURCES .....</b>	<b>90</b>
9.3.1. DATA FORMAT (RTU).....	90
9.3.2. NETWORK .....	90
9.3.3. MODBUS COMMANDS AVAILBLE AND DATA AREAS .....	91
9.3.4. ADDRESS CONFIGURATION.....	91
9.3.5. PARAMETER VISIBILITY AND VALUES.....	92
9.3.6. MODBUS TABLES .....	92
9.3.7. PARAMETER/VISIBILITY TABLE .....	94
9.3.8. PARAMETER/VISIBILITY H60 TABLE .....	99
9.3.9. FOLDER VISIBILITY TABLE .....	101
9.3.10. RESOURCES TABLE.....	101
<b>10. ADVANCED FUNCTIONS - NIGHT AND DAY .....</b>	<b>103</b>
10.1. DAY/NIGHT REGULATOR OPERATION .....	103
10.2. OPERATION WITH DEFROST GROUP.....	104
10.3. DAY/NIGHT REGULATOR DURING A BLACKOUT.....	104
10.4. OPENING FOLDER NAD - DAY/NIGHT.....	105
<b>11. ADVANCED FUNCTIONS - HACCP .....</b>	<b>106</b>
11.1. DISPLAYING HACCP ALARMS .....	107

---

## SAFETY INFORMATION



---

### Important information

Read these instructions carefully and visually inspect the equipment to familiarise yourself with the device before attempting to install it, put it into operation, overhaul or service it. The following warning messages may appear anywhere in this documentation or on the equipment to warn of potential dangers or to call attention to information that can clarify or simplify a procedure.



The addition of this symbol to a danger warning label indicates the existence of an electrical danger that could result in personal injury should the user fail to follow the instructions.



This is the safety warning symbol. It is used to warn the user of the potential dangers of personal injury. Observe all the safety warnings that follow this symbol to avoid the risk of serious injury or death.

#### **DANGER**

**DANGER** indicates a dangerous situation that, unless avoided, **will result** in death or serious injury.

#### **WARNING**

**WARNING** indicates a potentially dangerous situation which, if not avoided, **could result in** death or serious injury.

#### **CAUTION**

**CAUTION** indicates a potentially dangerous situation which, if not avoided, **could result in** minor or moderate injury.

#### **NOTICE**

**NOTICE** used in reference to procedures not associated with physical injuries.

### PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric and Eliwell for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

### Personnel qualification

Only personnel with suitable training and an in-depth knowledge and understanding of the contents of this manual and any other documentation relevant to the product are authorized to work on and with this product. Qualified personnel must be capable of identifying any dangers which may arise from the parameterization or changing of parameter values, and from the use of mechanical, electric and electronic equipment in general.

Plus, they must be familiar with the personal safety laws, provisions and regulations which must be observed during system

## Product related information

### DANGER

#### HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables or wires.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- Before powering the device back up, fit back and fix all the covers, hardware components and wiring.
- Check the earthing connections on all earthed devices.
- Use only the specified voltage when operating this equipment and any associated products.
- Comply with all standards regarding accident protection and local applicable safety directives.

**Failure to follow these instructions will result in death or serious injury.**

### DANGER

#### HAZARD OF OVERHEATING AND/OR FIRE

- Do not use with loads other than those indicated in the technical specification.
- Do not exceed the maximum permitted current; for higher loads, use a meter with sufficient power capacity.

**Failure to follow these instructions will result in death or serious injury.**

This equipment is designed to operate outside all hazardous locations and is not to be used in applications which generate (or could potentially generate) hazardous environments. Install this equipment only in areas and applications known to be free from dangerous atmospheres at all times.

### DANGER

#### POTENTIAL FOR EXPLOSION

- Install and use this equipment in non-hazardous locations only.
- Do not install or use this equipment in applications which could generate hazardous atmospheres, such as applications which use flammable refrigerants.

**Failure to follow these instructions will result in death or serious injury.**

For information regarding the use of control equipment in applications capable of generating hazardous materials, please contact the relevant national regulatory bodies or certifying authorities.

### WARNING

#### UNINTENDED EQUIPMENT OPERATION

- The equipment signal cables (probes, digital inputs, communication, and the relative power supplies) must be laid separately from the power cables.
- Every end application of this device must be tested individually and completely in order to check its proper operation before putting it in service.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

---

## HACCP Module - RCN..... MODELS

### **NOTICE**

#### **INOPERABLE EQUIPMENT**

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).

**Failure to follow these instructions can result in equipment damage.**

**NOTE.** For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.

### Permitted use

The device must be installed and used in accordance with the instructions provided. In particular, parts carrying dangerous voltages must not be accessible under normal conditions.

It must be adequately protected from water and dust with regard to the application, and must only be accessible using tools or a keyed locking mechanism (with the exception of the front panel).

The device is suitable for use in household refrigeration appliances and/or similar equipment and has been tested in accordance with the harmonized European reference standards.

### Prohibited use

Any use other than that expressly permitted is prohibited.

The relay contacts provided are mechanical and subject to failure; any protection devices required by product standards, or suggested by good practice in view of obvious safety requirements, must be installed externally of the device.

### Liability and residual risks

The liability of Schneider Electric and Eliwell is limited to the correct and professional use of the product according to the directives referred to herein and in the other supporting documents, and does not cover any damage (including but not limited to) the following causes:

- unspecified installation/use and, in particular, in contravention of the safety requirements of the legislation in force in the country of installation and/or specified in this document;
- use on equipment which does not provide adequate protection against electrocution, water and dust in the actual installation conditions;
- use on devices which allow access to dangerous parts without the aid of a keyed or tooled locking mechanism;
- tampering with and/or modification of the product;
- installation/use on equipment that does not comply with the regulations in force in the country of installation.

### Disposal



The equipment (or product) must be subjected to separate waste collection in compliance with the local legislation on waste disposal.

### Date of production

The date of production is shown on the device label, indicating the week and year of production (WW-YY).



# 1. INTRODUCTION

---

## 1.1. GENERAL DESCRIPTION

The **Coldface EWRC 300/500/5000 NT** series controls the temperature of a static or ventilated cold room. The instrument controls positive or negative cold rooms and is capable of managing a double evaporator and condenser fan.

**Coldface** has 3 or 5 configurable relays, depending on the model, and 2(3) configurable digital inputs for door switches or other devices. Models are available with clock with yearly calendar and HACCP event logging.

The instrument can be connected to Televis**System** / Modbus via the **RS-485 plug-in module** (optional).

The container lets you install one or more electromechanical devices, depending on the model.

## 1.2. MODELS

- **EWRC 300 NT** - Versions with 3 configurable relays for controlling all the accessory loads in the room.
- **EWRC 500 NT** - Versions with 5 configurable relays for controlling all the accessory loads in the room.
- **EWRC 500 NT HACCP** - Versions with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar.
- **EWRC 500 NT 4DIN** - Versions with 5 configurable relays for controlling all the accessory loads in the room, plus door for installation of magnetothermal switch or accessories on a DIN rail.
- **EWRC 500 NT 4DIN HACCP** - Versions with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar, plus door for installation of magnetothermal switch or accessories on a DIN rail.
- **EWRC 500 NT BREAKER** - Versions with 5 configurable relays for controlling all the accessory loads in the room, plus door and magnetothermal switch installed.
- **EWRC 500 NT 4DIN BREAKER HACCP** - Versions with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar, plus door and magnetothermal switch installed.
- **EWRC 5000 NT HACCP** - Version with larger container, with 5 configurable relays for controlling all the accessory loads in the room, HACCP function with clock and yearly calendar, plus door for installation of components on a DIN rail.

## 2. TECHNICAL SPECIFICATIONS

---

### 2.1. TECHNICAL DATA

(EN 60730-2-9:2010, EN 61439-1:2011 / 61439-2:2011 / EN 60204-1:2006)

Front panel protection rating	IP65
Classification:	Electronic automatic control device (not safety device) for stand-alone installation
Installation:	wall
Type of action:	1.B
Pollution class:	2
Panel use:	Internal use
Panel type:	Fixed panel
Maximum installation site altitude:	2000 m (2187 yd)
Weight:	< 2 kg (< 4.41 lb)
Material class:	IIIa
Over-voltage category:	II
Nominal pulse voltage:	2500 Vac
Operating temperature:	-5...50°C (23°F...122°F) (EN 60730-2-9:2010)
Storage temperature:	-20...85°C (-20°F...185°F) -20...70 °C (-20 °F...158 °F) <sup>(1)</sup>
Operating humidity:	10...90% non-condensing
Storage humidity:	10...90% non-condensing
Power supply:	230 Vac ±10 % 50/60 Hz
Power consumption:	11 VA max
Magnetothermal switch:	<b>EWRC 500 BREAKER</b> : Two-pole (2P)
Control:	EWRC NT electronic controller
Connection:	device on external flexible cable, Y type connection
Digital outputs (relay):	refer to the label on the device
Fire resistance category:	D
Software class:	A
Ball test temperature:	100°C (212°F)
Clock backup: (HACCP models only)	Up to four days in the absence of an external power supply.

### 2.2. ELECTRICAL SPECIFICATIONS

Rated voltage (Un):	230 Vac
Rated operating voltage (Ue):	230 Vac
Rated insulation voltage (Ui):	230 Vac
Rated impulse withstand voltage (Uimp):	<b>EWRC 500 BREAKER</b> <sup>(1)</sup> : 4 kV (EN 61439-2:2011)
Rated panel current (InA):	<b>EWRC 500 BREAKER</b> <sup>(1)</sup> : 16 A (EN 61439-2:2011)
Rated circuit current (InC):	<b>EWRC 500 BREAKER</b> <sup>(1)</sup> : 16 A (EN 61439-2:2011)
Conditioned short circuit current (Icc):	< 4.5 kA
Rated frequency (fn):	50/60 Hz

<sup>(1)</sup> **EWRC 500 BREAKER** RCA●●●R●●●●●● / RCA●●●S●●●●●● / RCNA●●●R●●●●●● / RCNA●●●S●●●●●●

## 2.3. FURTHER INFORMATION

### 2.3.1. INPUT CHARACTERISTICS

Measurement range:	NTC: -50.0...110°C (-58°F...230°F); (on 3-digit display with +/- sign) PTC: -55.0...150°C (-67°F...302°F); (on 3-digit display with +/- sign)
Accuracy:	better than 0.5% integral scale + 1 digit
Resolution:	0.1°C (0.1°F)
Buzzer:	only on models where this is provided
Analogue inputs:	3(2) configurable NTC/PTC inputs
Digital inputs:	2(3) multi-function, voltage-free digital inputs (DI)

### 2.3.2. OUTPUT CHARACTERISTICS

RELAY OUTPUTS						
MODEL	EWRC 300 NT		EWRC 500/5000 NT		EWRC 500 NT	
CODE	RCS•H•••••••• RCNS•H••••••••		RCS•U•••••••• RCA•U•••••••• RCH300•••••••• RCNS•U•••••••• RCNA•U••••~••••• RCNH300••••~•••••		RCS•P••••~••••• RCA•P••••~••••• RCNS•P••••~••~•• RCNA•P••••~••~••	
STANDARD	EN60730 max 250 Vac	UL60730 max 240 Vac	EN60730 max 250 Vac	UL60730 max 240 Vac	EN60730 max 250 Vac	UL60730 max 240 Vac
OUT1	12(8) A	12FLA - 72LRA	12(8) A	12FLA - 72LRA	12(8) A	12FLA - 72LRA
OUT2	8 A	8FLA - 48LRA	8 A	8FLA - 48LRA	8 A	8FLA - 48LRA
OUT3	8(4) A	8A resistive 4.9FLA - 29.4LRA	8(4) A	8 A resistive 4.9FLA - 29.4LRA	12(8) A	12FLA - 72LRA
OUT4	-	-	8 A	8FLA - 48LRA	8 A	8FLA - 48LRA
OUT5	-	-	NO 8(4) A, NC 6(3) A	NO 8 A, NC 6 A resistive NO 4.9FLA - 29.4LRA	NO 8(4) A, NC 6(3) A	NO 8 A, NC 6 A resistive NO 4.9FLA - 29.4LRA
NOTE	Maximum common flow rate 16 A for models EWRC500 BREAKER: <b>RCA•••S•••••••• / RCA•••R••••••••</b> <b>RCNA•••S••••~••~••••• / RCNA•••R••••~••~•••••</b> Maximum common flow rate 18 A for all other models					

---

### 2.3.3. MECHANICAL CHARACTERISTICS

Casing:	PC+ABS
Dimensions:	<b>EWRC 300/500</b> front panel 213 x 318 mm, depth 102 mm <b>EWRC 500 BREAKER</b> front panel 221 x 318 mm, depth 107 mm <b>EWRC 5000</b> front panel 420 x 360 mm, depth 147 mm
Terminals:	screw See "4.1.2. Rules for screw-type terminal boards" page 21
Connectors:	TTL for UNICARD / Copy Card / Device Manager connection (via DMI)
Humidity:	Operation / Storage: 10...90% RH (non-condensing)

**NOTE:** The technical specifications stated in this document regarding the measurement (range, accuracy, resolution, etc.) refer strictly to the instrument and not to any accessories provided, such as the probes.

## 3. MECHANICAL INSTALLATION

### 3.1. Before starting

Before starting to install your system, read this chapter carefully. Caution must be exercised concerning compliance with all safety information, other electrical requirements or laws which may apply to your machine or process when using this equipment.

#### **WARNING**

##### **REGULATORY INCOMPATIBILITY**

Make sure that all equipment used and the systems designed comply with all applicable local, regional and national laws.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### 3.2. Disconnection from the power supply

#### **DANGER**

##### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables or wires.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- Before powering the device back up, fit back and fix all the covers, hardware components and wiring.
- Check the earthing connections on all earthed devices.
- Use only the specified voltage when operating this equipment and any associated products.
- Comply with all standards regarding accident protection and local applicable safety directives.

**Failure to follow these instructions will result in death or serious injury.**

### 3.3. Operating environment

#### Flammable refrigerant gases

This equipment is designed to operate outside all hazardous locations and is not to be used in applications which generate (or could potentially generate) hazardous environments. Install this equipment only in areas and applications known to be free from dangerous atmospheres at all times.

#### **DANGER**

##### **POTENTIAL FOR EXPLOSION**

- Install and use this equipment in non-hazardous locations only.
- Do not install or use this equipment in applications which could generate hazardous atmospheres, such as applications which use flammable refrigerants.

**Failure to follow these instructions will result in death or serious injury.**

For information regarding the use of control equipment in applications capable of generating hazardous materials, please contact the relevant national regulatory bodies or certifying authorities.

---

**⚠ WARNING**

**UNINTENDED EQUIPMENT OPERATION**

Install and use the equipment in compliance with the conditions described in the Technical Specifications chapter.  
**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### 3.4. Comments concerning installation

**⚠ WARNING**

**UNINTENDED EQUIPMENT OPERATION**

- Use appropriate safety interlocks where personnel and/or equipment hazards exist.
- Do not use this equipment in safety-critical machine functions.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

The devices are designed for wall mounting.

When handling the equipment, use caution to avoid damage caused by electrostatic discharge. In particular, the unshielded connectors and in certain cases the open circuit boards are vulnerable to electrostatic discharge.

**⚠ WARNING**

**UNINTENDED EQUIPMENT OPERATION DUE TO ELECTROSTATIC DISCHARGE**

- Keep the equipment in the protective packaging until ready for installation.
- The equipment must only be installed in type-approved casing and/or in points that prevent unauthorised access and provide protection from electrostatic discharge.
- When handling sensitive equipment, use an antistatic bracelet or equivalent earthed protective device against electrostatic discharge.
- Before handling the equipment, always discharge the static electricity from the body by touching an earthed surface or type-approved antistatic mat.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### HACCP Module - RCN..... MODELS

***NOTICE***

**INOPERABLE EQUIPMENT**

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).


**Failure to follow these instructions can result in equipment damage.**

**NOTE.** For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.


## 3.5. INSTALLATION PROCEDURE

**NOTE:** procedural steps that are common to all models. ONLY the EWRC 5000 model is used as an example.

- 1) Remove the cover and drill the holes for the cable clamps (at least one for power cables and one for signalling cables) on the bottom of the panel.  
**NOTE:** for the 300/500 models, use the drilling template provided.




- 2) Drill the wall fixing holes on the back of the panel, in the areas marked on the back.






Hinges are available for mounting on special compartments for opening the cover both right and left. Screw on the respective anchoring screws taking care that the hinges are fitted well and lie flush so that they do not interfere with the compression of the seal.

- 3) Optional. Fit the panel.

**NOTE:** on models 300/500 with front door two more DIN spaces can be created: open the door with both hands as shown in the figure, then remove the factory-fitted push-through tabs.



- 4) Optional. Install the plug-in RS-485 module for communication with the supervisor.  
 EWRC 5000 only:
- 1) Remove the seven screws securing the plastic protecting the the board.
  - 2) Remove the protective element, then use a box cutter to remove the two terminal covers.
  - 3) Connect the RS-485 plug-in module (optional) using the specific spacers, then replace the cover and secure it using the screws.





**NOTICE**

**INOPERABLE DEVICE**

Fit the plug-in RS-485 module in the plug-in connector aligning the four posts with the holes in the control board.

**Failure to follow these instructions can result in equipment damage.**

- 5) Fix the back of the panel to the wall using four screws (not supplied) suited to the wall thickness.  
**NOTE:** TDI20 screw caps (not provided) can be fitted to 300/500 models at the wall mounting points so that the IP rating is not altered.



**⚡ ⚠ DANGER**

**HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

For models with magnetothermal switch, before connecting make sure that switch is in the OFF position.

**Failure to follow these instructions will result in death or serious injury.**



- 
- 6) Make the electrical connections referring to the wiring diagrams shown page 23 and page 25. Use suitable cable/pipe clamps.


**NOTE:** only models with magnetothermal switch. Connect the switch to the electronic board power supply using the accessory cable provided in the packaging.

---

- 7) Hinges are available for mounting on special compartments for opening the cover both right and left. Screw on the respective anchoring screws taking care that the hinges are fitted well and lie flush so that they do not interfere with the compression of the seal. Fit the hinges to secure the cover.


#### EWRC 5000

Place the panel cover on the base making it stick to the perimeter seal. Then, while holding the cover in place, fit the two hinges provided into the corresponding holes and press them until you hear them click as they are locked into place.




#### EWRC 300/500

Fit the hinges provided into their housings on the right or left side of the panel and tighten the corresponding screws to secure them.



- 
- 8) Close the cover and secure it with the screws provided.



---


## **⚡ ⚠ DANGER**

### **RISK OF ELECTRIC SHOCK, EXPLOSION OR EXPOSURE TO ACCESSIBLE PARTS**


The final application must disallow access to parts at hazardous voltage, as the instrument offers no intrinsic protection against this risk.

**Failure to follow these instructions will result in death or serious injury.**

- 9) DIN rail-mounted models with window only. Close access to inside the panel from the front window using the dedicated DIN plugs.  
 For EWRC NT 500 models with the plastic knockout removed and no internal magnetothermal switch, the end user is responsible for ensuring that the open parts of the box are not accessible.



- 10) EWRC 5000 only. Fit the door (a): align the front door with the two hooks at the bottom of the panel and push it towards the right until you hear it click as it locks into place.



- 11) Close the door (b)

## ⚠ WARNING

### UNINTENDED EQUIPMENT OPERATION

- Place the devices dissipating the most heat in the top of the cabinet and ensure suitable ventilation.
- Do not place this equipment near or above any devices which could cause overheating.
- Install the device in a point that guarantees the minimum distances from all structures and adjacent equipment as indicated in this document.
- Install all equipment in conformity with the technical specifications given in the respective documentation.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**




Fig. 1. Distance valid for all models

## 4. ELECTRICAL CONNECTIONS

---

### 4.1. Wiring practices

The following information describes the guidelines for wiring and the associated best practices to follow when using the device.

#### **DANGER**

##### **HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables or wires.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- Before powering the device back up, fit back and fix all the covers, hardware components and wiring.
- Check the earthing connections on all earthed devices.
- Use only the specified voltage when operating this equipment and any associated products.
- Comply with all standards regarding accident protection and local applicable safety directives.

**Failure to follow these instructions will result in death or serious injury.**

#### **DANGER**

##### **HAZARD OF OVERHEATING AND/OR FIRE**

- Do not use with loads other than those indicated in the technical specification.
- Do not exceed the maximum permitted current; for higher loads, use a meter with sufficient power capacity.

**Failure to follow these instructions will result in death or serious injury.**

This equipment is designed to operate outside all hazardous locations and is not to be used in applications which generate (or could potentially generate) hazardous environments. Install this equipment only in areas and applications known to be free from dangerous atmospheres at all times.

#### **DANGER**

##### **POTENTIAL FOR EXPLOSION**

- Install and use this equipment in non-hazardous locations only.
- Do not install or use this equipment in applications which could generate hazardous atmospheres, such as applications which use flammable refrigerants.

**Failure to follow these instructions will result in death or serious injury.**

For information regarding the use of control equipment in applications capable of generating hazardous materials, please contact the relevant national regulatory bodies or certifying authorities.

---

### 4.1.1. Wiring guidelines

The following regulations must be complied with for wiring:

- Make connections as short as possible and do not wind them around electrically connected parts.
- Check that the operating conditions and surroundings comply with the specification values.
- Use wires of the correct diameter and suited to the voltage and current requirements.
- Use copper conductors (obligatory).

 <b>WARNING</b>
--

<b>UNINTENDED EQUIPMENT OPERATION</b>
---------------------------------------

- |  |
|--|
| <ul style="list-style-type: none"><li>• The equipment signal cables (probes, digital inputs, communication, and the relative power supplies) must be laid separately from the power cables.</li><li>• Every end application of this device must be tested individually and completely in order to check its proper operation before putting it in service.</li></ul> |
|--|

<b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b>
---

### HACCP Module - RCN..... MODELS

<b><i>NOTICE</i></b>
----------------------

<b>INOPERABLE EQUIPMENT</b>
-----------------------------










For TTL serial line connection, use cables no longer than 1 m (3.28 ft).
--

<b>Failure to follow these instructions can result in equipment damage.</b>
---



**NOTE.** For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.

### 4.1.2. Rules for screw-type terminal boards

The table below illustrates the types of cables and wire sections for a screw-type terminal board with **5.08 (0.197 in.)** spacing:










								
mm <sup>2</sup>	0.2...2.5	0.2...2.5	0.25...2.5	0.25...2.5	2x0.2...0.75	2x0.2...0.75	2x0.25...0.75	2x0.5...1.5
AWG	24...14	24...14	22...14	22...14	2x24...18	2x24...16	2x22...18	2x20...16



		N•m	0.5...0.6
Ø 3,5 mm (0.14 in.)		lb-in	4.42...5.31

**Fig. 2.** Spacing 5.08 mm (0.197 in.)

The table below illustrates the types of cables and wire sections for a screw-type terminal board with **7.62 (0.30 in.)** spacing:






								
mm <sup>2</sup>	0.2...4	0.2...2.5	0.25...2.5	0.25...2.5	2x0.2...1.5	2x0.2...1.5	2x0.25...0.75	2x0.5...1.5
AWG	24...12	24...14	22...14	22...14	2x24...16	2x24...16	2x22...18	2x20...16

		N•m	0.5...0.6
Ø 3,5 mm (0.14 in.)		lb-in	4.42...5.31

**Fig. 3.** Spacing 7.62 mm (0.3 in.)

The table below illustrates the types of cables and wire sections for the magnetothermal switch:

					N•m	2
mm <sup>2</sup>	1...25	1...16	Ø 6 mm (0.24 in.)		lb-in	17.7
AWG	18...4	18...6				

**Fig. 4.** Cable types and tightening torque for the magnetothermal switch

## DANGER

### LOOSE WIRING CAN RESULT IN ELECTRIC SHOCK

Tighten the connections in compliance with the technical specifications for pairs.

**Failure to follow these instructions will result in death or serious injury.**

---

### Specific considerations for handling

When handling the equipment, use caution to avoid damage caused by electrostatic discharge. In particular, the unshielded connectors and in certain cases the open circuit boards are vulnerable to electrostatic discharge.

#### **⚠ WARNING**

##### **UNINTENDED EQUIPMENT OPERATION DUE TO ELECTROSTATIC DISCHARGE**

- Keep the equipment in the protective packaging until ready for installation.
- The equipment must only be installed in type-approved casing and/or in points that prevent unauthorised access and provide protection from electrostatic discharge.
- When handling sensitive equipment, use an antistatic bracelet or equivalent earthed protective device against electrostatic discharge.
- Before handling the equipment, always discharge the static electricity from the body by touching an earthed surface or type-approved antistatic mat.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### 4.1.3. Analogue Inputs-Probes

#### **⚠ WARNING**

##### **UNINTENDED EQUIPMENT OPERATION DUE TO CONNECTIONS**

- The equipment signal cables (probes, digital inputs, communication, and the relative power supplies) must be laid separately from the power cables.

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

#### **NOTICE**

##### **INOPERABLE DEVICE**

Before switching on the electrical power, check all the wiring connections.

**Failure to follow these instructions can result in equipment damage.**

**NOTE:** The NTC temperature probes do not feature any connection polarity and can be extended using normal bipolar cable.

---

#### 4.1.4. Serial connections

The controller can be connected to Televis**System** / Modbus remote control systems by a direct RS-485 connection using the RS-485 optional plug-in module.

#### 4.1.5. RS-485 connection

- Use a “**twisted pair**” shielded cable with two conductors with cross-section 0.5 mm<sup>2</sup> (AWG 20), plus sheath, such as, for example, a Belden cable version 3105A (typical impedance 120 Ω) with PVC sheath, rated capacity between conductors 36 pF/m, rated capacity between conductor and sheath 68 pF/m. Alternatively, use a “**twisted pair**” shielded cable with two conductors with cross-section 0.5 mm<sup>2</sup> (AWG 20), plus sheath, such as, for example, a Belden cable version 8762 with PVC sheath, rated capacity between conductors 89 pF/m, rated capacity between conductor and sheath 161 pF/m. For laying wires, comply with the indications given in standard EN 50174 on information technology wiring.
- Follow the applicable regulations for laying and connecting the cables. Extra care must be taken in separating data transmission circuits from power lines.
- The length of the RS-485 network which can be connected directly to the controller is 1200 m. This length can be extended and the number of devices for each channel increased using appropriate repeater modules.
- Input impedance: 1/8 unit load.
- Single terminal board with 3 conductors: use all 3 conductors (“+” and “-” for the signal and “GND” for the braiding).
- Attach the 120 Ω 1/4W resistors between the “+” and “-” terminals on the interface and the last controller in each branch of the network.
- The RS-485 physical level can be used for Modbus SL communication  
Concurrent communication of different protocols on the same serial port is **NOT** permitted.

Pay special attention when connecting serial lines. Incorrect wiring may cause the equipment to stop working.

<b>NOTICE</b>
---------------

<b>INOPERABLE DEVICE</b>
--------------------------

Do not communicate simultaneously via Modbus and Televis protocols on the same serial port. <b>Failure to follow these instructions can result in equipment damage.</b>
--

#### 4.1.6. TTL connection

Use a 5-wire TTL cable up to 3 m (118 in.) in length.

An Eliwell-supplied TTL cable is recommended. Contact Eliwell Sales Office for item availability.

#### HACCP Module - RCN..... MODELS

<b>NOTICE</b>
---------------


<b>INOPERABLE EQUIPMENT</b>
-----------------------------

For TTL serial line connection, use cables no longer than 1 m (3.28 ft).
--

<b>Failure to follow these instructions can result in equipment damage.</b>
---

**NOTE.** For information on the cables to be used with the HACCP Module, contact your local Eliwell representative.

# WIRING DIAGRAM




## 4.1.7. TERMINALS

TERMINALS	
<b>1, 5, 8</b>	GND
<b>2</b>	Analogue input Pb1
<b>3</b>	Analogue input Pb2
<b>4</b>	Analogue input Pb3 / Digital input DI3
<b>6</b>	Digital input DI2
<b>7</b>	Digital input DI1
<b>CARD</b>	TTL for connection to HACCP Module (MODELLE RCN••••••~••••••~••••••) / UNICARD / Copy Card / TelevisSystem
<b>RS-485</b>	Plug-in module for connection to TelevisSystem / Modbus (optional)
<b>9, 10</b>	LINE/NEUTRAL. Power supply
<b>11</b>	NO OUT1
<b>12</b>	NEUTRAL
<b>13</b>	NO OUT2
<b>14</b>	NEUTRAL
<b>15</b>	NO OUT3
<b>16</b>	NEUTRAL
<b>17</b>	NO OUT4
<b>18</b>	NEUTRAL
<b>19</b>	NC OUT5
<b>20</b>	OUT5 Common terminal
<b>21</b>	NO OUT5



## 4.2. WIRING DIAGRAM FOR MODELS WITH MAGNETOTHERMAL SWITCH INSTALLED




### 4.2.1. TERMINALS

TERMINALS			
1, 5, 8	GND	9, 10	LINE/NEUTRAL. Power supply
2	Analogue input Pb1	11	NO OUT1
3	Analogue input Pb2	12	NEUTRAL
4	Analogue input Pb3 / Digital input DI3	13	NO OUT2
6	Digital input DI2	14	NEUTRAL
7	Digital input DI1	15	NO OUT3
CARD	<b>"4.2.1. TERMINALS" page 24</b>	16	NEUTRAL
RS-485	<b>"4.2.1. TERMINALS" page 24</b>	17	NO OUT4
		18	NEUTRAL
		19	NC OUT5
		20	OUT5 Common terminal
		21	NO OUT5

## 5. USER AND START-UP INTERFACE

### 5.1. DISPLAY

#### 5.1.1. KEYS



No.	KEY	press and release	press and hold for about 3 seconds	NAVIGATION MENU	Notes
A	ESC Defrost	<ul style="list-style-type: none"> <li>• Functions Menu</li> </ul>	<ul style="list-style-type: none"> <li>• Manual defrost</li> <li>• Return to Main Menu</li> </ul>	<ul style="list-style-type: none"> <li>• Output</li> </ul>	Configurable - see parameter H33
B	▲ UP Alarms	<ul style="list-style-type: none"> <li>• Alarms Menu (always visible)</li> </ul>	/	<ul style="list-style-type: none"> <li>• Scroll</li> <li>• Increase values</li> </ul>	HACCP alarms only on foreseen models and if present
C	SET	<ul style="list-style-type: none"> <li>• Display setpoint / probe values / time (Models with clock only)</li> <li>• Confirm values</li> <li>• Access value edit mode (top display blinking)</li> </ul>	Access Parameters menu	<ul style="list-style-type: none"> <li>• Confirm values</li> <li>• Move right</li> </ul>	Time only visible on models with clock
D	▼ DOWN AUX	<ul style="list-style-type: none"> <li>system INFO</li> <li>See Technical Support</li> </ul>	Activate auxiliary function	<ul style="list-style-type: none"> <li>• Scroll</li> <li>• Decrease values</li> </ul>	Configurable - see parameter H32
E	ON/OFF	/	Switch On/Off device	/	Configurable - see parameter H34
F	LIGHT	Switch light On/Off	Switch light On/Off	/	Configurable - see parameter H35

### 5.1.2. DISPLAY MEANING


G	H
<b>3-FIGURE TOP DISPLAY plus the - sign</b>	<b>4-FIGURE BOTTOM DISPLAY</b>
Display: <ul style="list-style-type: none"> <li>• operating value</li> <li>• parameters label</li> <li>• alarms, functions</li> </ul> if TOP display is <b>blinking</b> it means that the value of the BOTTOM Display can be modified	Display: <ul style="list-style-type: none"> <li>• parameters value</li> <li>• probe value</li> <li>• function state</li> </ul> <b>HACCP models</b> <ul style="list-style-type: none"> <li>• time</li> </ul>

### 5.1.3. CONNECTION TO HACCP Module



**RCN●●●●●●●●●●** models: when the HACCP Module is connected and the Bluetooth connection to the Eliwell Air App is active, the btL label appears on the TOP DISPLAY and the BOTTOM DISPLAY and icons are turned off.

## 5.1.4. ICONS



Icons have the following meaning:

No.	ICON	colour	description
17	%RH	amber	not used
18	TIME	amber	access in case of time display or editing
19	DATA	amber	access in case of date display or editing

Alarms	ICON 7	ICON 8	Colour	Buzzer	OFF	
					Icon	Buzzer
ALARM			Red	See "8.2. ALARM CAUSE/EFFECT TABLE" page 81		
PANIC			Red		---	---
LEAK DETECTOR			Red			---
PANIC + LEAK DETECTOR			Red		---	(1)

(1) = As long as the Panic alarm persists it will not be possible to mute the buzzer from the keypad.

No.	Icon	colour	ON	BLINKING	OFF
1	POWER SUPPLY	green	Power supply ON	/	Power supply OFF
2	ENERGY SAVING	amber	Energy saving ON	/	Energy saving OFF
3	NIGHT & DAY	amber	Night & Day ON	/	Night & Day OFF
4	HACCP	amber	HACCP menu	/	/
5	DEEP COOLING (DCC)	amber	Drip cooling cycle ON	/	Drip cooling cycle OFF
6	PUMP DOWN	amber	Compressor Pump Down ON	/	Compressor Pump Down OFF
9	COMPRESSOR	amber	Compressor ON	Delay	Compressor OFF
10	DEFROST 1	amber	Defrost	Dripping	No defrost
11	EVAPORATOR FANS	amber	Fans ON	Forced ventilation	Fans OFF
12	DEFROST 2	amber	Defrost	Dripping	No defrost
13	HACCP ALARM	red	HACCP alarm	Not displayed	No alarm
14	AUXILIARY (AUX)	amber	AUX ON	/	AUX OFF
15	LIGHT	amber	Light ON	/	Light OFF
16	CONDENSER FANS	amber	Fans ON	/	Fans OFF

ON: function/alarm ON; OFF: function/alarm OFF

---

## 5.1.5. PRELIMINARY CONFIGURATIONS

After making the electrical connections, simply power up the device to start operation.

At first start-up, Eliwell recommends that you:

1. make sure the instrument is powered (green POWER SUPPLY icon on)
2. make sure the display is working: when the controller is powered up it performs a lamp test, during which time the display and icons will blink for several seconds to ensure that they all function correctly
3. make sure there are no active alarms (ALARM / HACCP ALARM icon off and labels **E1**, **E2**, **E3** not displayed).
4. configure the main parameters listed in the USER menu to suit your requirements, as described below

## 5.1.6. OPERATION IN DEFAULT CONFIGURATION

The instrument is configured for negative cold. For positive cold, disable the evaporator probe Pb2 (set **H42**=n) and relay OUT3 (set **H23**=6) to prevent continuous ventilation.

### COMPRESSOR

The compressor is active if the cold room temperature measured by Pb1 exceeds the value of **SEt** + **diF**. The compressor stops if the cold room temperature detected by Pb1 falls below the **SEt** value. The instrument includes compressor on/off protection.

### DEFROST

Defrost is by means of electric heaters (parameter **dtY** = 0) and the time counter is always active with the instrument switched on (**dCt**=1).

### Manual defrost

Manual defrost is activated by pressing and holding the ESC key (A)

If conditions are not right for defrosting, (e.g. the evaporator probe temperature is higher than the defrosting end temperature) or parameter **OdO**≠0, the display will blink three times to indicate that the operation will not be performed.

### Default Defrost settings

**dit** = 6 hours. interval between 2 defrost cycles

**dSt** = 6.0 °C. defrosting end temperature. set by Pb2

The Defrost cycle may terminate due to a timeout based on the parameter **dEt** (default 30 min).

### EVAPORATOR FANS

The OUT3 relay is configured as the fan relay and is activated when required, according to the delay and parameter settings.

### Default fan settings

**dt** = 0 min. dripping time

**dFd** = Y. Fans off during defrosting

### LIGHT (EWRC 500/5000)


The light is activated by pressing and holding the LIGHT key (F)

As digital input DI1 is configured as door switch, relay OUT4 (light) is activated when the door is opened. The light also switches on with the instrument in stand-by.

### ALARM relay (EWRC 500/5000)

Relay OUT5 is configured as alarm relay and is activated in the case of alarms, according to delays and parameter settings.

## 5.1.7. NAVIGATION








### 5.1.8. FUNCTIONS MENU AND KEY-ENABLED FUNCTIONS

The Functions menu is used to perform a number of manual functions such as putting the device into stand-by, clearing pressure switch interventions and clearing HACCP alarms, etc.

Access the Functions menu by pressing the ESC key.

The following table lists the functions, which are all OFF by default.

Display	Function	description
	Keypad lock	The UP/ESC/ON-OFF/LIGHT keys and the functions programmed via keys are locked The DOWN key may be used to view the Setpoint only; the value cannot be modified Only function visible if keypad locked (On)
	Disables HACCP alarm recording	Disables HACCP alarm recording
	Reset pressure switch alarm	Clears pressure switch alarm NOTE: the function reverts to OFF status when you exit the Functions Menu
	Reduced set	Reduced set
	Reset HACCP alarms	Clears HACCP alarms May be protected by Password PA3

All models have the **UP** key set to display the Alarms Menu.

All models also allow the setting of other keys to activate a specific function as identified by the client.

The parameters for configuring the two keys are:

- **H32** = DOWN key configuration
- **H33** = ESC key configuration
- **H34** = ON/OFF key configuration
- **H35** = LIGHT key configuration

The values that can be set apply to these keys and the functions that can be activated are:

Value of H32/H33/H34/H35	
0 = disabled	10 = Activate / disable Frame Heater relay
1 = defrost	11 = Enable/disable Night And Day functions
2 = Auxiliary	12 = deep cooling cycle
3 = Activate reduced set	13 = Clear voltage drop errors (Reset Power Failure)
4 = Reset HACCP alarms	14 = Service stoppage
5 = Disable HACCP alarms	15 = Activate economy set + Night And Day
6 = Light	
7 = Stand-by	
8 = NOT USED	
9 = Evaporator fans ON	






### 5.1.9. PASSWORDS

Password PA1 is disabled by default.

Password "PA1": allows access to **User** parameters.



To enable (PA1≠0): press and hold **SET** for more than 3 seconds. The label **USr** appears. Press **SET** again. Scroll through the parameters using **UP** and **DOWN** until you find label **PA1**, press **SET** to display its value, change it using **UP** and **DOWN** and save by pressing **SET** or **ESC**.

**Example with password enabled (PA1≠0):** it will be requested before access to the User parameters is granted.





Display	description
	Press SET for 3 seconds
	Label PA1 appears
	Press SET Use UP and DOWN keys to enter the password
	In the example the password is 12 Press SET
	User menu accessed The first User parameter appears  If the value entered is incorrect, label <b>PA1</b> will be shown again and the procedure must be repeated

Password "PA2": allows access to **Installer** parameters.

The example is the same. Note. Password **PA2** is set by default to **15**





Display	description
	Press SET for 3 seconds
	Label USr appears Use 'UP' and 'DOWN' to search for InS










Display	description
	Press SET
	Use UP and DOWN keys to enter the password
	In the example the password is 15 Press SET
	Installer menu accessed the first CP folder appears  If the value entered is incorrect, label <b>PA2</b> will be shown again and the procedure must be repeated

### 5.1.10. SETPOINT PROGRAMMING

By way of example, we will change the Setpoint value from -18.0 degrees centigrade to -20.0 degrees centigrade.









Display	description
	Press and release the SET key
	The top display will show SEt, the bottom display will indicate the current setpoint value Press and release the SET key once more
	The top display will show SEt blinking Use the UP & DOWN keys to adjust the setpoint value
	Press the ESC key several times to return to the normal display (or press the SET key to confirm, followed by ESC to exit)  The new Setpoint value is saved and appears on the bottom display

## 5.1.11. VIEWING PROBE VALUES





Display	description
	Press and release the SET key
	<p>The top display will show SET, the bottom display will indicate the current setpoint value</p> <p>Use the DOWN key to view the value of probe Pb1</p>
	The time is displayed in HACCP models
	Use the DOWN key again to view the value of probe Pb1
	Use the DOWN key again to view the value of probe Pb2
	<p>If H43 is not 0 (probe 3 present)</p> <p>Use the DOWN key again to view the value of probe Pb3</p>
	<p>Press the ESC key to return to the normal display</p> <p>Normal display</p>

### 5.1.12. How to modify the date and time

Function only available in HACCP models

Display	description
	<p>Press and release the SET key</p>
	<p>The top display will show SET, the bottom display will indicate the current setpoint value Use the DOWN key to display the time</p>
	<p><b>The CLOCK icon will be on</b> Press and release the SET key.</p>
	<p><b>The CLOCK icon will be on</b> <u>The hour value will begin to blink</u> Use the UP &amp; DOWN keys to adjust the hour value</p>
	<p><b>The CLOCK icon will be on</b> Press and release the SET key</p>
	<p><b>The CLOCK icon will be on</b> The hour value has been changed <u>The minute value begins to blink</u> Use the UP &amp; DOWN keys to adjust the hour value</p>
 	<p>Repeat this procedure to adjust the date value (DAY.MONTH) and YEAR  In this case the DATA icon (31) is on  Press the ESC key several times to return to the normal display</p>





### 5.1.13. Displaying Alarms

Display	description
	<p>Press and release the UP key. The top display will show ALr.</p>
 	<p>The bottom display will show</p> <ul style="list-style-type: none"> <li>a. nOnE if no alarms active</li> <li>b. SYSt if system alarms present</li> </ul>
	<p style="text-align: center;"><b>HACCP models ONLY</b></p> <p>The top display will show ALr.</p> <p>The bottom display will show HACCP if HACCP alarms are present NOTE: parameter H50 must = 1</p>

### 5.1.14. System Alarms example

Let us suppose two alarms have occurred,

- one HIGH TEMPERATURE on the cold room probe
- one HIGH TEMPERATURE on probe 3 (parameter H43 different from 0)

Display	description
	<p>Press and release the UP key.</p>
	<p>The top display will show ALr. The bottom display will indicate SYSt Press and release the SET key.</p>
	<p>The top display will show ALr. The bottom display will show HA1 HIGH TEMPERATURE alarm on the cold room probe Use the UP &amp; DOWN keys to view other alarms, if present</p>
	<p>In the example, the bottom display will indicate HA3 HIGH TEMPERATURE alarm on probe 3 (see para. H43) Press the ESC key several times to return to the normal display</p>






### 5.1.15. Modifying a parameter

The User parameters **USr** are not divided into subfolders. They are always visible by default (access password PA1 is not enabled by default). The same parameters are also visible in the respective folders 'Compressor', 'Fans', etc. within the Installer parameters menu **InS**. The password is enabled (PA2=15) by default.

**NOTE: It is advisable to switch the device off and on again each time the configuration of the parameters is changed, so as to prevent malfunctions affecting the configuration and/or the current timings.**






#### How to modify a user parameter

Instructions are provided below on how to modify a User parameter. The same procedure applies to Installer (**inS**) level parameters. Let us take the **dit** parameter as our example. There are no sub-folders at User level. At Installer level the parameter is in the folder containing **dEF** defrost parameters. We will now show how to change the value from 6 hours to 8 hours.

Display	description
	Press and hold the SET key for approx. 3 seconds
	<p>The folder for USr parameters will appear</p> <p>Press and release the SET key.</p> <p>Press and release the SET key to access the first parameter</p>
	<p>The first User parameter appears</p> <p>Use the UP &amp; DOWN keys to find the parameter that you wish to modify</p>
	<p>Press and release the SET key.</p> <p>The dit label will blink</p> <p>Use the UP &amp; DOWN keys to adjust its value</p>
	Press and release the SET key to confirm the modification.

## How to modify an Installer parameter

Instructions are provided below on how to modify the same User parameter but via the Installer menu  
 Let us take the **dit** parameter as our example.  
 At Installer level the parameter is in the folder containing **dEF** defrost parameters.  
 We will now show how to change the value from **8 h** to **6 h**.

Display	description
	<p>Press and hold the SET key for approx. 3 seconds</p>
	<p>The folder for USr parameters will appear            Use the UP &amp; DOWN keys to search for the inS folder            Press and release the SET key.</p> <p>Press and release the SET key to access the first parameter</p>
	<p>The first folder appears</p> <p>Use the UP &amp; DOWN keys to search for the dEF folder</p>
	<p>Press and release the SET key.</p> <p>The first parameter in the dEF folder will appear            Use the UP &amp; DOWN keys to find the parameter you want to change</p>
	<p>Press and release the SET key.            The dit label will blink            Use the UP &amp; DOWN keys to adjust its value</p> <p>Press and release the SET key            to confirm the modification.</p>

## 6. FUNCTIONS AND REGULATORS

---

This chapter describes the various functions of the devices.

**NOTE:** some functions may not be available in certain models.

### 6.1. SETTINGS

#### 6.1.1. PROBE SETTING AND CALIBRATION

**EWRC 300/500/5000 NT** have 3 configurable NTC/PTC inputs (Pb1...Pb3).

The temperature probes (Pb1...Pb3) must all be the same type and should be configured via parameter **H00**, visible at User level (**USr**) or inside folder **CnF**, Installer level (**inS**)

- **H00** = 0 if using PTC probes
- **H00** = 1 if using NTC probes (Default)

After installation, the values read by the probes can be corrected/calibrated using the following parameters:

- **CA1**: probe 1 offset. Positive or negative value to be added to the value read by Pb1 (Range: **-30.0...30.0**)
- **CA2**: probe 2 offset. Positive or negative value to be added to the value read by Pb2 (Range: **-30.0...30.0**)
- **CA3**: probe 3 offset. Positive or negative value to be added to the value read by Pb3 (Range: **-30.0...30.0**)

#### 6.1.2. DISPLAY SETTINGS

At User level (**USr**) or inside the **diS** folder at Installer level (**inS**) you will find the parameters used to set the temperature readout, decimal point usage, unit of measure and display during defrost.

- **ndt**: (**USr/inS**) enables/disables decimal point display (with resolution of one-tenth of a degree; e.g.: 10.0°C)  
Display with decimal point is only possible within the range of values from -99.9°C to 99.9°C
  - **ndt** = y → displays read values with decimal point (**default**);
  - **ndt** = n → displays read values without decimal point

**NOTE:** enabling/disabling the decimal point only affects the on-screen display of values. The controller will continue to perform calculations with decimal point.
- **ddl**: (**USr/inS**) sets the type of display during and up to the end of defrost
  - **ddl** = 0 → displays the probe value (**default**)
  - **ddl** = 1 → continues to display the value read by the probe at the start of defrosting
  - **ddl** = 2 → displays the fixed label **dEF**
- **dro**: (**inS**) sets temperature display to °C or °F.
  - **dro** = 0 → display in °C (**default**)
  - **dro** = 1 → display in °F

**NOTE:** switching between °C and °F DOES NOT modify the values of temperature parameters (e.g. setpoint=10°C becomes 10°F). This means that the maximum and minimum limits of parameters as absolute values are the same for both units of measure and hence the ranges are different.
- **ddd**: (**inS**) establishes the value to be shown on the top display. All other display and adjustment modes are the same.
  - **ddd** = Set → displays the Setpoint value
  - **ddd** = Pb1 → displays the values read by Pb1 (**default**)
  - **ddd** = Pb2 → displays the values read by Pb2
  - **ddd** = Pb3 → displays the values read by Pb3



---

## 6.2. FUNCTIONS

### 6.2.1. UPLOAD, DOWNLOAD, FORMAT

#### Description

The UNICARD / Copy Card must be connected to the (TTL serial port and allows the rapid programming of instrument parameters.

**DOWNLOAD** from reset operating mode: at power-on, if the UNICARD / Copy Card is inserted in the device, the controller automatically downloads data.

After connecting the UNICARD / Copy Card with the instrument switched off and on completion of the lamp test, one of the following labels will be displayed:

- **dLY** if the operation was successful
- **dLn** if the operation was not successful

After about 5 seconds, the display will show the probe or set point value, depending on the default settings.

**NOTE:** once the download has been completed successfully, the controller will start to work with the new map loaded.

Operating mode: access "Installer" parameters by entering the password "**PA2**" if enabled (PA2≠0), scroll through the folders using **UP & DOWN** until the folder "**FPr**" appears. Select it using **SET**, scroll through the parameters using **UP & DOWN** and then select one of the functions by pressing **SET**:

- **UL** (Upload): With this function, the programming parameters are uploaded from the instrument to the card. If the operation is successful, the display will show "**y**", otherwise it will show "**n**".
- **Fr** (Format): This command is used to format the copy card (which is necessary when using the card for the first time).  
**NOTE:** the use of the **Fr** parameter deletes all data present and this operation cannot be reversed.
- **Download:** Connect the UNICARD / Copy Card when the instrument is switched off. At power-on, data will automatically start downloading from the UNICARD / Copy Card to the instrument. At the end of the lamp test, the display will show "**dLy**" if the operation was successful and "**dLn**" if not.

**NOTE:** before Uploading or Downloading a map, make sure that communication with the supervisor (PC with Televis, TelevisGo system, etc.) has been cut off.

This means you should make sure that the RS-485 is disconnected from the instrument or that Supervision system acquisitions have been stopped.

#### Parameters

The parameters that control this function are:

Label	Description
UL	Transfer of programming parameters from device to UNICARD / Copy Card <b>COLDFACE → UNICARD / Copy Card</b>
dL	Transfer of programming parameters from UNICARD / Copy Card to device <b>UNICARD / Copy Card → COLDFACE</b>
Fr	UNICARD / Copy Card formatting. Erases all data on the UNICARD/UNICARD / Copy Card


## 6.2.2. UNICARD

The Unicard lets you download/upload a parameter map from/to a controller, in the same way as the UNICARD / Copy Card. It is a versatile tool that also allows you to quickly and easily customise devices. It differs from the UNICARD / Copy Card in the following ways:


- 1) it can be connected to a computer via USB
- 2) it can be plugged into a USB socket or USB battery, to power the device directly during upload/download.

The UNICARD can be powered in the following ways:

### A) Cabinet powered



### B) Site powered



---

## 6.3. BOOT LOADER FIRMWARE

The device is equipped with a Boot Loader, so it is possible to update the Firmware directly on site. Updating may be carried out using UNICARD or UNICARD / Copy Card (UNICARD / Copy Card).

Updating procedure:

- Connect the UNICARD/UNICARD / Copy Card equipped with the application;
- Power the device if it is off, otherwise switch it off and on again

**NOTE:** the UNICARD/UNICARD / Copy Card can be connected even with the instrument powered.

- Wait until the LED for the UNICARD/UNICARD / Copy Card is blinking (operation in progress);
- The operation will be concluded when the LED for the UNICARD/UNICARD / Copy Card is:
  - **ON:** operation concluded correctly;
  - **OFF:** operation not performed (application not compatible...)

**NOTE:** the LED display is only provided for UNICARDS produced from week 18-12 onwards.

## 6.4. COMPRESSOR

The compressor is controlled by the device's relay. It will be switched on or off depending on:

- the temperature status readings from the cold room probe
- the temperature control functions set
- the defrost/dripping functions (see Defrost chapter)

### 6.4.1. Compressor configuration

See the wiring diagrams for details of how to connect the compressor to the device  
Relay polarity is fixed.

**NOTE:** you MUST check the Compressor → digital output (relay) association by setting parameter **H2x** accordingly.

**NOTE:** By default **H21 = 1 (compressor)**

### 6.4.2. Second compressor configuration

Coldface offers the option of using a second compressor

**NOTE:** you MUST check the Compressor 2 → digital output (relay) association by setting parameter **H2x** accordingly.

Example H25 = 10 (compressor 2).

**NOTE:** to prevent the two compressors from starting up with an insufficient interval in between, an activation delay can be set for the second compressor using **dSC**.

### 6.4.3. Compressor operating conditions

Compressor operation

The regulator is active when:


- the device is ON
- there is not an alarm **E1** indicating control probe fault
- the time set in parameter **OdO** has elapsed
- a defrost cycle is not underway (except in FREE mode)

(There is a fixed interval of one second between the request and activation of the relay)

The parameters that control this regulator are:

- the setpoint that can be set via the keypad, with a range from minimum to maximum setpoint.
- the differential

The diagram below indicates the compressor activation mode for cooling based on parameters **SEt** and **diF** > 0.



## 6.5. COMPRESSOR/GENERAL PROTECTIONS

### Description

If the cold room probe is in error **E1** the output relay configured as compressor/general regulates in accordance with the times set in parameters **Ont** and **Oft**.

The first time to consider is **Ont**.

If **Ont > 0** the protection programmed in parameters **dOn-dOF-dbi** (see safety compressor times).

**NOTE:** remember that parameter **Odo** inhibits the activation of all outputs commanding a relay for its entire duration (compressor/general, defrost, fans), excluding buzzers or alarm relays.

### Operating conditions

The table below lists the ways the compressor relay output can be managed:


Ont	Oft	Compressor OUT
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	Duty-cycle

If **Ont > 0** and **Oft = 0** the compressor regulator entrusts relay deactivation to the safety protection **CA1**.

If **Ont > 0** and **Oft > 0**: the compressor regulator activates in operating cycle mode irrespective of the values read by the probes (cold room probe failure) and of requests from other loads (**Duty-cycle** mode).

If the cold room probe is working properly, Duty-cycle mode does **NOT** activate as it does not have priority over normal compressor regulator settings.

The following diagram shows the **Duty-cycle** operating mode, based on parameters **Ont** and **Oft > 0**:



### 6.5.1. Compressor safety timings

Compressor on-off operations must respect the safety times that you can set using the special parameters as described below.

The compressor icon will flash to indicate when a compressor activation request has been received but a safety protection exists.

A safety time (compressor On... Off safety time) regulated by the parameter **dOF** must be respected between a switch-off and switch-on of the same compressor. This waiting time also occurs at switch-on of the device.


A safety time regulated by the parameter **dbi** must be respected between one switch-on and the next.

The safety time set in parameter **dOn** must elapse between a compressor start-up request and actual start-up.

Times set with parameters **dOn**, **dOF** and **dbi**, if active, are not accumulative but parallel.

The following diagram illustrates the operation of the compressor protection with parameters **dOn**, **dOF**, **dbi** set where:

<b>IN</b>	Input status for compressor regulator.
<b>OUT</b>	Output status for compressor regulator.



**NOTE:** See the chapter entitled Compressor Function During Defrost for other safety measures and compressor timings.

#### Maximum timer period

The maximum compressor activation time before its deactivation can be set via the parameter **CA<sub>t</sub>**.

#### Minimum timer period

The minimum compressor activation time before its deactivation can be set via the parameter **Ci<sub>t</sub>**.

## User parameters

The parameters that manage this regulator are:

Label	Description
<b>Ont</b>	Compressor output ON time in the event of a faulty Pb1 probe
<b>OFt</b>	Compressor output OFF time in the event of a faulty Pb1 probe
<b>dOn</b>	Compressor output activation delay from request
<b>dOF</b>	Compressor output activation delay from shutdown
<b>dbi</b>	Delay between two consecutive starts of the compressor output
<b>OdO</b>	Output activation delay from power-on
<b>Cit</b>	Minimum compressor output activation time
<b>CAt</b>	Maximum compressor output activation time

## 6.6. DEFROST/DRIPPING

### 6.6.1. Defrost type and activation

Defrost is used to stop ice from forming on the surface of the evaporator. Its **activation** can be:

- automatic, in one of the following modes selected via **dCt**:
  - compressor hours (Digifrost);
  - device hours;
  - compressor stop;
  - via clock (see corresponding paragraph under RTC);
- via digital input (DI);
- via key;
- remotely.

The **type** of defrost can be selected via the parameter **dt** and can be:

1. defrost with electric heaters;
2. inverse;
3. FREE

#### Dripping

On completion of defrost, given that there will be water on the evaporator, it is better not to start “cooling” right away as this would ruin the effect of the defrost by creating ice immediately.

The dripping interval is regulated via parameter **dt**.

#### Defrost conditions and operation

Defrosting is enabled if:

- the evaporator temperature, read by probe 2, is lower than the defrost end setpoint configured via parameter **dSt**
- manual defrosting has not already been activated, in which case the request for automatic defrost will be cancelled.

Defrost requests can be made in the following ways:

Controller power-on	if parameter <b>dPO</b> (defrost at power-on) is programmed accordingly.
Time intervals	if <b>dit</b> > 0 whenever the defrost time interval set in parameter <b>dit</b> elapses.
Manually (via key)	by pressing the <b>UP</b> key The cycle will not start if <b>OdO</b> ≠0; the request will be refused and the display will flash three times to indicate that defrost is impossible.
External request via digital input (DI)	If the digital input (DI) is suitably configured. Activation via digital input (DI) respects the protections of the automatic cycle. The cycle will not start if <b>OdO</b> ≠0; the request will be refused and the display will flash three times to indicate that defrost is impossible.

HACCP models also offer the following mode:

Time	if <b>dit</b> = 0 and <b>dCt</b> =3 with rtc function (real time clock). At the times set in parameters dE1...dE8 (dd folder)
------	--

## 6.6.2. Automatic defrosting

The defrost cycle is programmed to start at intervals.

**NOTE:** To disable the automatic cycle, set **dit**=0.

If **dit**>0, the defrost cycles will be run at fixed intervals, as indicated in parameter **dit** and the interval time is counted as follows:

Par.	Value	U.M.	Description	Notes
<b>dCt</b>	<b>0</b>	num	Hours of compressor compressor (DIGIFROST method®)	In this case, the counter runs only if the compressor is on. A new count starts when the defrost interval elapses and a new defrost cycle starts if conditions permit. <b>NOTE:</b> compressor running time is counted separately from the evaporator temperature. If the evaporator probe is missing or faulty, the count continues for the time the compressor is on.
	<b>1</b>	num	Device running time	The defrosting interval is counted continuously when the device is on and starts at each power-on. A defrost cycle starts when the defrosting interval elapses (indicated by <b>dit</b> ) if conditions permit and the controller immediately starts counting a new defrosting interval.
	<b>2</b>	num	Compressor stop	Each time the compressor stops, a defrost cycle is run according to the mode set in parameter <b>dtY</b> .
	<b>3</b>	num	RTC (clock)	The clock can be used to set: <ul style="list-style-type: none"> <li>defrost times (<b>6</b> bands for weekdays and <b>6</b> bands for weekends/holidays),</li> <li>regular defrosts (every <b>n</b> days)</li> <li>daily events (<b>1</b> event for weekdays and <b>1</b> event for weekends/holidays)</li> </ul> Time band defrosts and periodic defrost are mutually exclusive functions (they cannot be activated simultaneously). If defrost by RTC has been enabled and the clock has failed, the defrost will run according to the mode set in <b>dit</b> (provided the value is <b>≠ 0</b> ).

**NOTE:** regardless of how the interval is counted, the following conditions apply:

If parameter **OdO** is underway or the temperature read by the evaporator probe is higher than **dSt**, then defrost will not be permitted: a new interval will be counted and only at the end of this subsequent count will conditions be tested for the start of a defrost cycle.

## 6.6.3. Manual defrost

Press and hold the manual defrost key **ESC** (or from digital input (DI) if appropriately configured **H11...H13 = 1**), the device enters defrost. Procedures for the activation of this defrost cycle are the same as for external defrost.

The defrosting interval will now be counted as described for Automatic Defrost (time **dEt** is not cleared, it continues).

If the conditions for defrost activation are not present, i.e.:

- the time set in parameter **OdO** has not elapsed
- the evaporator temperature is higher than the value set in parameter **dSt**

this will be indicated on the display (screen flashes three times) and the defrost will stop.

Manual defrost is always enabled except when **dit** = 0.




### 6.6.4. External defrost

If the Digital Input is configured for this function (if **H11...H13 = 1**) and if conditions permit, defrost can be requested and the corresponding regulator activated.

Time graphs for signals in each of the various function modes are presented below.

**NOTE:** Defrost activation occurs when the signal is toggled and the polarity can be selected.  
Hence you can only activate a defrost, NOT stop one that is underway.  
Defrost or dripping currently underway and the defrost or dripping interval count cannot be suspended.

<b>IN (Digital Input)</b>	Input status for defrost regulator, with activation from Digital Input.
<b>OUT (Defrost)</b>	Output status for defrost regulator.
<b>DurDI</b>	Digital Input duration.
<b>NOTE:</b>	<b>dSt</b> indicates end defrost time when Setpoint temperature reached and <b>dEt</b> indicates end of defrost due to timeout.



---

## 6.6.5. Defrost WITH REMOTE START/STOP

If the Digital Input is configured for this function (if **H11...H13 = ±22**) defrost with start/stop is activated from remote.

The defrost is switched on when the digital input becomes active. Vice versa, when the digital input is disabled, the defrost ends.

If the automatic defrost is also active, the two functions will proceed in parallel. In this case, the defrost interval set in the parameter **dit** will be reset when the remote defrost is activated (digital input).

Having ended the remote defrost, the dripping function will be activated if **dt** > 0.

The conditions for activation are:

- Defrost probe present and temperature lower than **dSt**;
- Defrost not inhibited by an alarm.

The defrost will not be activated if the following conditions are present:

1. Defrost end probe present and temperature higher than **dSt**;
2. Alarm condition inhibiting the defrost,

The defrost may end before the defrost is disabled from the digital input (DI) if:

- **dEt** ends the count;
- Defrost probe present and temperature higher than **dSt**;
- Alarm condition ending the defrost early.

To manage the activation delays of the digital inputs DI1 and DI2 separately:

- Set **dAd** = 0;
- Add a delay using parameters **O1i** (to delay the activation of digital input DI1) and **O2i** (to delay the activation of digital input DI2), the delay of the digital input DI3 can be set using parameter **di3**.

**NOTE:** If **dAd** ≠ 0, any delays set in **O1i** and **O2i** will not be considered by the instrument.

### User parameters

Label	Description
<b>dAd</b>	Delay activating digital input DI1 and digital input DI2.
<b>O1i</b>	Delay activating digital input DI1
<b>O2i</b>	Delay activating digital input DI2
<b>di3</b>	Delay activating digital input DI3

## 6.7. DEFROST MODE

### 6.7.1. Defrost with electric heaters

Defrost with electric heaters is configured via parameter **dt** = 0.

The compressor remains stopped for the duration of the defrost cycle and the relay configured as defrost regulator output, to which the electric heaters are connected, activates. On completion of defrost, the electric heaters are switched off and the compressor remains off for the dripping time set in parameter **dt**, if it is not equal to zero.


Defrost ends due to:

Evaporator Probe	End of defrost description
Evaporator Probe ABSENT	Due to timeout set in parameter <b>dEt</b> (defrost timeout)
Evaporator Probe PRESENT	Temperature setpoint for the end of defrost set in parameter <b>dSt</b> reached. If this setpoint is not reached within the time set in parameter <b>dEt</b> (defrost timeout), the defrost will end due to timeout.




#### NOTES:

- If **dSt** intervenes before **dEt**, dripping (**dt** and **Fdt**) aligns with **dSt**.
- If **Fdt** < **dt** then **Fdt** = **dt**.
- During defrost, fans are OFF if parameter **dFd** is set accordingly, otherwise they will behave as set for the fan regulator.

The operating diagram is as follows:



Key:

	Output status for <b>Compressor regulator</b>
	Output status for <b>Defrost regulator</b>
	Output status for <b>Evaporator Fan regulator</b>

## 6.7.2. Inverse defrost

Hot gas defrost is configured by setting parameter **dt** = 1.

The compressor stays on for the entire duration of the defrost cycle and the relay configured as defrost regulator output, and that the solenoid valve is connected to, activates.

On completion of the defrost cycle, the valve relay is de-energised and the dripping phase set in parameter **dt** (if not equal to zero) is interrupted. The compressor relay is once again controlled by the compressor regulator.


Defrost ends due to:

Evaporator Probe	End of defrost description
Evaporator Probe ABSENT	Due to timeout set in parameter <b>dEt</b> (defrost timeout)
Evaporator Probe PRESENT	Temperature setpoint for the end of defrost set in parameter <b>dSt</b> reached. If this setpoint is not reached within the time set in parameter <b>dEt</b> (defrost timeout), the defrost will end due to timeout.

**NOTE:** Parameters **dOn**, **dOF** and **dbi** still have priority.

- NOTES:**
- If **dSt** intervenes before **dEt**, dripping (**dt** and **Fdt**) aligns with **dSt**.
  - If **Fdt** < **dt** then **Fdt** = **dt**.
  - During defrost, fans are OFF if parameter **dFd** is set accordingly, otherwise they will behave as set for the fan regulator.

The operating diagram is as follows:



---

### 6.7.3. Double evaporator defrost

The defrost for a second evaporator can be controlled via the probe configured as second evaporator.

Configure a relay output (see configuration parameters **H21...H25**) as a defrost relay for evaporator 2.

To enable this function, you need to:

- set probe Pb3 to control defrost evaporator 2 mode (parameter **H43**).
- configure a relay output (see configuration parameters **H21...H25**) as a defrost relay for evaporator 2.
- Define defrost mode by setting parameter **H45**.

#### Input mode

A double evaporator defrost can take place in three different ways on the basis of parameter **H45**, as described below:

- **H45=0**: Defrost is enabled only when the temperature of evaporator 1 is lower than the value set in parameter **dSt**.
- **H45=1**: Defrost is enabled when the readings from at least one of the two probes is below its defrosting end temperature (**dSt** for evaporator 1 and **dS2** for evaporator 2)
- **H45=2**: Defrost is enabled when both probe values are below the corresponding end of defrost setpoints (**dSt** for evaporator 1 and **dS2** for evaporator 2)

The probe error condition is considered as a probe calling for defrost.

The defrost for every single evaporator ends when the following conditions have been met:

- the **dEt/dE2** timeout period has elapsed
- the **dSt/dS2** temperature has been reached

#### Ending mode

Defrost in the case of a double evaporator takes place when both probe values have reached or exceeded the relative end of defrost setpoints (**dSt** for evaporator 1 and **dS2** for evaporator 2)

If one or both probes are in error, the end of defrost will take place due to timeout.

#### In any case

If there are no conditions for performing the defrost the request will be cancelled.

The defrost for a single evaporator will end when the corresponding probe reaches or exceeds the defrosting end temperature or when the timeout period begins.

Dripping begins when both defrosts have ended.

If one or both probes are in error, the defrost for the corresponding evaporator will end due to timeout. Onset is allowed as if the corresponding temperature is lower than the corresponding setpoint (**dSt** or **dS2**).

If the probe is not configured to be the probe for the second evaporator (**H43** ≠ 2), the defrost for the second evaporator may take place if a digital output is configured to control defrost on the second evaporator (**H21..H25** = 9). In this case consent for defrost will be granted, as if the probe temperature (evaporator 2) < **dS2** and the output takes place due to timeout. The fan regulator is not affected.

## User parameters

The parameters that manage this regulator are:

Label	Description
<b>dt</b>	Selects defrost type
<b>dit</b>	Time interval between 2 consecutive defrost cycles
<b>dCt</b>	Selects the count mode for the defrost interval
<b>dOH</b>	Defrost cycle activation delay after request
<b>dEt</b>	Defrost timeout evaporator 1. Determines the maximum defrost duration
<b>dE2</b>	Defrost timeout evaporator 2. Determines the maximum defrost duration
<b>dSt</b>	Defrost 1 end temperature - determined by evaporator probe 1
<b>dS2</b>	Defrost 2 end temperature - determined by evaporator probe 2
<b>dPO</b>	Determines whether the instrument must enter defrost mode at power-on
<b>Fdt</b>	Fan activation delay after a defrost cycle
<b>dt</b>	Dripping time
<b>dFd</b>	Allows exclusion of the evaporator fans to be selected or not selected during defrosting.
<b>dAO</b>	Temperature alarm disabling time after defrost cycle
<b>dAt</b>	Alarm signalling end of defrost due to timeout
<b>ddL</b>	Display mode during defrost cycle (lock display.)
<b>Ldd</b>	Timeout value for display unlock - label <b>dEF</b>

## Summary table

### Defrost on evaporator 1

Defrost START		Defrost END
If <b>H45=0</b>	Probe Pb3 (evaporator 2) (evaporator 1) temperature < <b>dSt</b>	Probe Pb3 (evaporator 2) (evaporator 1) temperature > <b>dSt</b> or if Probe Pb3 (evaporator 2) (evaporator 1) temperature < <b>dSt</b> due to time-out or if probe Pb2 in error due to timeout
If <b>H45=1</b>	Probe Pb3 (evaporator 2) (evaporator 1) temperature < <b>dSt</b>	
If <b>H45=2</b>	Probe Pb3 (evaporator 2) (evaporator 1) temperature < <b>dSt</b> and Probe temperature (evaporator 2) < <b>dS2</b>	
<b>Note:</b> if the probe is in error or <b>H43</b> ≠2 and a digital output is configured as a regulator for the second evaporator, the following condition applies: Probe temperature (evaporator 2) < <b>dS2</b>		

### Defrost on evaporator 2

Defrost START		Defrost END
If <b>H45=0</b>	Probe Pb3 (evaporator 2) (evaporator 1) temperature < <b>dSt</b> and Probe temperature (evaporator 2) < <b>dS2</b>	Probe 3 temperature (evaporator 2) > <b>dS2</b> or if Probe temperature (evaporator 2) < <b>dS2</b> due to timeout or if probe in error due to timeout.
If <b>H45=1</b>	Probe temperature (evaporator 2) < <b>dS2</b>	
If <b>H45=2</b>	Probe Pb3 (evaporator 2) (evaporator 1) temperature < <b>dSt</b> and Probe temperature (evaporator 2) < <b>dS2</b>	
<b>Note:</b> if the probe is in error or <b>H43</b> ≠2 and a digital output is configured as a regulator for the second evaporator, the following condition applies: Probe temperature (evaporator 2) < <b>dS2</b>		

## Dripping

Drip cooling START	Drip cooling END
End of defrost for both evaporators if defrosting takes place for both evaporators, otherwise end of the only defrost in progress	Unchanged

## 6.8. EVAPORATOR FANS

### 6.8.1. Evaporator fan operating conditions

The regulator is active when:

- the time set in parameter **OdO** has elapsed.
- the temperature of the evaporator probe, if present, is between the values of parameters **Fot** and **FSt**
- during defrost it is not excluded by the parameter **dFd** (**dFd = y**).
- dripping is not active (**dt**).
- the fan delay is not active after defrost (**Fdt**).

The request to switch fans on or off can be made in the following ways:


- by the compressor regulator to help in the “cooling” process (temperature control mode.)
- by the defrost regulator to check and/or limit the diffusion of hot air.

	FCO	Compressor ON	Compressor OFF
Probe present and working	0	THERMOSTAT CONTROLLED	OFF
	1	THERMOSTAT CONTROLLED	THERMOSTAT CONTROLLED
	2	THERMOSTAT CONTROLLED	THERMOSTAT CONTROLLED
	3	THERMOSTAT CONTROLLED	DUTY-CYCLE*
	4	THERMOSTAT CONTROLLED	DUTY-CYCLE* **
Probe present but in error	0	DUTY-CYCLE	OFF
	1	ON	OFF
	2	DUTY-CYCLE	DUTY-CYCLE
	3	DUTY-CYCLE	DUTY-CYCLE
	4	DUTY-CYCLE	DUTY-CYCLE
Probe absent	0	ON	OFF
	1	ON	ON
	2	DUTY-CYCLE*	DUTY-CYCLE*
	3	ON	DUTY-CYCLE*
	4	ON	DUTY-CYCLE* **

\* see paragraph “Fan operation with probe Pb2 absent” (H42 ≠ 0).

\*\* Normal Duty-Cycle operation reversed (OFF cycle - ON cycle)

The graphs below illustrate fan operation on the basis of the **FCO** value.  
In the graphs, we can see that:



### 6.8.2. Fan operation in temperature control mode

During “cooling”, the fans operate as shown in this diagram:

Thermostat control of fans takes place at the values set in parameters

- **FSt** (fan disabling temperature) and **FAd** (fan differential).
- **Fot** (fan start temperature) and **FAd** but with the sign inverted.

By default, the fan disabling temperature, set by parameters **FSt** (fan disabling temperature) and **FAd** (fan differential), is an absolute value, as **FPt = 0** (actual temperature value).

Depending on the parameter **FPt**, the fan disabling temperature set at parameter **FSt** can be absolute (actual temperature value) or relative (value to add to the Setpoint SET).


Depending on the parameter **FPt**, the fan start temperature set at parameter **Fot** can be absolute (actual temperature value) or relative (value to add to the Setpoint SET).

**NOTE:** if as an absolute value the parameter **Fot** is greater than **FSt** the fans will be excluded

Around the fan start temperature (-50°C by default) the differential will always take account of the differential parameter **FAd** but with the sign inverted (negative side). Fan stop in **Fot**, and activation at value (**Fot + FAd**).

The fan regulator operates as indicated below:






### 6.8.3. Fan operation in Duty-Cycle mode

For Duty-cycle operation, parameters **Fon** and **FoF** must be set accordingly;

The fans operate as follows:

DUTY-CYCLE		
Fon	FoF	Fan operation
0	0	OFF
0	≠0	OFF
≠0	0	ON
≠0	≠0	DUTY-CYCLE

The fan regulator will operate in Duty-cycle mode as illustrated below:



### 6.8.4. Fan operation in defrost

During defrost, the fans operate as shown in this diagram

<b>dFd = n:</b> the fans are not excluded during defrost (see parameters <b>FCO</b> , <b>Fon</b> , <b>FoF</b> )	TEMPERATURE CONTROL / DUTY-CYCLE
<b>dFd = y:</b> exclusion of fans during defrost	OFF

Thermostat control of fans takes place at the values set in parameters:

- **FSt** (fan disabling temperature) and **FAd** (fan differential).

**NOTE:** during defrost with electric heaters, the compressor is OFF but the fans work as if the compressor was still ON, unless they have been disabled during defrost (see parameter **dFd**).


When the evaporator fans are enabled in defrost (**dFd = n**) and regulate the evaporator probe Pb2 in thermostat controlled mode, when the latter enters error "E2" during defrost, the fans must always be ON, regardless of the values set via the Duty-cycle.

### Fan operation without probe

If parameter **H42 = n** (probe Pb2 absent), depending on the **FCO** value and the status of the compressor, the fans may assume the status "On", "Off", "Duty-cycle".

The parameter **FCO** will determine the operating mode of the evaporator fans during the DAY phase and the NIGHT phase.

The following is an example of fan operation on the basis of the value set for **FCO**.



---

### 6.8.5. Fan function during dripping

If parameter **dt** ≠ 0 (dripping time), the fans will stay OFF for the time set in this parameter.

See “**Defrost with electric heaters**”.

Note that if **Fdt** (fan delay time) is greater than **dt** (dripping time) the fans stay OFF for the time set in **Fdt** rather than **dt** (e.g. whichever timing is longer will be applied).

### 6.8.6. Post-ventilation

Parameter **FdC** delays the switching off of the fans after the compressor has stopped (increasing efficiency of the system by making better use of inertia). Post-ventilation must be active with any FCO value and without a configured probe.

If **FdC** = 0 the function is disabled.

**NOTE:** Post-ventilation does not have priority over the delay set by parameter **dcd**.

#### User parameters

The parameters that manage the fan regulator are:

Label	Description
<b>FPt</b>	Characterises parameter “FSt” which can be expressed either as an absolute value or relative to the setpoint
<b>FSt</b>	Evaporator fan disabling temperature
<b>Fdt</b>	Evaporator fans delay after defrost cycle
<b>dFd</b>	Evaporator fans disabling during defrost time
<b>FCO</b>	Evaporator fans operating mode
<b>FAd</b>	Evaporator fans activation differential
<b>dt</b>	Dripping time
<b>FdC</b>	Evaporator fans switch-off delay after compressor deactivation
<b>Fon</b>	Evaporator fans ON time in duty-cycle mode
<b>FoF</b>	Evaporator fans OFF time in duty-cycle mode

## 6.9. DEEP COOLING CYCLE - DCC

### Description

This regulator ensures that the compressor regulates the setpoint **dCS**, with differential equal to the value set via parameter **diF**. When the **DCC** (Deep Cooling Cycle) activates, the interval between defrost cycles is cleared and defrosts are disabled. Ending of the **DCC** is time-based, by setting the parameter **tdc**≠0, or when the setpoint **dCS** if **tdc = 0**.

When a **DCC** has ended and once the time set in parameter **dcc** has elapsed, a defrost cycle is forced and the counters restart for the interval between defrost cycles (value set via parameter **dit**). If **dcc=0** defrost begins at the end of the **DCC**. During the **DCC** the temperature alarms are disabled. Normal temperature alarm management is restored at the end of the **DCC**, when the temperature value read by probe **Pb1** reaches the regulation setpoint value **SEt**.


### Operating conditions

The Deep Cooling Cycle will be activated via Digital Input or via a suitably configured key.

In the event of a probe error and/or power failure, the Deep Cooling Cycle is stopped and standard controller function restored.

If the **dCS** parameters are changed, **tdc** and **dcc** the functioning of the Deep Cooling Cycle is recalculated with new set values.

**NOTE:** After a Deep Cooling Cycle, the **dcc** time must elapse before a new cycle can begin.



### User parameters

The parameters that manage the fan regulator are:

Label	Description
<b>dCS</b>	Deep Cooling set point
<b>tdc</b>	Deep Cooling Time
<b>dcc</b>	Delay Defrost after Deep Cooling

## 6.10. PREHEAT

The preheating phase is linked to a suitably configured digital input (**H11... H13 = ±12**).

In the period when the preheat output is active:

- the compressor output will be forced OFF;
- the compressor icon will flash.

The Preheat only affects defrosting in applications that require the use of the compressor (**dtY= 1** and **dtY= 2**).

## 6.11. PRESSURE SWITCH

This regulator performs diagnostic procedures on an activated digital input by assigning the value  $\pm 11$  (General pressure switch),  $\pm 09$  (Minimum pressure switch) or  $\pm 10$  (Maximum pressure switch) to one of the parameters **H11...H13**.

If a pressure switch input is activated, power to the compressor loads is immediately cut off, the corresponding alarm icon lights up to provide a visual warning and the alarms folder **ALr** is also displayed. The folder contains labels with the number of pressure switch activations (up to the maximum value set in parameter **PEn**):

- **P01, P02, ...P0n...** for general pressure switch
- **H01, H02, ...H0n...** for maximum pressure switch
- **L01, L02, ...L0n...** for minimum pressure switch

If the number of activations exceeds the maximum number defined by parameter **PEn** within a time less than the value of **PEi**, the following conditions occur:

- The compressor, fan and defrost outputs are disabled
- in the alarms folder **ALr** label **PA, LPA** or **HPA** are displayed (general, minimum or maximum pressure switch respectively).
- The alarm relay comes on (if configured).

**NOTE:** 1) if the number of activations exceeds the number set in **PEn** in the **PEi** time, the alarm is automatically reset.  
2) the input must be:

- closed on itself if unused and the input is active when normally closed;
- open if unused and active when normally open;
- deactivated via digital input configuration parameter.

**NOTES:** 1) Once it has entered alarm status, the device must be switched off and on again, or reset using the **rPA** key in the functions menu.  
2) If parameter **PEn = 0**, the function is disabled and alarms and counters are also disabled.  
3) The pressure switch alarm is not stored in EEPROM  
4) During the pressure switch activation period the defrost interval count runs as normal.

### Operating conditions

The number of pressure switch errors is counted using a FIFO method. The time interval **PEi** is divided into 32 parts; the counter is incremented by one unit if there are one or more activations during one part of the entire interval **PEi**.

Two operating examples are given below: In both cases, suppose that **PEi = 32'** (equal to  $32'/32 = 1$  minute) and **PEn = 7**.

#### Example 1: ALARM SIGNALLED.

The interval for storing activations is 1 minute: all activations within that minute are counted as a single activation and the alarm is activated when the sampling interval has elapsed. In this example the pressure switch alarm is signalled because there have been 7 activations during the 32' time window.

#### Example 2: ALARM NOT SIGNALLED

In this example the alarm is not activated because during the 32' time window the number of activations set in parameter **PEn** was not reached. In practice the time window is a rolling window and all activations that are outside of it are deleted: the reference point is the last activation and the time **PEi** is subtracted from that point to establish how many activations are included in the count.



The parameters that manage the pressure switch regulator are:

Label	Description
<b>PEn</b>	Number of errors allowed per general/maximum/minimum pressure switch input
<b>PEi</b>	General/minimum/maximum pressure switch error count interval (in 32 parts)

## 6.11.1. AUXILIARY OUTPUT (AUX/LIGHT)

### Description

If one of the parameters **H21...H25** is set to the value **H2x=5**, it anticipates the relay control as AUX and, by pressing the associated key **H32...H35** which must be set to the value **H3x=2**, the relay is activated if it was off previously and vice-versa.

The on/off status is saved in non-volatile memory hence when power returns after a blackout, the device will restart in the status that was active prior to the blackout.

If one of the parameters **H11...H13** is set to the value **H11...H13=±3**, it anticipates the AUX relay control by the digital input; in this case the relay will mirror the status of the input. In this case, on/off status is not saved in non-volatile memory.

**NOTE:** the meaning of the digital input (DI) must always remain the same: for example, if the relay is activated by digital input (DI) and switched off by key, when the digital input (DI) is reset to the starting position, the relay does not change status (since it was already de-energised by key).

With the instrument OFF, if set accordingly, only the digital input (DI) and the associated key can change the status of the output.

### Operating conditions


The regulator is activated by:

- Key
- Function
- Digital Input

if configured accordingly.

The regulator is not active when:

Condition	AUX output status
during start-up	OFF
during stand-by	status depending on parameters H06 and H08



### User parameters

The parameters that manage the auxiliary (AUX) output regulator are:

Label	Description
<b>H11...H13</b>	Configuration of digital input 1...3 / Polarity
<b>H21...H25</b>	Configuration of digital output 1...5
<b>H32...H35</b>	Configuration of DOWN, ESC, ON/OFF, LIGHT key

## 6.12. DOOR/EXTERNAL ALARM MANAGEMENT

The door switch input is associated to an appropriately configured digital input (**H1x = ±4**).

By controlling the opening of the door, it is possible to disable the compressor output and/or the fans.

It is also possible to associate a deactivation delay with the compressor output by means of parameter **dCO**.

If the door is opened during a defrost cycle, the cycle is not shut down.

The values that can be set for the parameters involved are:

**dod**: Door switch switches off loads on digital input (DI) command

- **0** = function disabled
- **1** = disables fans (FAN)
- **2** = disables the compressor (COMP)
- **3** = disables the compressor (COMP) and fans (FAN)

Any protective timers (e.g. compressor start delay, etc.) will still be observed.

**rLO**: Locks compressor, defrost and fan regulators if the digital input (configured as external alarm) is activated.

- **0** = no resource locked
- **1** = Compressor and Defrost locked
- **2** = compressor, defrost and fans locked

**dOA**: Establishes what should be enabled/disabled on enabling/disabling of the Digital input. Only applies if **PEA** ≠ 0.

- **0** = activates the compressor (COMP)
- **1** = activates fans (FAN)
- **2** = activates the compressor (COMP) and fans (FAN)
- **3** = deactivates the compressor (COMP)
- **4** = deactivates fans (FAN)
- **5** = deactivates the compressor (COMP) and fans (FAN)

**PEA**: Establishes which of the door switch and alarm should be linked to the parameter **dOA** in the following way:

- **0** = function deactivated
- **1** = function linked to door switch
- **2** = function linked to external alarm
- **3** = function linked to door switch and external alarm




**dCO**: Compressor resource activation/power off delay (0 ...255 min).

**dFO**: Evaporator fan resource activation/power off delay (0 ...255 min).


**tdO**: Door open alarm exclusion time (0...255 min). The door open alarm will be activated if the door remains open for a time period greater than the setting for this parameter.

The way in which parameters **dCO** and **dFO** act depends on how parameter **dOA** is configured. To better understand the meaning of these parameters, refer to the figures below.


The graphs below illustrate fan operation on the basis of the **dOA** value. In the graphs, we can see that:

	Door
	Evaporator fans
	Compressor


dOA = 0




dOA = 1




dOA = 2




dOA = 3



dOA = 4



dOA = 5





## 6.13. DEMISTING HEATERS (FRAME HEATERS)

The controller is equipped with a regulator for the demisting heaters.

### Operating conditions

The table below lists the ways the relay output can be managed:


HOn	HOF	FRAME HEATER OUT
0	0	OFF
0	>0	OFF
>0	0	ON
>0	>0	Duty-cycle

Where **HOn** = 0 the regulator is always off, while if **HOn** > 0 and **HOF** = 0 the regulator is always on.

If **HOn** > 0 and **HOF** > 0: the regulator activates in operating cycle mode irrespective of the values read by the probes (cold room probe failure) and of requests from other loads (**Duty-cycle** mode).

If the cold room probe is working properly, the Duty-cycle mode does **NOT** activate as it does not have priority over normal regulator settings.

The following diagram shows the **Duty-cycle** operating mode based on the parameters **HOn** and **HOF** > 0:



### User parameters

The parameters that manage the frame heater regulator are:


Label	Description
<b>HOn</b>	Frame Heater regulator output ON time
<b>HOF</b>	Frame Heater regulator output OFF time
<b>dt3</b>	Frame Heater regulator time standard unit of measurement: <b>0</b> = hours; <b>1</b> = minutes; <b>2</b> = seconds

## 6.14. CONDENSER FANS

This regulator is associated with probe Pb3 (see specific section) and features:

- intervention setpoint **SCF**
- operating differential **dCF**
- exclusion of fans during defrost **dCd**
- activation delay after end of defrost **tCF**

If a digital output is set as condenser fans (**H21...H25=12**), this output will behave as follows:



If probe Pb3 is not present and if alarm E3 is active, the regulator will always be active except during the defrost cycle. Probe 3 can be excluded and, in this case, its lack of connection to the instrument will not cause any error signalling to occur.

**NOTE:** During the dripping time the output is OFF.

**NOTE:** If a digital output is programmed as “condenser fans” (**H21...H25=12**), parameter **SA3** is always an absolute value, regardless of the value assumed by the parameter Att.

### User parameters

The parameters that manage the condenser fan regulator are:

Label	Description
<b>SCF</b>	Condenser fans activation Setpoint
<b>dCF</b>	Condenser fans activation differential
<b>tCF</b>	Condenser fans switch-on delay after defrost
<b>dCd</b>	Exclusion of condenser fans during defrost
<b>dt</b>	Dripping time.

---

## 6.15. STAND-BY

### Operating conditions

The stand-by regulator can be activated by digital input (if configured) or by key (if programmed).

**With the device OFF the display shows “OFF” and all regulators are blocked including alarms.**

When the device is switched on via a key or an appropriately configured digital input, regular operation commences, the same as from power-on. After power-on, the temperature alarm is excluded for a time set in parameter **PAO**, and the delay set by parameter **OdO** is activated.

Each time that the device is switched off, all cycle times are reset.

The on/off status is saved in non-volatile memory hence when power returns after a blackout, the device will restart in the status that was active prior to the blackout.

The output from stand-by is linked to the delay set in parameter **OdO**.

**NOTE:** With the controller off, all relays are de-energized except for Aux: button/aux input-light-door switch are active.

### User parameters

The parameters that manage the stand-by regulator are:

Label	Description
<b>PAO</b>	Alarm disabling after power-on
<b>OdO</b>	Output activation delay from power-on
<b>OA0</b>	High/low temperature alarm exclusion time after door closing

## 6.16. PUMP DOWN

In some applications, Coldface manages the fluid solenoid valve, located in the cold room, while the refrigeration output is generated by a condenser unit, where the compressor is switched on/off directly by a minimum pressure switch on the unit itself.

Pump-down mode can be used to manage the compressor directly by connecting the minimum pressure switch to the Coldface, which means it can also be used for diagnostics.

The purpose of this regulator is to allow compressor activation (pump-down compressor output) exclusively on the basis of minimum pressure switch regulation and regardless of the status of the main temperature controller, which will be used to enable/disable solenoid valves (compressor output) instead.

### 6.16.1. Service stoppage

Service stoppage switches the cold room OFF, and this status is indicated on the display. It also allows compressor activation every time the pressure on the suction line rises until the minimum pressure switch starts running (pump-down).

## 7. PARAMETERS

---

### 7.1. HOW TO MODIFY THE USER PARAMETERS

The 'User' parameters are the most useful ones. This document describes them in the Parameter Table section.

- 1) Press and hold the SET button for at least 3 seconds, until the display shows USr
- 2) Press and release the SET key. The top display will show the first parameter, the bottom display will indicate the current parameter value
- 3) Using the UP & DOWN keys, find the parameter that you wish to modify
- 4) Press and release the SET key again. The top display will show the name of the blinking parameter
- 5) Use the UP & DOWN keys to adjust the parameter value
- 6) Press and release SET to save the parameter value
- 7) Return to step 3) or press ESC several times to return to the normal display.

**IT IS POSSIBLE TO EDIT OTHER INSTALLER PARAMETERS (inS) ON THE INSTRUMENT**

### 7.2. HOW TO EDIT THE INSTALLER PARAMETERS

- 1) Press and hold the SET key for 3 seconds until the display shows USr
  - 2) Use the UP & DOWN keys to select the **inS** parameter section
  - 3) Press and release the SET key again. The display will show the first folder
  - 4) Press and release the SET key again. The top display will show the first parameter in the folder, the bottom display will indicate the current parameter value
  - 5) Use the UP & DOWN keys to find the parameter that you want to change
- The procedure progresses in a similar manner to that described for the User parameters (steps 4-7).

## 7.3. PARAMETER TABLE

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
SEt	USr/inS	Temperature control SEtpoint	°C/°F	-58.0...302	0.0
<b>COMPRESSOR parameters (CPr)</b>					
diF	USr/inS	Activation differential N.B.: diF cannot be equal to 0.	°C/°F	0...30.0	2.0
HSE	USr/inS	Maximum value that can be assigned to the setpoint. NOTE: The two setpoints are interdependent: HSE cannot be less than LSE and vice versa.	°C/°F	LSE...HdL	50.0
LSE	USr/inS	Minimum value that can be assigned to the setpoint. NOTE: The two setpoints are interdependent: HSE cannot be greater than LSE HSE and vice versa.	°C/°F	LdL...HSE	-50.0
OSP	USr/inS	Temperature value to be added algebraically to the setpoint if reduced set enabled (Economy function). Enabling can take place via key, function or digital input configured specifically for this purpose.	°C/°F	-30.0...30.0	0.0
Cit	USr/inS	Minimum activation time of compressor before possible deactivation. If Cit = 0 it is not active.	min	0...255	0
CAt	USr/inS	Maximum activation time of compressor before possible deactivation. If CAt = 0 it is not active.	min	0...255	0
Ont	USr/inS	Controller switch-on time in the event of probe error. - if Ont = 1 and OFt = 0, the compressor stays on permanently (ON), - if Ont > 0 and OFt > 0, it operates in duty-cycle mode.	min	0...255	10
OFt	USr/inS	Controller switch-off time in the event of probe error. - if OFt = 1 and Ont = 0, the compressor stays OFF permanently, - if Ont > 0 and OFt > 0, it operates in duty-cycle mode	min	0...255	10
dOn	USr/inS	Delayed start. The parameter indicates that a protection is active on the general compressor relay actuations. At least the indicated time must elapse between the request and the actual activation of the compressor relay.	s	0...255	2
dOF	USr/inS	Delay time after power-off: the delay time indicated must elapse between deactivation of the compressor relay and the next power-on.	min	0...255	0
dbi	USr/inS	Delay between switch-ons; the delay time indicated must elapse between two consecutive compressor power-ons.	min	0...255	2
OdO	USr/inS	Delay in activating outputs after the instrument is switched on or after a power failure. 0 = not active	min	0...255	0
dSC	inS	Compressor 2 activation delay. Indicates the time after which the relay configured as compressor 2 will be activated in relation to the first compressor. If compressor 1 is disabled during this time, the call for compressor 2 will be cancelled.	s	0...255	0
dCS	inS	DEEP COOLING CYCLE Deep cooling cycle setpoint	°C/°F	-58.0...302.0	0
tdc	inS	Deep cooling cycle duration	min	0...600	10
dcc	inS	Delay defrost after deep cooling cycle	min	0...255	0
<b>DEFROST parameters (dEF)</b>					
dty	USr/inS	Defrost mode 0 = electric defrost (defrost cycle OFF), or compressor not running during defrost. NOTE: electric defrost + air defrost, in the case of fans connected in parallel to the defrost output relay 1 = cycle inversion defrost (hot gas, or compressor on during defrost;) 2 = "free" mode defrost (independent of compressor)	num	0...2	0
dit	USr/inS	Interval between defrost cycles Time interval between the start of two consecutive defrost cycles. 0 = function disabled (defrost is NEVER activated). See dt1 for UM.	hrs/min/s	0...255	6 hours
dt1	inS	Unit of measure for defrost intervals (parameter dit). 0 = parameter dit in hours 1 = parameter dit in minutes 2 = parameter dit in seconds	num	0...2	0
dt2	inS	Unit of measure for duration of defrost (parameter dEt/dE2). 0 = parameter dEt/dE2 in hours 1 = parameter dEt/dE2 in minutes 2 = parameter dEt/dE2 in seconds.	num	0...2	1

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
dCt	USr/inS	Defrost interval count mode 0 = compressor running time (DIGIFROST® method); defrost active ONLY when compressor is on. N.B.: compressor running time is counted separately from the evaporator probe (count active even if the evaporator probe absent or error). 1 = device running hours; defrost count is always active when machine is on and starts at each power-up. 2 = compressor stop. Every time the compressor stops, a defrost cycle is run depending on parameter dtj; 3 = RTC. Defrost at specific times set by parameters dE1...dE8, F1...F8	num	0...3	1
dOH	USr/inS	Defrost cycle enabling delay from request Delay preceding start of first defrost after call.	min	0...59	0
dEt	USr/inS	Defrost timeout Determines the maximum defrost time on Evaporator 1. See dt2 for UM.	hrs/min/s	1...255	30
dSt	USr/inS	Defrost end temperature Defrost 1 end temperature (determined by evaporator probe 1).	°C/°F	-58.0...302.0	6.0
dS2	inS	Evaporator 2 defrost end temperature Determines the maximum defrost time on Evaporator 2	°C/°F	-58.0...302.0	8.0
dE2	inS	Evaporator 2 maximum defrost duration Determines the maximum defrost time on Evaporator 2. See dt2 for UM.	hrs/min/s	1...255	30
dPO	USr/inS	Defrost enabling request from power-on Determines whether the instrument must enter defrost mode at power-on (provided that the temperature measured at the evaporator will allow defrost). n = no, does not start defrosting at power-on; y = yes, starts defrost at power-on	flag	n/y	n
tcd	inS	Compressor output activation/deactivation time before a defrost Minimum time that must elapse with the compressor ON or OFF before defrost is activated.	min	-31...31	0
Cod	inS	Time preceding a defrost, during which the compressor output is not activated	min	0...60	0
<b>Parameters dE1..dE8 / F1..F8 – ONLY VISIBLE IN HACCP MODELS</b>					
<b>NOTE: do not confuse parameters dE1...dE8 with values d0 ...d7 in folder nAd, used for the Day/Night regulator.</b>					
dE1..dE8 F1..F8		Parameters for setting the time of single defrosts • daily (dE1...dE8) • daily “weekends/public holidays” (F1..F8), used by the Day/Night regulator. The parameters will only be displayed if: • dit = 0 • dCt = 3 (Real time clock) • H48 = y (rtc option declared present) • the device has been switched off and on again after the above parameters have been set.			
dE1...dE8		Setting the time for defrosts on weekdays If parameter dit (defrosting interval) = 0, dCt = 3 and the rTc option is (declared) present, then parameters dE1...dE8 allow you to set the hours and minutes. Only on the basis of these values will a defrost cycle begin. If you do not wish to use some of the defrost times (dE1...dE8), exclude them as explained below: Select the parameter (dE1...dE8) that you want to exclude, then increase the value until 24 appears on the display, indicating that the parameter has been excluded. Bear in mind that the times do not have to be set in exact chronological order, e.g.: dE1 = h 12.25 dE2 = h 06.05 dE3 = h 18.30 ...	hours/ mins	The parameter is then split into dEn_H (hours), dEn_m (minutes), n=1...8	

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
F1...F8		Setting the time for defrosts on weekends/public holidays If parameter dit (defrosting interval) is dit = 0, dCt = 3 and the RTC option is declared present, then parameters F1...F8 allow you to set the hours and minutes. Only on the basis of these values will a defrost cycle begin. If you do not wish to use some of the defrost times (F1...F8), exclude them as explained below: Select the parameter (F1...F8) that you want to exclude, then increase the value until 59 appears on the display, indicating that the parameter has been excluded. Bear in mind that the times do not have to be set in exact chronological order, e.g.: • F1 = h 12.25 • F2 = h 06.05 • F3 = h 18.30	hours/ mins	The parameter is then split into Fn_H (hours), Fn_m (minutes), n=1...8	
dE1H	USr/inS	Start time weekday defrost 1. 0...23 = start hour; 24 = disabled.	hours	0...24	0
dE1m	USr/inS	Start time minutes weekday defrost 1.	min	0...59	0
dE2H	USr/inS	2nd workday defrost start hour. d1H...23 = start hour; 24 = disabled.	hours	0...24	0
dE2m	USr/inS	2nd workday defrost start minutes.	min	0...59	0
dE3H	USr/inS	3rd workday defrost start hour. d2H...23 = start hour; 24 = disabled.	hours	0...24	0
dE3m	USr/inS	3rd workday defrost start minutes.	min	0...59	0
dE4H	USr/inS	4th workday defrost start hour. d3H...23 = start hour; 24 = disabled.	hours	0...24	0
dE4m	USr/inS	4th workday defrost start minutes.	min	0...59	0
dE5H	USr/inS	5th workday defrost start hour. d4H...23 = start hour; 24 = disabled.	hours	0...24	0
dE5m	USr/inS	5th workday defrost start minutes.	min	0...59	0
dE6H	USr/inS	6th workday defrost start hour. d5H...23 = start hour; 24 = disabled.	hours	0...24	0
dE6m	USr/inS	6th workday defrost start minutes.	min	0...59	0
dE7H	USr/inS	7th workday defrost start hour. d4H...23 = start hour; 24 = disabled.	hours	0...24	0
dE7m	USr/inS	7th workday defrost start minutes.	min	0...59	0
dE8H	USr/inS	8th workday defrost start hours. d5H...23 = start hour; 24 = disabled.	hours	0...24	0
dE8m	USr/inS	8th workday defrost start minutes.	min	0...59	0
F1H	USr/inS	1st weekend/public holiday defrost start hour. 0...23 = start hour; 24 = disabled.	hours	0...24	0
F1m	USr/inS	1st weekend/public holiday defrost start minutes.	min	0...59	0
F2H	USr/inS	2nd weekend/public holiday defrost start hour. F1H...23 = start hour; 24 = disabled.	hours	0...24	0
F2m	USr/inS	2nd weekend/public holiday defrost start minutes.	min	0...59	0
F3H	USr/inS	3rd weekend/public holiday defrost start hour. F2H...23 = start hour; 24 = disabled.	hours	0...24	0
F3m	USr/inS	3rd weekend/public holiday defrost start minutes.	min	0...59	0
F4H	USr/inS	4th weekend/public holiday defrost start hour. F3H...23 = start hour; 24 = disabled.	hours	0...24	0
F4m	USr/inS	4th weekend/public holiday defrost start minutes.	min	0...59	0
F5H	USr/inS	5th weekend/public holiday defrost start hour. F4H...23 = start hour; 24 = disabled.	hours	0...24	0
F5m	USr/inS	5th weekend/public holiday defrost start minutes.	min	0...59	0
F6H	USr/inS	6th weekend/public holiday defrost start hour. F5H...23 = start hour; 24 = disabled.	hours	0...24	0
F6m	USr/inS	6th weekend/public holiday defrost start minutes.	min	0...59	0
F7H	USr/inS	7th weekend/public holiday defrost start hour. F5H...23 = start hour; 24 = disabled.	hours	0...24	0
F7m	USr/inS	7th weekend/public holiday defrost start minutes.	min	0...59	0
F8H	USr/inS	8th weekend/public holiday defrost start hour. F5H...23 = start hour; 24 = disabled.	hours	0...24	0
F8m	USr/inS	8th weekend/public holiday defrost start minutes.	min	0...59	0
FAN parameters (FAn)					
FPt	inS	FSt parameter management mode. 0 = absolute value; 1 = relative value	flag	0/1	0
FSt	USr/inS	Fans lockout temperature; if the value read is greater than FSt, the fans will be stopped. The value may be positive or negative	°C/°F	-58.0...302	6.0
Fot	inS	Fan start temperature. If the temperature read by the evaporator probe is lower than the set value, the fans remain off.	°C/°F	-58.0...302	-50.0
FAd	USr/inS	Fans activation differential	°C/°F	0.1...25.0	1.0
Fdt	USr/inS	Fans activation delay after a defrost cycle	min	0...255	0
dt	USr/inS	dripping time. Dripping time.	min	0...255	0
dFd	USr/inS	Operating mode of evaporator fans during defrost. n (0) = no (depending on the FCO parameter); y (1) = yes (fan off).	flag	n/y	y

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT																								
FCO	USr/inS	Evaporator fans operating mode. The status of the fans will be:	num	0..4	1																								
		<table border="1"> <thead> <tr> <th>FCO</th> <th>COMPRESSOR ON</th> <th>COMPRESSOR OFF</th> <th>Notes</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Thermostat controlled</td> <td>OFF</td> <td>-</td> </tr> <tr> <td>1</td> <td>Thermostat controlled</td> <td>Thermostat controlled</td> <td>-</td> </tr> <tr> <td>2</td> <td>Thermostat controlled</td> <td>Thermostat controlled</td> <td>-</td> </tr> <tr> <td>3</td> <td>Thermostat controlled</td> <td>duty-cycle</td> <td>controlled via parameters FOn and FOF</td> </tr> <tr> <td>4</td> <td>Thermostat controlled</td> <td>duty-cycle</td> <td>controlled via parameters FOn and FOF</td> </tr> </tbody> </table>				FCO	COMPRESSOR ON	COMPRESSOR OFF	Notes	0	Thermostat controlled	OFF	-	1	Thermostat controlled	Thermostat controlled	-	2	Thermostat controlled	Thermostat controlled	-	3	Thermostat controlled	duty-cycle	controlled via parameters FOn and FOF	4	Thermostat controlled	duty-cycle	controlled via parameters FOn and FOF
		FCO				COMPRESSOR ON	COMPRESSOR OFF	Notes																					
		0				Thermostat controlled	OFF	-																					
		1				Thermostat controlled	Thermostat controlled	-																					
		2				Thermostat controlled	Thermostat controlled	-																					
3	Thermostat controlled	duty-cycle	controlled via parameters FOn and FOF																										
4	Thermostat controlled	duty-cycle	controlled via parameters FOn and FOF																										
FdC	inS	Evaporator fans switch-off delay after compressor deactivation.	min	0...255	0																								
FOn	inS	Time fans remain ON during daytime duty-cycle. Fans used in duty-cycle mode; applies to FCO = 3,4 (duty-cycle)	min	0...255	0																								
FOF	inS	Time fans remain OFF during daytime duty-cycle. Fans used in duty-cycle mode; applies to FCO = dc	min	0...255	0																								
SCF	inS	Condenser Fans Condenser fans activation Setpoint	°C/°F	-50.0...150.0	10.0																								
dCF	inS	Condenser fans activation differential	°C/°F	-30.0...30.0	2.0																								
tCF	inS	Condenser fans switch-on delay after defrost	min	0..59	0																								
dCd	inS	Exclusion of condenser fans during defrost n (0)= fans running during defrost; y (1) = fans excluded;	flag	n/y	n																								
<b>ALARMS parameters (ALr)</b>																													
Att	inS	Parameters HAL and LAL mode intended as the absolute temperature value or differential in relation to the Setpoint. (0) = absolute value (1) = relative value  NOTE: In case of relative values (par. Att=1), the HAL parameter should be set to positive values, while the LAL parameter should be set to negative values (-LAL).	flag	0/1	0																								
AFd	USr/inS	Alarms cut-in differential.	°C/°F	0.1...25.0	1.0																								
HAL	USr/inS	Probe 1 maximum alarm. Temperature value (intended either as distance from setpoint or as an absolute value based on Att) above which the probe will trigger activation of the alarm signal.	°C/°F	LA1...302	50.0																								
LAL	USr/inS	Probe 1 minimum alarm. Temperature value (intended as distance from setpoint or as an absolute value based on Att) under which the probe will trigger activation of the alarm signal.	°C/°F	-58.0...HA1	-50.0																								
PAO	USr/inS	Alarm exclusion time after device is switched on following a power failure. This parameter refers to high/low temperature alarms LAL and HAL only	hours	0...10	3																								
dAO	USr/inS	Temperature alarm exclusion time after defrost.	min	0...255	60																								
OAo	USr/inS	Alarm indication delay (high and low temperature) following deactivation of digital input (port closed).	hours	0...10	1																								
tdO	USr/inS	Door open alarm activation delay.	min	0...255	10																								
tAO	USr/inS	Delay preceding temperature alarm signal. This parameter refers to high/low temperature alarms LAL and HAL only	min	0...255	0																								
dAt	inS	Alarm indicating end of defrost as a result of timeout. n (0) = alarm is not triggered y (1) = triggers the alarm.	flag	n/y	n																								
rLO	inS	Regulators inhibited by external alarm. 0 = does not inhibit any resource 1 = compressor and defrost blocked 2 = compressor, defrost and fans blocked	num	0/1/2	0																								
AOP	inS	Alarm output polarity: 0 = alarm active and output disabled 1 = alarm active and output enabled	flag	0...1	1																								
PbA	inS	Configuration of temperature alarm on probe 1 and/or 3: 0 = on probe 1 (cold room) 1 = on probe 3 (display) 2 = on probes 1 and 3 (cold room and display) 3 = on probes 1 and 3 (cold room and display) with external threshold	num	0...3	0																								
SA3	inS	Probe 3 alarm set point	°C/°F	-58.0...302.0	0.0																								
dA3	inS	Probe 3 alarm differential	°C/°F	-300...300	2.0																								
tA3	inS	Delay time for alarm signal on probe 3	min	0...59	0																								



PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT	
ArE	inS	Enables alarm relay in the event of probe 3-related alarms: 0 = does not enable alarms in the event of alarms/errors on probe 3 1 = enables the alarm relay in the event of alarms/errors on all probes 2 = enables the alarm relay ONLY in the event of alarms/errors on probe 3	num	0...2	0	
Art	inS	Regulator alarm type. 0 = regulation of temperature alarms disabled with door open; 1 = temperature alarms enabled with door open.	num	0...1	0	
<b>LIGHTS &amp; DIGITAL INPUTS parameters (Lit)</b>						
dSd	inS	Light relay / door switch interlock. dd2 n (0) = door opening does not switch on the light; y (1) = door opening switches on the light (if it was off).	flag	n/y	y	
dLt	inS	Delay preceding deactivation (switch-off) of light relay (interior light). The interior light remains on for dLt minutes when the door is closed if parameter dSd is set to 'yes'.	min	0...31	0	
OFL	inS	Light relay always deactivated by light key. Enables switching off with cold room light switch even if the delay after closing the door set by dLt is enabled. n (0) = no y (1) = yes.	flag	n/y	y	
dOd	inS	Enable utility switch-off on activation of door switch. 0 = disabled 1 = disable fans 2 = disable compressor 3 = disable fans and compressor	num	0...3	1	
dAd	inS	Activation delay for digital inputs DI1, DI2	min	0...255	0	
di3	inS	Activation delay for digital inputs DI3	min	0...255	0	
dOA	inS	Forced action of digital input (if PEA ≠ 0): 0 = activate compressor 1 = activate fans 2 = activate compressor and fans 3 = disable compressor 4 = disable fans 5 = disable compressor and fans	num	0...5	0	
PEA	inS	Selection of digital input configured to inhibit/enable resources. 0 = function disabled 1 = associated with door switch 2 = associated with external alarm 3 = associated with external alarm and door switch	num	0...3	0	
dCO	inS	Compressor activation/deactivation delay when enabled.	min	0...255	0	
dOC	inS	Compressor switch-off delay from acknowledgement.	min	0...255	0	
dFO	inS	Fan activation/deactivation delay when enabled.	min	0...255	0	
PEn	inS	Number of errors allowed per pressure switch input. 0= disabled.	num	0...15	15	
PEi	inS	Pressure switch error count interval.	min	1...99	99	
O1i	inS	Activation delay for digital inputs DI1. Only if dAd ≠ 0.	min	0...250	0	
O2i	inS	Activation delay for digital inputs DI2. Only if dAd ≠ 0.	min	0...250	0	
<b>NIGHT AND DAY (nAd) parameters</b>						
<b>FOLDER ONLY VISIBLE IN HACCP MODELS</b>						
<p>If the Night &amp; Day regulator is enabled (via key or DI), both weekday and weekend defrost management is active (see parameters dE1...dE8, F1...F8): parameter E3 can be used for every day to establish which defrosts to activate. If the Night &amp; Day regulator has not been enabled, only weekday defrosts dE1...dE8 will be run</p> <p>Folder consisting of 7 sub-folders: d0, d1, d2, d3, d4, d5, d6 and d7(°), each of which contain the following parameters. (°) NOTE: it is advisable to consider the first day d0 as SUNDAY. 'd7' can be used to program daily events which are valid for all days</p>						
E0		Functions enabled during events. 0 = events management disabled 1 = enable reduced setpoint 2 = enable reduced set+light 3 = enable reduced set+light+aux 4 = enable stand-by		5 = enable reduced setpoint*. 6 = enable reduced set+light*. 7 = enable reduced set+light+aux*. 8 = enable stand-by*. * disables the buzzer; the alarms and alarm relay continue to run as per the programming		

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
E1		Start of event hours/minutes. Sets event start time based on the value of E0. The "NIGHT" mode begins at this time. The duration is determined by parameter E2 In hours and minutes (in the parameter table, the parameter is split into E1_h (hours), E1_min (minutes))			
E2		Duration of event. Sets the duration of the event starting as programmed in E1, based on the value of E0 In hours			
E3		Enable defrost weekdays or weekends: 0 = "weekdays" defrost sequence defined by parameters dE1...dE8. 1 = "weekends/holidays" defrost sequence defined by parameters F1...F8. NOTE: This regulator can be enabled by key (see para. H32...H37=11) or by Digital Input (see para. ...H11...H13=16) Note: for the daily event 'd7', this parameter is ignored (it is not possible to manage defrosts)			
d0_E0	inS	Enable functions during events day 1 (SUNDAY)	num	0...8	0
d0_E1_h	inS	Event start time (hours) day 1	hours	0...23	0
d0_E1_min	inS	Event start time (minutes) day 1	min	0...59	0
d0_E2	inS	Event duration day 1	hours	0...72	0
d0_E3	inS	Enable defrost weekdays or weekends day 1	flag	0...1	0
d1_E0	inS	Enable functions during events day 2	num	0...8	0
d1_E1_h	inS	Event start time (hours) day 2	hours	0...23	0
d1_E1_min	inS	Event start time (minutes) day 2	min	0...59	0
d1_E2	inS	Event duration day 2	hours	0...72	0
d1_E3	inS	Enable defrost weekdays or weekends day 2	flag	0...1	0
d2_E0	inS	Enable functions during events day 3	num	0...8	0
d2_E1_h	inS	Event start time (hours) day 3	hours	0...23	0
d2_E1_min	inS	Event start time (minutes) day 3	min	0...59	0
d2_E2	inS	Event duration day 3	hours	0...72	0
d2_E3	inS	Enable defrost weekdays or weekends day 3	flag	0...1	0
d3_E0	inS	Enable functions during events day 4	num	0...8	0
d3_E1_h	inS	Event start time (hours) day 4	hours	0...23	0
d3_E1_min	inS	Event start time (minutes) day 4	min	0...59	0
d3_E2	inS	Event duration day 4	hours	0...72	0
d3_E03	inS	Enable defrost weekdays or weekends day 4	flag	0...1	0
d4_E0	inS	Enable functions during events day 5	num	0...8	0
d4_E1_h	inS	Event start time (hours) day 5	hours	0...23	0
d4_E1_min	inS	Event start time (minutes) day 5	min	0...59	0
d4_E2	inS	Event duration day 5	hours	0...72	0
d4_E3	inS	Enable defrost weekdays or weekends day 5	flag	0...1	0
d5_E0	inS	Enable functions during events day 6	num	0...8	0
d5_E1_h	inS	Event start time (hours) day 6	hours	0...23	0
d5_E1_min	inS	Event start time (minutes) day 6	min	0...59	0
d5_E2	inS	Event duration day 6	hours	0...72	0
d5_E3	inS	Enable defrost weekdays or weekends day 6	flag	0...1	0
d6_E0	inS	Enable functions during events day 7 (SATURDAY)	num	0...8	0
d6_E1_h	inS	Event start time (hours) day 7	hours	0...23	0
d6_E1_min	inS	Event start time (minutes) day 7	min	0...59	0
d6_E2	inS	Event duration day 7	hours	0...72	0
d6_E3	inS	Enable defrost weekdays or weekends day 7	flag	0...1	0
d7_E0	inS	Enable functions during daily event (EVERY DAY)	num	0...8	0
d7_E1_h	inS	Daily event start time (EVERY DAY)	hours	0...23	0
d7_E1_min	inS	Daily event start time (minutes) (EVERY DAY)	min	0...59	0
d7_E2	inS	Daily event duration (EVERY DAY)	hours	0...72	0
d7_E3	inS	Enable daily defrost weekdays or weekends (EVERY DAY)	flag	0...1	0
		COMMUNICATION parameters (Add)			
PtS	inS	Protocol selection. t (0) = Televis d (1) = ModBUS	flag	t d	t
dEA	inS	Device address: indicates the device address to the management protocol.	num	0...14	0
FAA	inS	Family address: indicates the device family to the management protocol.	num	0...14	0
Adr	inS	ModBUS protocol controller address (only if PtS = d).	num	1...250	1
Pty	inS	Set the ModBUS parity bit (only if PtS = d). n (0) = none E (1) = parity o (2) = disparity	num	n E o	n
StP	inS	ModBUS stop bit: 1b=1 bit; 2b=2 bit	num	1b - 2b	1b

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
bAU	inS	Baudrate selection. 96 (0) = 9600 192 (1) = 19200 384 (2) = 38400	num	96 192 384	96
<b>DISPLAY parameters (diS)</b>					
LOC	USr/inS	LOCK. Setpoint edit lock. The parameter programming menu can still be accessed, and the settings changed, which means also that the status of this parameter can be changed so as to unlock the keypad. n (0) = no y (1) = yes.	flag	n/y	n
PA1	USr/inS	PAssword 1. When enabled (PA1 ≠ 0) this password provides access to level1 parameters (User).	num	0...255	0
PA2	inS	PAssword 2. When enabled (PA2 ≠ 0), this password provides access to level2 parameters (Installer).	num	0...255	15
PA3	inS	PAssword 3. When enabled (PA3 ≠ 0), this is the access key used to clear HACCP alarms in the Functions menu.	num	0...255	0
ndt	USr/inS	Display values with decimal point. n (0) = no (integers only) y (1) = yes (display with decimal point).	flag	n/y	y
CA1	USr/inS	Calibration of probe Pb1. Positive or negative temperature value added to the value read by Pb1. This sum is used for both temperature display and temperature regulation purposes.	°C/°F	-30.0...30.0	0.0
CA2	USr/inS	Calibration of probe Pb2. Positive or negative temperature value added to the value read by Pb2. This sum is used for both temperature display and temperature regulation purposes.	°C/°F	-30.0...30.0	0.0
CA3	inS	Calibration of probe Pb3. Positive or negative temperature value added to the value read by Pb3. This sum is used for both temperature display and temperature regulation purposes.	°C/°F	-30.0...30.0	0.0
CA	inS	Offset activation on display, thermoregulation or both: 0 = only the temperature shown is modified 1 = only the temperature used by the regulators is modified; the display remains unchanged. 2 = temperature displayed is modified, which is also the one used by the regulators.	num	0/1/2	2
LdL	inS	Minimum value that can be displayed by the device.	°C/°F	-58.0...HdL	-50.0
HdL	inS	Maximum value that can be displayed by the device.	°C/°F	LdL...302	140.0
ddL	USr/inS	Display mode during defrost. 0 = displays the temperature read by probe 1 = locks the reading at the temperature value registering via the probe when the defrost cycle starts and until the next time the SET is reached 2 = displays label dEF during defrosts and until the SET is reached (or until Ldd elapses)	num	0/1/2	1
Ldd	inS	Timeout value for display unlock - label dEF.	min	0...255	0
dro	inS	Selection of °C or °F to display the probe value. 0= °C, 1= °F. NOTE: switching between °C and °F or vice-versa DOES NOT modify the setpoint, differential, etc. (e.g. setpoint = 10°C becomes 10°F).	flag	0/1	0
ddd	inS	Selects the type of value to show in the display. 0 = Setpoint 1 = probe Pb1 will be used 2 = probe Pb2 will be used 3 = probe Pb3 will be used	num	0...3	1
dd2	inS	PARAMETER ONLY VISIBLE IN HACCP MODELS Selects the type of value to show in the display 0 = Setpoint 1 = RTC	num	0/1	1
<b>HACCP ALARM parameters (HAC)</b>					
<b>FOLDER ONLY VISIBLE IN HACCP MODELS</b>					

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
Shi	inS	"Instant" maximum HACCP alarm indication threshold: when the temperature value read by the temperature control probe goes beyond the range set in "SHi", an HACCP alarm is immediately triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	SHH...150.0	35.0
Sli	inS	"Instant" minimum HACCP alarm indication threshold: when the temperature value read by the temperature control probe goes beyond the range set in "SLi", an HACCP alarm is immediately triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	-50.0...SLH	-35.0
SHH	inS	Maximum HACCP alarm indication threshold: when the temperature value displayed by the temperature control probe is outside the range set by the value of "SHH" for longer than the time set in parameter "drA", an HACCP alarm is triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	SLH...150.0	30.0
SLH	inS	Minimum HACCP alarm indication threshold: when the displayed temperature value of the temperature control probe is outside the range set by the value of "SLH" for longer than the time set in parameter "drA", an HACCP alarm is triggered, with the icon/(alarm relay) coming on according to parameter H50 (see specific section). The differential when returning from the alarm condition is fixed at 0.1°C/°F.	°C/°F	-50.0...SHH	-30.0
drA	inS	Minimum dwelling time in critical area for the event to be recorded: one this time has elapsed it is saved and an HACCP alarm generated.	min	0...99	10
drH	inS	HACCP alarm reset time from last reset: this is the time that must pass once the instrument has been switched on before any recorded alarms are cleared automatically. If the parameter is set to 0, automatic reset is inhibited and only manual reset is enabled.	hours	0...255	0
H50	inS	Enable HACCP alarms storage with or without alarm relay enabling: NOTE. SWITCH THE INSTRUMENT OFF AND ON AGAIN AFTER MODIFYING PARAMETER H50 • 0 = HACCP alarms disabled • 1 = HACCP alarms enabled and alarm relay NOT enabled • 2 = HACCP alarms enabled and alarm relay enabled	num	0...2	0
H51	inS	HACCP alarms storage disabling time (key or DI) In minutes	min	0...255	0
H52	inS	Probe enabled to signal HACCP alarms: 1=probe 1; 3=probe 3;	flag	1/3	1
CONFIGURATION parameters (CnF)					
<b>If one or more parameters present in the folder are changed, the controller <u>MUST</u> be switched off and switched on again.</b>					
H00	Usr/inS	Selection of type of probe used (Pb1...Pb3). (0) = PTC (1) = NTC	num	0/1	1
H01	inS	Enable deep cooling function n (0) = not enabled; y (1) =enabled.	flag	n/y	n
H02	inS	Activation time for keypad functions	s	0...15	3
H06	inS	Key or digital input configured as AUX/LIGHT on with device in stand-by n (0)=not active; y (1)=active;	flag	n/y	y
H08	inS	Stand-by operating mode. 0 = the display is off and the regulators on, the device signals any alarms by reactivating the display. 1 = the display is on, plus all regulators including alarms 2 = the display is off, plus all regulators are locked including alarms 3 = the top display shows the label "OFF", plus all regulators are locked including alarms	num	0/1/2/3	3

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
H11	inS	Configuration of digital input 1/polarity. NOTE: - The "+" sign indicates that the input is active when the contact is closed - The "-" sign indicates that the input is active when the contact is open	num	-22...+22	4
		<ul style="list-style-type: none"> <li>0 = disabled</li> <li>± 1 = defrost</li> <li>± 2 = Reduced set</li> <li>± 3 = Auxiliary AUX</li> <li>± 4 = Door microswitch</li> <li>± 5 = external alarm</li> <li>± 6 = Disable HACCP alarm logging</li> <li>± 7 = Stand-by</li> <li>± 8 = NOT USED</li> <li>± 9 = Minimum pressure switch</li> </ul>			
H12	inS	Configuration of 2/polarity digital input. Same as H11.	num	-22...+22	0 : 300/500 5 : 5000
H13	inS	Configuration of 3/polarity digital input. Same as H11.	num	-22...+22	0
H21	inS	Configuration of digital output 1 (OUT 1)	num	0...13	1
		<ul style="list-style-type: none"> <li>0 = disabled</li> <li>1 = Compressor (cooling)</li> <li>2 = Defrost</li> <li>3 = Fans</li> <li>4 = Alarm</li> <li>5 = AUX</li> <li>6 = Stand-by</li> <li>7 = Light</li> </ul>			
H22	inS	Configuration of digital output 2 (OUT 2). Same as H21	num	0...13	2
H23*	USr/inS	Configuration of digital output 3 (OUT 3). Same as H21	num	0...13	3
H24	inS	PARAMETER ONLY VISIBLE IN MODELS 500 and 5000 Configuration of digital output 4 (OUT 4). Same as H21	num	0...13	7
H25	inS	PARAMETER ONLY VISIBLE IN MODELS 500 and 5000 Configuration of digital output 5 (OUT 5). Same as H21	num	0...13	4
H28	inS	Enable buzzer. (0) = output disabled (8) = output enabled	num	0...13	8
H32	inS	Configuration of DOWN key	num	0...15	2
		<ul style="list-style-type: none"> <li>0 = disabled</li> <li>1 = defrost</li> <li>2 = Auxiliary</li> <li>3 = Activate reduced set</li> <li>4 = Reset HACCP alarms</li> <li>5 = Disable HACCP alarms</li> <li>6 = Light</li> <li>7 = Stand-by</li> <li>8 = NOT USED</li> <li>9 = Evaporator fans ON</li> </ul>			
H33	inS	ESC key configuration. Same as H32.	num	0...15	1
H34	inS	ON/OFF key configuration. Same as H33.	num	0...15	7
H35	inS	LIGHT key configuration. Same as H34.	num	0...15	6
H41	inS	Presence of Cold Room probe Pb1 n= not present; y= present.	flag	n/y	y
H42	USr/inS	Presence of Evaporator probe Pb2 n= not present; y= present.	flag	n/y	y
H43	inS	Presence of probe Pb3 n= not present; y= present; 2EP= second evaporator; 3-1= regulation on Pb1 or on Pb3-Pb1 differential	num	n/y/2EP/3-1	n

PAR.	LEV.	DESCRIPTION	U.M.	RANGE	DEFAULT
H44	inS	Setpoint for Pb3-Pb1 temperature differential. Sets the Pb3-Pb1 differential If H43=3-1, regulation of the temperature differential between probes Pb3 and Pb1, in addition to regulation of probe Pb1, is enabled. In this way, to activate compressor regulation, one or both of the two conditions must be met (on Pb1 or Pb3-Pb1 differential). The differential is defined by H44. To disable the compressor, both conditions must be met, so: • Output enabled if: Pb1>SET+diF, or (Pb3-Pb1) > H44+diF • Output not enabled if: Pb1<SET and (Pb3-Pb1) < H44	°C/°F	0...255	0.0
H45	inS	Start defrost mode for applications with double evaporator: 0 = Defrost is enabled by checking only that the temperature of evaporator 1 is lower than the value set in parameter dSt. 1 = Defrost is enabled, checking that the readings from at least one of the two probes is below its defrosting end temperature (dSt for evaporator 1 and dS2 for evaporator 2) 2 = Defrost is enabled, checking that both probe values are below the corresponding defrost end setpoints (dSt for evaporator 1 and dS2 for evaporator 2).	num	0/1/2	0
H48	inS	PARAMETER ONLY VISIBLE IN HACCP MODELS Clock presence. (0) = no clock (1) = clock present.	flag	n/y	y
rEL	USr/inS	Firmware version release (e.g. 1,2,...). Read only. See Technical Support.	/	/	/
tAb	USr/inS	Map code. Read only. See Technical Support.	/	/	/
H60	inS	Display of selected application. 0 = no vector selected; 1 = vector 1, ..., 6 = vector 6. It has a subset of parameters which can be programmed in line with the type of configuration required for the installation. By setting H60, the user can also select one of the six 'sets' of pre-programmed parameters. If you do not want to enable any of the available setpoints, but prefer to use the programming menu values, simply set parameter H60 to 0. The parameters corresponding to the different programs are described at the bottom of the table	num	0..6	0
FRAME HEATER parameters (FrH)					
		The Frame Heater function can be selected by key or by Digital Input This function can be associated to all relay outputs (by setting parameters H21...H25 = 11) and can be used to actuate "Duty-cycle" regulation with the intervals set by parameters HOn and HOF.			
HOn	inS	Frame Heater regulator output ON time	min	0...255	0
HOF	inS	Frame Heater regulator output OFF time	min	0...255	0
dt3	inS	Frame Heater regulator time standard unit of measurement: 0=hours; 1=minutes; 2=seconds	num	0...2	0
COPY CARD parameters (FPr)					
UL		Upload. To transfer programming parameters from instrument to UNICARD / Copy Card.	/	/	/
dL		Download. To transfer programming parameters from UNICARD / Copy Card to instrument.	/	/	/
Fr		Formatting. Deletes data on UNICARD / Copy Card. NOTE: If parameter "F" is used, the data entered will be permanently lost. This operation cannot be reversed.	/	/	/

\* H23 Installer (inS) level for the EWRC5000 model

### 7.3.1. Parameter H60

Display of selected application.

**0**=no vector selected; **1**= application 1, ..., **6**= application 6.

It has a subset of parameters which can be programmed in line with the type of configuration required for the installation. By setting **H60**, the user can also select one of the six 'sets' of pre-programmed parameters. If you do not want to enable any of the available setpoints, but prefer to use the programming menu values, simply set parameter **H60** to 0.

The parameters corresponding to the different programs are described at the bottom of the table

	parameter H60	=1	=2	=3	=4	=5	=6
<b>SEt</b>	Temperature control SEtpoint	0.0	2.0	-18.0	2.0	-18.0	5.0
<b>diF</b>	Activation differential (absolute or relative)	2.0	2.0	2.0	2.0	2.0	2.0
<b>LSE</b>	Maximum value that can be assigned to the setpoint	-50.0	-5.0	-25.0	-5.0	-25.0	2.0
<b>HSE</b>	Minimum value that can be assigned to the setpoint	50.0	5.0	-15.0	5.0	-15.0	10.0
<b>dSt</b>	Defrost end temperature	6.0	10.0	15.0	10.0	15.0	10.0
<b>FSt</b>	Fans disabling temperature	6.0	8.0	-5.0	8.0	-5.0	50.0
<b>dtY</b>	Defrost mode	0	1	1	0	0	0
<b>dit</b>	Defrost cycle enabling delay from request	6	6	6	6	6	6
<b>dCt</b>	Defrost interval count mode	1	1	1	1	1	1
<b>dOH</b>	Defrost cycle enabling delay from request	0	0	0	0	0	0
<b>dEt</b>	Defrost timeout	30	15	15	30	30	15
<b>Fdt</b>	Fans activation delay after a defrost cycle	3	1	2	1	2	0
<b>dt</b>	dripping time. Dripping time	0	2	2	2	2	0
<b>dPO</b>	Defrost enabling request from power-on	0	0	0	0	0	0
<b>ddL</b>	Display mode during defrost	1	0	0	0	0	0
<b>dFd</b>	Operating mode of evaporator fans during defrost	1	1	1	1	1	1

## 8. ALARMS

### 8.1. ALARMS AND SIGNALS TABLE

When an alarm condition is detected, the ALARM icon will come on  
If present and enabled, the buzzer and alarm relay will also activate.

To silence the buzzer, press and release any key, the relative icon will continue to flash.

All alarms are reset automatically (i.e. they disappear when the issue that caused them is removed).

The alarm codes are as follows:

Code	Description	Alarm relay	Reset	Parameters used to ENABLE ALARM
<b>E1</b>	Pb1 probe error	<b>active</b>	Automatic	Ont, OFt
<b>E2</b>	Pb2 probe error	<b>active</b>	Automatic	Ont, OFt
<b>E3</b>	Pb3 probe error	<b>active</b>	Automatic	Ont, OFt
<b>HA1</b>	HIGH temperature alarm	<b>active</b>	Automatic	SP1, Att, AFd, HAL, LAL, PAO, dAO, OAO, tAO
<b>LA1</b>	LOW temperature alarm	<b>active</b>	Automatic	SP1, Att, AFd, HAL, LAL, PAO, dAO, OAO, tAO
<b>EAL</b>	External alarm	<b>active</b>	Automatic	PEA, rLO
<b>OPd</b>	Door open alarm	not active	Automatic	PEA, tdO
<b>Ad2</b>	Defrost end due to timeout	not active	Automatic	dEt, dE2, dAt
<b>PAn</b>	Panic alarm	not active	Automatic	
<b>ALd</b>	leak detector alarm	not active	Automatic	
<b>Prr</b>	Preheat alarm	not active	Automatic	
<b>E10</b>	Clock alarm	not active	Automatic	
<b>PA</b>	General pressure switch alarm	not active	<b>Manual</b>	PEn, PEi
<b>LPA</b>	Low pressure switch alarm	not active	<b>Manual</b>	PEn, PEi
<b>HPA</b>	High pressure switch alarm	not active	<b>Manual</b>	PEn, PEi

#### NOTES:

1. If alarm exclusion times have been set (see "ALr" folder in the Parameters table) the alarm will not be indicated.
2. With the exception of faulty probe alarms, all other alarms will record the corresponding label in the ALr folder (press UP key)
3. Faulty probe alarms will be indicated on the display by means of label E1, E2, E3 depending on whether the fault relates to probe Pb1, Pb2 or Pb3 respectively
4. In the event of an overlap between the "Panic" alarm and the "Refrigerant leakage" alarm, priority is given to the "Panic Alarm" with its operating modes. Both alarm codes can in any case be viewed in the alarms folder.



## 8.2. ALARM CAUSE/EFFECT TABLE

EWRC 300/500/5000 NT can run integral diagnostics on the installation, signalling any operating faults with specific alarms found, and record and signal any user-defined unusual events to have greater control over the system as a whole.

Label	Description	Cause	Effects	Remedy
E1	Probe Pb1 in error	<ul style="list-style-type: none"> <li>Measured values are outside operating range</li> <li>probe errors/short-circuited/open</li> </ul>	<ul style="list-style-type: none"> <li>Label E1 displayed</li> <li>Alarm icon permanently alight</li> </ul>	<ul style="list-style-type: none"> <li>Check probe type (H00)</li> <li>Check probe wiring</li> <li>Replace probe</li> </ul>
E2	Probe Pb2 in error	<ul style="list-style-type: none"> <li>Measured values are outside operating range</li> <li>probe errors/short-circuited/open</li> </ul>	<ul style="list-style-type: none"> <li>Label E2 displayed</li> <li>Alarm icon permanently alight</li> </ul>	<ul style="list-style-type: none"> <li>Check probe type (H00)</li> <li>Check probe wiring</li> <li>Replace probe</li> </ul>
E3	Probe Pb3 in error	<ul style="list-style-type: none"> <li>Measured values are outside operating range</li> <li>probe errors/short-circuited/open</li> </ul>	<ul style="list-style-type: none"> <li>Label E3 displayed</li> <li>Alarm icon permanently alight</li> </ul>	<ul style="list-style-type: none"> <li>Check probe type (H00)</li> <li>Check probe wiring</li> <li>Replace probe</li> </ul>
HA1	HIGH temperature Temperature 1	value read by probe 1 > HA1 after time equal to tAO. (see "MAX/MIN TEMP. MAX/MIN)	<ul style="list-style-type: none"> <li>Label HA1 recorded in folder ALr</li> <li>No effect on regulation</li> </ul>	Wait until value read by the probe returns below HA1-AFd.
LA1	LOW temperature Temperature 1	Value read by probe 1 < LA1 after time equal to tAO. (see "MAX/MIN TEMP. MAX/MIN)	<ul style="list-style-type: none"> <li>Label LA1 recorded in folder ALr</li> <li>No effect on regulation</li> </ul>	Wait until value read by the probe returns above LA1+AFd.
HA3	HIGH temperature Temperature 3	<p>with PbA = 1 or 2 Value read by probe Pb3 &gt; HAL after time equal to tAO.</p> <p>with PbA = 3 and dA3 &gt; 0 Value of probe Pb3 &gt; SA3 plus tA3 time</p>	<ul style="list-style-type: none"> <li>Recording of label HA3 in folder ALr</li> <li>No effect on regulation</li> </ul>	<p>Wait for value read by probe to return with PbA = 1 or 2 below threshold of HAL-AFd.</p> <p>with PbA = 3 and dA3 &gt; 0 below threshold of SA3-dA3.</p>
LA3	LOW temperature Temperature 3	<p>with PbA = 1 or 2 Value read by probe Pb3 &lt; LAL after time equal to tAO.</p> <p>with PbA = 3 and dA3 &lt; 0 Value of probe Pb3 &lt; SA3 plus tA3 time</p>	<ul style="list-style-type: none"> <li>Recording of label LA3 in folder ALr</li> <li>No effect on regulation</li> </ul>	<p>Wait for value read by probe to return with PbA = 1 or 2 above threshold of LAL-AFd.</p> <p>with PbA = 3 and dA3 &lt; 0 above threshold of SA3-dA3.</p>
EAL	Alarm External	Digital input activated	<ul style="list-style-type: none"> <li>Label EAL recorded in folder ALr</li> <li>Alarm icon permanently alight</li> <li>Lockout of regulation as requested by rLO</li> </ul>	Check and remove external cause of alarm on DI
OPd	Alarm Door Open	Digital input activated (for a time greater than tdO)	<ul style="list-style-type: none"> <li>Recording of label OPd in folder ALr</li> <li>Alarm icon permanently alight</li> <li>Lockout of regulation as requested by dOd</li> </ul>	<ul style="list-style-type: none"> <li>Close the door</li> <li>Delay preceding defined alarm signal by OAO.</li> </ul>
Ad2	End Defrost due to timeout	end of defrost cycle due to timeout rather than due to defrost end temperature being read by Pb2.	<ul style="list-style-type: none"> <li>Recording of label Ad2 in folder ALr</li> <li>Alarm icon permanently alight</li> </ul>	Await next defrost cycle for automatic return to normal
Prr	Alarm Preheat	Alarm for preheat input regulator ON	<ul style="list-style-type: none"> <li>Label Prr recorded in folder ALr</li> <li>Compressor icon blinking</li> <li>Regulation inhibited (Compressor and Fans)</li> </ul> <p>NOTE: defrost will also be inhibited if it is hot gas defrost.</p>	Preheat input regulator off
E10	Alarm Clock	<ul style="list-style-type: none"> <li>Clock faulty</li> <li>Extended period without power</li> </ul>	<ul style="list-style-type: none"> <li>Recording of label E10 in folder ALr</li> <li>Functions associated with clock not managed</li> </ul>	Connect the instrument to the power supply.

Label	Description	Cause	Effects	Remedy
P01 ... P99	Alarm general pressure switch	Pressure switch alarm activation by general pressure switch regulator.	If the number n of pressure switch activations is $n < PEn$ : • Number of pressure switch activations recorded • Regulation inhibited (Compressor and Fans)	Check and remove external cause of alarm on DI (Automatic Reset).
PA	Alarm general pressure switch	Pressure switch alarm activation by general pressure switch regulator.	If the number n of pressure switch activations is $n = PEn$ : • Label PA displayed • Recording of label PA in folder ALr • Alarm icon permanently alight • Regulation inhibited (Compressor and Fans)	• Switch the device off and back on again • Reset alarms using the rPA key (Manual Reset)
L01 ... L99	Alarm low pressure switch	Activation of pressure switch alarm by minimum pressure switch regulator.	If the number n of pressure switch activations is $n < PEn$ : • Number of pressure switch activations recorded • Regulation inhibited (Compressor and Fans)	Check and remove external cause of alarm on DI (Automatic Reset).
LPA	Alarm minimum pressure switch	Activation of pressure switch alarm by minimum pressure switch regulator.	If the number n of pressure switch activations is $n = PEn$ : • Label LPA displayed • Recording of label LPA in folder ALr • Alarm icon permanently alight • Regulation inhibited (Compressor and Fans)	• Switch the device off and back on again • Reset alarms using the rPA key (Manual Reset)
H01 ... H99	Alarm high pressure switch	Activation of pressure switch alarm by maximum pressure switch regulator.	If the number n of pressure switch activations is $n < PEn$ : • Number of pressure switch activations recorded • Regulation inhibited (Compressor and Fans)	Check and remove external cause of alarm on DI (Automatic Reset).
HPA	Alarm maximum pressure switch	Activation of pressure switch alarm by maximum pressure switch regulator.	If the number n of pressure switch activations is $n = PEn$ : • Label PHPA displayed • Recording of label HPA in folder ALr • Alarm icon permanently alight • Regulation inhibited (Compressor and Fans)	• Switch the device off and back on again • Reset alarms using the rPA key (Manual Reset)
PAn	Panic alarm	Activation of appropriately configured digital input	• Recording of PAn label in ALr folder • PANIC Alarm icon steadily on • Alarm icon steadily on • Temperature control is NOT inhibited when the alarm is active	Check and remove external cause of alarm on DI (Automatic Reset).
ALd	Alarm Refrigerant Leak	Activation of appropriately configured digital input	• Recording of ALd label in ALr folder • Panic Alarm icon blinking • Alarm icon steadily on • Intermittent buzzer sounding • Temperature control is NOT inhibited when the alarm is active	Check and remove external cause of alarm on DI (Automatic Reset).
ALL ALARMS • Alarm icon permanently alight • Buzzer (if present) and alarm relay (OUT5) activated, except Ad2 • Press any key to mute the alarm. The icon changes from steady to blinking. NOTE: the buzzer is deactivated while the alarm relay remains active *E1 - E2: If simultaneous they will be shown alternately on the display at a frequency of 2 seconds			REFRIGERANT LEAK ALARM (LEAK DETECTOR) • Blinking alarm icon and Alarm icon steadily on • Intermittent sounding of buzzer (if present) and alarm relay (OUT5) • Press any key to mute the alarm. In this case the Panic icon switches from blinking to steady while the alarm icon will blink.	

---

## 8.3. DESCRIPTION OF ALARMS

### 8.3.1. PROBE alarm

#### OPERATING CONDITIONS

When one of the probes is out of the nominal operating range or in the case of an open probe or a probe in short circuit, an alarm is generated if this condition persists for longer than 10 seconds.

The alarm condition is indicated on the display by means of the following error codes:

- **E1** = Pb1 probe error
- **E2** = Pb2 probe error
- **E3** = Pb3 probe error

The alarm icon and alarm relay are activated. Codes **E1**, **E2**, **E3**, when occurring at the same time, are shown in the following sequence: E1 x 2 seconds, E2 x 2 seconds, E3 x 2 seconds, etc.

#### ACTIONS ON CURRENT REGULATION

For all probes, the probe error condition causes the following actions:

- the display shows code **E<sub>x</sub>** (where **x** = 1, 2, 3)
- activation and permanent display of alarm icon and activation of alarm relay (if present)

When the faulty probe condition ceases, regulation resumes as normal.

During the probe error, the defrost interval count continues as normal.

#### SIGNALLING

Code	Meaning
<b>E1</b>	Probe Pb1 error
<b>E2</b>	Probe Pb2 error
<b>E3</b>	Probe Pb3 error

#### ALARM ACKNOWLEDGEMENT

In the alarm condition, it is possible to acknowledge the alarm and/or relay configured as an alarm, even if the alarm condition persists, by pressing any key or using the corresponding function in the menu. The alarm icon will start to blink. Eliminating the cause of the alarm disarms the acknowledgement.

The probe alarm error is not stored by the controller.

#### USER PARAMETERS

Label	Description
<b>Ont</b>	ON time for compressor output with control probe error
<b>OfT</b>	OFF time for compressor output with control probe error

### 8.3.2. MINIMUM AND MAXIMUM TEMPERATURE alarm

#### OPERATING CONDITIONS

The alarm regulation is carried out on probe 1. The temperature limits defined in parameters **HAL** and **LAL** are determined by parameter **Att** which specifies if they represent the absolute temperature value or a setpoint differential (in the case of offset on the entered setpoint, the high and low alarms will refer to this new control set point).

- If **Att=0 Ab(solute)**, the temperature limits for probe 1/3 are absolute.
- If **Att=1 rE(lative)**, the temperature limits for probe 1/3 refer to the Setpoint **SEt**

**NOTE:** to obtain the minimum alarm below the setpoint in the case of **Att=1** (relative) set **LAL < 0**

#### ALARM CONDITIONS

A maximum/minimum alarm is generated when the Pb1 temperature is:

- Maximum alarm:  $\geq \text{HAL}$  if **Att=Ab(solute)** and  $\geq (\text{SEt} + \text{HAL})$  if **Att=rE(lative)**
- Minimum alarm:  $\leq \text{LAL}$  if **Att=Ab(solute)** and  $\leq (\text{SEt} + \text{LAL})$  if **Att=rE(lative)**



If **Att=Ab(solute)** the values of **HAL** and **LAL** must be with sign, if **Att=rE(lative)** it is necessary that **HAL > 0** and **LAL < 0**.

When one of the two aforementioned conditions occurs, if no alarm override times apply (see alarm override parameters), the alarm icon lights up and the relay configured as alarm activates (if present).

The maximum/minimum alarm will be reset when the temperature of probe 1/2 is:

- Reset from maximum alarm:  $\leq (\text{HAL} - \text{AFd})$  if **Att=Ab(solute)** and  $\leq (\text{SEt} + \text{HAL} - \text{AFd})$  if **Att=rE(lative)**
- Reset from minimum alarm:  $\geq (\text{LAL} + \text{AFd})$  if **Att=Ab(solute)** and  $\geq (\text{SEt} + \text{LAL} + \text{AFd})$  if **Att=rE(lative)**

**Att=rE(lative)**



#### NOTES:

- During a defrost cycle, high and low temperature alarms are overridden.
- Occurrence of this alarm does not effect any regulation in progress.

---

## SIGNALLING

Code	Meaning
HA1	HIGH temperature alarm, refers to probe
LA1	LOW temperature alarm, refers to probe

### ALARM ACKNOWLEDGEMENT

In the alarm condition, it is possible to acknowledge the relay configured as an alarm (if present), even if the alarm condition persists, by pressing any key or using the corresponding function in the menu. The alarm icon will start to blink.

Eliminating the cause of the alarm disarms the acknowledgement.

The probe alarm error is not stored by the controller.

### HIGH AND LOW TEMPERATURE ALARM OPERATION WITH DOOR OPEN

- If **Art = 0** (regulation of temperature alarms disabled with door open)
  1. If the door is open and there is no temperature alarm, the alarms are inhibited and cannot be activated;
  2. If the door is opened, the temperature alarm must continue;
  3. If the temperature alarm is triggered and the door is open, the temperature alarm will cease when the reset conditions return.
- If **Art = 1** ( temperature alarms enabled with door open)
  1. If the door is open, the temperature alarms are not inhibited and can be activated if the required conditions are in place. The delay **OAO**, referred to the previous closing of the door, is not counted.
  2. If a temperature alarm is triggered with the door closed, on opening the door the temperature alarm must continue.
  3. If the temperature alarm is present with the door open, the temperature alarm will cease when the reset conditions return.

### USER PARAMETERS

Label	Description
<b>Att</b>	HAL and LAL parameter mode (absolute or relative)
<b>AFd</b>	Alarm activation differential
<b>HAL</b>	Probe maximum alarm threshold
<b>LAL</b>	Probe minimum alarm threshold
<b>PAO</b>	Temperature alarm exclusion time from power-on
<b>dAO</b>	Temperature alarm disabling time after defrost cycle
<b>OAO</b>	High/low temperature alarm exclusion time after door closing
<b>tAO</b>	Temperature alarms delay time
<b>Art</b>	Regulator alarm type

---

### 8.3.3. END OF DEFROST DUE TO TIMEOUT alarm

#### OPERATING CONDITIONS

The regulator is activated without any delay in the case of end of defrost due to timeout, instead of probe 2 reaching the defrost end temperature.

The action consists of:

- alarm icon steadily on
- recording of Label **Ad2** in the alarms menu.

Automatic reset occurs with the start of the next defrost cycle.

The alarm icon can be switched off using the normal acknowledgement procedure, although the alarm signal is only actually cancelled at the start of the next defrost cycle.

#### SIGNALLING

Code	Meaning
<b>Ad2</b>	Defrost alarm on Pb2

#### USER PARAMETERS

Label	Description
<b>dEt</b>	Evaporator 1 defrost timeout
<b>dE2</b>	Defrost timeout evaporator 2
<b>dAt</b>	Alarm signalling end of defrost due to timeout

### 8.3.4. EXTERNAL alarm

#### OPERATING CONDITIONS

In the case of activation of the digital input, the alarm regulator is activated with the delay set by parameter **dAd**, and this alarm persists until the next time the digital input is deactivated.

The action consists of:

- alarm icon steadily on
- recording of Label **EAL** in the alarms menu.
- Activation of the relay configured as alarm (if enabled)
- deactivation of regulation if parameter **rLO** requires it.

It is possible to mute the alarm relay but the regulators still remain locked until the next time the digital input is deactivated.

The values that **rLO** can be assigned to parameter:

- **rLO = 0**: an external alarm has not locked any resource;
- **rLO = 1**: an external alarm has locked the compressor and defrost;
- **rLO = 2**: an external alarm has locked the compressor, defrost and the fans.

#### SIGNALLING

Code	Meaning
<b>EAL</b>	External alarm

#### USER PARAMETERS

Label	Description
<b>rLO</b>	An external alarm blocks the regulators

---

### 8.3.5. DOOR OPEN alarm

#### OPERATING CONDITIONS

The door switch alarm is associated to a specially configured digital input:

- **H11, H12, H13 = ± 4**

On activation of the digital input (door open) and after delay **tdO** has elapsed, the door open alarm must be signalled in the alarms folder and the icon and alarm relay should come on. The label **OPd** is displayed.

The action consists of:

- alarm icon steadily on
- recording of Label **OPd** in the alarms menu.
- Activation of the relay configured as alarm

As in the case of the other alarms, the relay may be disabled by pressing an acknowledgement key, the alarm icon will blink and label **OPd** will remain in the alarms menu until the door is closed.

If the door is opened, the regulator will operate on the basis of the value of parameter **dOd**. The values that can be assigned to it are:

- **dOd = 0**: no resource is locked;
- **dOd = 1**: fans are locked (FAN);
- **dOd = 2**: the compressor is locked (COMPR);
- **dOd = 3**: both the fans (FAN) and compressor (COMPR) are locked

If the door open alarm locks the compressor, it can still be reactivated even if the door remains open, by setting the parameter **dCO**.

#### SIGNALLING

Code	Meaning
<b>OPd</b>	Door open alarm

#### USER PARAMETERS

Label	Description
<b>dOd</b>	Digital input for switching off loads: <b>0</b> = disabled; <b>1</b> = disables the fans; <b>2</b> = disables the compressor; <b>3</b> = disables fans and compressor.
<b>dCO</b>	Compressor activation delay from acknowledgement
<b>tdO</b>	Open door disabling time

### 8.3.6. PRESSURE SWITCH INPUT alarm

#### OPERATING CONDITIONS

The pressure switch is associated with a suitably configured Digital Input and can be general, minimum or maximum.

**NOTE:** behaviour and configuration parameters are the same for all three types.

Every time pressure switch input activation causes the compressor/fans to be disabled instantly, with only visual indication of the activation (WARNING) provided via illumination of the alarm icon and recording of the number of pressure switch activations that have taken place.

If the pressure switch Digital Input is deactivated, the compressor starts up again and the alarm icon switches off, but the alarm folder still contains the number of activations recorded in the previous counting interval (defined using parameter **PEi**). Once the number of activations set in parameter **PEn** has been reached **PA** (general), **LPA** (minimum) or **HPA** (maximum) will appear on the display.

Compressor, fans and defrosts are deactivated, the alarm icon lights up and the alarm relay comes on if configured. Once the device has entered alarm mode, it must be switched off and on again, or a key-activated reset performed using the function **rPA** (reset pressure switch alarm) on the functions menu.

**NOTA:** **PEn** represents the number of pressure switch activations within the interval defined in parameter **PEi**, which determines activation of alarm mode and deactivation of the compressor, fan and defrost outputs  
If **PEn = 0** the function is excluded and the pressure switch alarm is ignored.

## SIGNALLING

Code	Meaning
PA	General pressure switch alarm
LPA	Minimum pressure switch alarm
HPA	Maximum pressure switch alarm

## USER PARAMETERS

Label	Description
PEn	Number of errors allowed per pressure switch input. <b>0</b> = disabled.
PEi	Pressure switch error count interval.

### 8.3.7. PANIC alarm

#### OPERATING CONDITIONS

The panic alarm is associated to a specially configured digital input:

- **H11, H12, H13 = ± 18**

After the delay set in parameter dAd, this alarm is activated and persists until the next digital input deactivation.

The action consists of:

- Panic alarm icon steadily on
- Alarm icon steadily on
- recording of label PAn in the alarms menu.
- activation of the relay configured as alarm (if enabled)

## SIGNALLING

Code	Meaning
PAn	Panic alarm

## USER PARAMETERS

Label	Description
dAd	Activation delay DI1, DI2
di3	Activation delay DI3



---

## 8.3.8. Leak detector ALARM

### OPERATING CONDITIONS

The refrigerant leak (Leak Detector) alarm is associated with an appropriately configured digital input.

- **H11, H12, H13 = ± 21**

This alarm is activated after the delay set in parameter **di3** and it persists until the next digital input deactivation.

The action consists of:

- Panic alarm icon blinking
- Alarm icon steadily on
- intermittent sounding of alarm buzzer
- recording of Label “ALd” in the alarms menu
- activation of the relay configured as alarm (if enabled)

The alarm relay can be inhibited by pressing any key; this action mutes the buzzer while the icons respond as follows:

- alarm icon blinking
- Panic alarm icon steadily on

If the “Leak Detector” alarm occurs in synchrony with the “Panic” alarm, the system response is as follows:

- Panic alarm icon steadily on
- Alarm icon steadily on
- intermittent sounding of buzzer
- recording of labels “Pan” and “ALd” in the alarms menu

As long as the Panic alarm persists it will not be possible to mute the buzzer from the keypad.

### SIGNALLING

Code	Meaning
<b>ALd</b>	Leak Detector Alarm

### USER PARAMETERS

Label	Description
<b>dAd</b>	Activation delay DI1, DI2
<b>di3</b>	Activation delay DI3

## 9. MODBUS MSK 554 /812 FUNCTIONS AND RESOURCES

ModBUS is a client/server protocol for communication between devices connected in a network.

ModBUS devices communicate using a master-slave technique in which only one device (master) can send messages.

The other devices in the network (slave) respond, returning the data requested by the master or executing the action contained in the message sent.

A slave is a device connected to a network that processes information and sends the results to the master using the ModBUS protocol.

The master device can send messages to individual slaves or to the entire network (broadcast) whilst slaves can only respond individually to the master.

The ModBUS standard used by Eliwell employs the RTU code for data transmission.

### 9.3.1. DATA FORMAT (RTU)

The coding model used defines the structure of messages transmitted on the network and the way in which this information is deciphered. The type of coding is usually selected on the basis of specific parameters (baudRate, parity, etc.); furthermore, some devices support only specific coding models, although it must be the same one for all devices connected in a ModBUS network.


The protocol uses the RTU binary method with bytes configured as follows: **8 bits for data (non-configurable), parity bit none, 1 stop BIT.**

Parameter setting allows the integral configuration of the device

Changes can be made via:

- Device keypad
- UNICARD / Copy Card
- data via Modbus protocol directly to an individual controller or broadcasting it, using the address 0 (broadcast)

### 9.3.2. NETWORK



### 9.3.3. ModBUS COMMANDS AVAILABLE AND DATA AREAS

The following commands are implemented:

ModBUS command	Command description								
<b>03</b> (hex 0x03)	Read 16 consecutive registers for Client side.								
<b>04</b> (hex 0x04)	Read 1 single register for parameters.								
<b>16</b> (hex 0x10)	Write 15 consecutive registers for Client side								
<b>22</b> (hex 0x16)	Write 1 register for the parameters								
<b>43</b> (hex 0x2B)	Read device ID. It is possible to read the following 3 fields: <table border="1" data-bbox="593 698 1449 1003" style="margin-left: 40px;"> <thead> <tr> <th>Field code</th> <th>Field description</th> </tr> </thead> <tbody> <tr> <td><b>0</b></td> <td>Manufacturer ID (=“Invensys”)</td> </tr> <tr> <td><b>1</b></td> <td>Device model/polycarbonate ID  <b>format: 00FB_0401</b>  <b>PCH = 251 (FB hex) POLI = 1025 (0401 hex)</b></td> </tr> <tr> <td><b>2</b></td> <td>Device family (MSK554)/version ID  <b>format: 022A_0259</b>  <b>MSK = 554 (22A hex) REL = 0601 (259 hex)</b></td> </tr> </tbody> </table>	Field code	Field description	<b>0</b>	Manufacturer ID (=“Invensys”)	<b>1</b>	Device model/polycarbonate ID <b>format: 00FB_0401</b> <b>PCH = 251 (FB hex) POLI = 1025 (0401 hex)</b>	<b>2</b>	Device family (MSK554)/version ID <b>format: 022A_0259</b> <b>MSK = 554 (22A hex) REL = 0601 (259 hex)</b>
Field code	Field description								
<b>0</b>	Manufacturer ID (=“Invensys”)								
<b>1</b>	Device model/polycarbonate ID <b>format: 00FB_0401</b> <b>PCH = 251 (FB hex) POLI = 1025 (0401 hex)</b>								
<b>2</b>	Device family (MSK554)/version ID <b>format: 022A_0259</b> <b>MSK = 554 (22A hex) REL = 0601 (259 hex)</b>								

### 9.3.4. ADDRESS CONFIGURATION

The serial TTL - which we will call COM1 – can be used to configure the device, parameters, states, and variables with ModBUS via the ModBUS protocol.

The address of a device within a ModBUS message is set using the parameter **Adr**.

The address 0 is used for broadcast messages that all slaves recognise. Slaves don't respond to broadcast messages. The parameters for configuring the device are:

Parameter	Description	Values	Range
<b>PtS</b>	Select COM1 (TTL) protocol	d	t = Televis d = ModBUS
<b>Adr</b>	ModBUS protocol controller address	1	1...250
<b>Pty</b>	ModBUS protocol parity bit	n	• n= NONE • E = EVEN (parity) • o = ODD (disparity)
<b>bAU</b>	Baudrate selection.	96	• 96 = 9600 baud • 192 = 19200 baud • 384 = 38400 baud

**NOTE:** for correct operation, the controller must be switched off and switched on again after modification

## 9.3.5. PARAMETER VISIBILITY AND VALUES

### NOTE:

- 1) When not indicated otherwise, the parameter is always visible and modifiable, unless customised settings have been configured by the user via serial
- 2) If folder visibility is modified, the new setting will apply to all parameters in the folder.

## 9.3.6. MODBUS TABLES

The tables below list all information required to read, write and decode all accessible resources in the device. There are 3 tables:

- the **"PARAMETER TABLE"** contains all device configuration parameters stored in the controller's non-volatile memory, including visibility
- the **"FOLDER VISIBILITY TABLE (FOLDER)"** indicates the visibility of the folders containing the parameters
- the **"CLIENT TABLE"** includes all I/O and alarm status resources available in the volatile memory of the instrument.

### Description of the columns:

#### FOLDER

Indicates the label of the folder containing the parameter in question

#### LABEL

Indicates the label used to display the parameters in the menu of the controller.

#### PAR. VALUE ADDRESS

The whole part represents the address of the ModBUS register containing the value of the resource to be read or written in the controller. The value after the decimal point indicates the position of the most significant data bit inside the register; if not indicated it is taken to be zero. This information is always provided when the register contains more than one information item, and it is necessary to distinguish which bits actually represent the data (the working size of the data indicated in the column DATA SIZE is also taken into consideration).

Given that the ModBUS registers have the size of one WORD (16 bit), the index number after the point can vary from 0 (least significant bit -LSb-) to 15 (most significant bit -MSb-).

Examples (in binary form the least significant bit is the first on the right):

PAR. VALUE ADDRESS	DATA SIZE	Value		Content of register
8806	WORD	1350	1350	(0000010101000110)
8806	BYTE	70	1350	(00000101 <b>01000110</b> )
8806.8	BYTE	5	1350	( <b>00000101</b> 01000110)
8806.14	1 BIT	0	1350	(0000010101000 <b>110</b> )
8806.7	4 BIT	10	1350	(00000 <b>1010</b> 1000110)

**IMPORTANT:** when the register contains more than one piece of data, the writing procedure is as follows:

- Read current value of register
- Modify bits for the resource concerned
- Write register

#### VIS PAR. ADDRESS

The same as above. In this case, the ModBUS register address contains the visibility value of the parameter.

By default all parameters have:

- Data size 2 bit
- Range 0...3
- \*\*Visibility 3
- U.M. num

#### \*\*Value Meaning

- Value 3 = parameter or folder always visible
- Value 2 = **installer level**; these parameters can only be viewed by entering the manufacturer password (see parameter PS2) (all parameters specified as always visible, parameters visible at the installer level and manufacturer level will be visible)
- Value 1 = **user level**; these parameters can only be viewed by entering the installer password (see parameter PS1) (all parameters specified as always visible and parameters visible at the installer level will be visible)
- Value 0 = parameter or folder NOT visible

1. Parameters and/or folders with a level of visibility =**1,2** (password-protected) will be visible only if the correct password is entered (installer or user) following this procedure:
2. Parameters and/or folders with a level of visibility =3 are always visible even without a password: in this case, the following procedure is not necessary.

Examples (in binary form the least significant bit is the first on the right):

**Default visibility:**

PAR. VALUE ADDRESS	DATA SIZE	Value		Content of register
49336.6	2 BIT	3	65535	----- (00000000 <b>1111111111111111</b> )
49337	2 BIT	3	65535	(00000000 <b>1111111111111111</b> )
49337.2	2 BIT	3	65535	(00000000 <b>1111111111111111</b> )
49337.4	2 BIT	3	65535	(00000000 <b>1111111111111111</b> )
49337.6	2 BIT	3	65535	(00000000 <b>1111111111111111</b> )

**R/W**

Indicates the option of reading or writing the resource

- R The resource is read-only
- W The resource is write-only
- RW The resource can be both read and written

**DESCRIPTION**

This is the description of the meaning of **parameters** in the **LABEL** column.

**DATA SIZE**

Indicates the size of the data in bits.

- WORD = 16 bit
- Byte = 8 bit
- "n" bit = 0...15 bit based on the value of "n"

**CPL**

When the field indicates "Y", the value read by the register needs to be converted because the value represents a number with a sign. In the other cases the value is always positive or null.

To carry out conversion, proceed as follows:

- if the value in the register is between 0 and 32,767, the result is the value itself (zero and positive values)
- if the value in the register is between 32,768 and 65,535, the result is the value of the register – 65,536 (negative values)

**EXP**

**WHEN UTILISING MODBUS PROTOCOL ONLY**

If = -1 the value read by the register is divided by 10 (value/10) to convert it to the values indicated in the RANGE and DEFAULT columns using the unit of measure indicated in the column U.M.

Example: parameter HSE = 50.0. Column EXP = -1:

- The value read by the device /DeviceManager is 50.0
- The value read by the register is 500 --> 500/10 = 50.0

**RANGE**

Describes the interval of values that can be assigned to the parameter. It can be correlated with other parameters in the instrument (indicated with the parameter label).

**U.M.**

Unit of measure for values converted according to the rules indicated in the CPL and EXP columns.

### 9.3.7. PARAMETER/VISIBILITY table

**NOTE:** ModBUS read command: 04 (0x04) and ModBUS write command: 22 (0x16)

FOLDER	LABEL	PAR. ADDRESS Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	UM	RANGE
/	SEt	16386	49455	RW	Setpoint	WORD	Y		°C/°F	LSE...HSE
CPr	diF	16388	49455,2	RW	Setpoint differential	WORD	Y	-1	°C/°F	0...30.0
CPr	HSE	16390	49455,4	RW	Maximum setpoint value that can be set	WORD	Y	-1	°C/°F	LSE...HdL
CPr	LSE	16392	49455,6	RW	Minimum setpoint value that can be set	WORD	Y	-1	°C/°F	LdL...HSE
CPr	OSP	16394	49456	RW	Offset on setpoint	WORD	Y	-1	°C/°F	-30.0...30.0
CPr	Cit	49235	49456,4	RW	Minimum compressor output activation time	BYTE			min	0...255
CPr	CAt	49236	49456,6	RW	Maximum compressor output activation time	BYTE			min	0...255
CPr	Ont	49237	49457	RW	ON time for compressor output with control probe error	BYTE			min	0...255
CPr	OFt	49238	49457,2	RW	OFF time for compressor output with control probe error	BYTE			min	0...255
CPr	dOn	49239	49457,4	RW	Compressor output activation delay from request	BYTE			s	0...255
CPr	dOF	49240	49457,6	RW	Compressor output activation delay from shutdown	BYTE			min	0...255
CPr	dbi	49241	49458	RW	Delay between two consecutive starts of the compressor output	BYTE			min	0...255
CPr	OdO	49242	49458,2	RW	Output activation delay from power-on	BYTE			min	0...255
CPr	dSC	49243	49458,4	RW	Compressor 2 activation delay	BYTE			s	0...255
CPr	dCS	16396	49458,6	RW	Deep Cooling setpoint	WORD	Y	-1	°C/°F	-58.0...302.0
CPr	tdc	16398	49459	RW	Deep Cooling Duration	WORD			min	0...600
CPr	dcc	49244	49459,2	RW	Delay defrost after Deep Cooling	BYTE			min	0...255
dEF	dty	49245	49459,4	RW	Defrost mode	BYTE			num	0...2
dEF	dit	49246	49459,6	RW	Interval between defrost cycles	BYTE			hrs/min/s	0...255
dEF	dt1	49247	49460	RW	Unit of measure for defrost interval	BYTE			num	0/1/2
dEF	dt2	49248	49460,2	RW	Unit of measurement for defrost duration	BYTE			num	0/1/2
dEF	dCt	49249	49460,4	RW	Defrost interval count mode	BYTE			num	0...3
dEF	dOH	49250	49460,6	RW	Defrost interval count mode	BYTE			min	0...59
dEF	dEt	49251	49461	RW	Evaporator 1 defrost timeout	BYTE			hrs/min/s	1...255
dEF	dSt	16400	49461,2	RW	Probe 1 defrost end temperature	WORD	Y	-1	°C/°F	-58.0...302.0
dEF	dS2	16402	49461,4	RW	Probe 2 defrost end temperature	WORD	Y	-1	°C/°F	-58.0...302.0
dEF	dE2	49252	49461,6	RW	Defrost timeout evaporator 2	BYTE			hrs/min/s	1...250
dEF	dPO	49253	49462	RW	Defrost activation request from power-on	BYTE			flag	0/1
dEF	tcd	16404	49462,2	RW	Minimum compressor ON or OFF time in mins. before defrost	WORD	Y		min	-31...31
dEF	Cod	49254	49462,4	RW	Time preceding a defrost, during which the compressor output is not activated	BYTE			min	0...60
dEF	dE1_h	49341		RW	Defrost start time (minutes) no. 1 weekday	BYTE			hours	0...24
dEF	dE1_min	49340		RW	Defrost start time (hours) no. 2 weekday	BYTE			min	0...59
dEF	dE2_h	49343		RW	Defrost start time (minutes) no. 2 weekday	BYTE			hours	0...24
dEF	dE2_min	49342		RW	Defrost start time (hours) no. 3 weekday	BYTE			min	0...59
dEF	dE3_h	49345		RW	Defrost start time (minutes) no. 3 weekday	BYTE			hours	0...24
dEF	dE3_min	49344		RW	Defrost start time (hours) no. 4 weekday	BYTE			min	0...59
dEF	dE4_h	49347		RW	Defrost start time (minutes) no. 4 weekday	BYTE			hours	0...24
dEF	dE4_min	49346		RW	Defrost start time (hours) no. 5 weekday	BYTE			min	0...59
dEF	dE5_h	49349		RW	Defrost start time (minutes) no. 5 weekday	BYTE			hours	0...24
dEF	dE5_min	49348		RW	Defrost start time (hours) no. 6 weekday	BYTE			min	0...59
dEF	dE6_h	49351		RW	Defrost start time (minutes) no. 6 weekday	BYTE			hours	0...24
dEF	dE6_min	49350		RW	Defrost start time (hours) no. 7 weekday	BYTE			min	0...59
dEF	dE7_h	49353		RW	Defrost start time (minutes) no. 7 weekday	BYTE			hours	0...24
dEF	dE7_min	49352		RW	Defrost start time (hours) no. 8 weekday	BYTE			min	0...59

FOLDER	LABEL	PAR. Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	UM	RANGE
dEF	dE8_h	49355		RW	Defrost start time (minutes) no. 8 weekday	BYTE			hours	0...24
dEF	dE8_min	49354		RW	Weekday defrost 3 duration	BYTE			min	0...59
dEF	F1_h	49357		RW	Defrost start time (hours) no. 1 weekend	BYTE			hours	0...24
dEF	F1_min	49356		RW	Defrost start time (minutes) no. 1 weekend	BYTE			min	0...59
dEF	F2_h	49359		RW	Defrost start time (hours) no. 2 weekend	BYTE			hours	0...24
dEF	F2_min	49358		RW	Defrost start time (minutes) no. 2 weekend	BYTE			min	0...59
dEF	F3_h	49361		RW	Defrost start time (hours) no. 3 weekend	BYTE			hours	0...24
dEF	F3_min	49360		RW	Defrost start time (minutes) no. 3 weekend	BYTE			min	0...59
dEF	F4_h	49363		RW	Defrost start time (hours) no. 4 weekend	BYTE			hours	0...24
dEF	F4_min	49362		RW	Defrost start time (minutes) no. 4 weekend	BYTE			min	0...59
dEF	F5_h	49365		RW	Defrost start time (hours) no. 5 weekend	BYTE			hours	0...24
dEF	F5_min	49364		RW	Defrost start time (minutes) no. 5 weekend	BYTE			min	0...59
dEF	F6_h	49367		RW	Defrost start time (hours) no. 6 weekend	BYTE			hours	0...24
dEF	F6_min	49366		RW	Defrost start time (minutes) no. 6 weekend	BYTE			min	0...59
dEF	F7_h	49369		RW	Defrost start time (hours) no. 7 weekend	BYTE			hours	0...24
dEF	F7_min	49368		RW	Defrost start time (minutes) no. 7 weekend	BYTE			min	0...59
dEF	F8_h	49371		RW	Defrost start time (hours) no. 8 weekend	BYTE			hours	0...24
dEF	F8_min	49370		RW	Defrost start time (minutes) no. 8 weekend	BYTE			min	0...59
FAn	FPt	49255	49463	RW	FSt parameter mode	BYTE			flag	0/1
FAn	FSt	16406	49463,2	RW	Fan disabling temperature	WORD	Y	-1	°C/°F	-58.0...302.0
FAn	Fot	16408	49463,4	RW	Evaporator fans start temperature	WORD	Y	-1	°C/°F	-58.0...302.0
FAn	FAd	16410	49463,6	RW	Fans differential	WORD		-1	°C/°F	0.1...25.0
FAn	Fdt	49256	49464	RW	Fan activation delay from compressor start	BYTE			min	0...255
FAn	dt	49257	49464,2	RW	Dripping time	BYTE			min	0...255
FAn	dFd	49258	49464,4	RW	Evaporator fans mode in defrost	BYTE			flag	0/1
FAn	FCO	49259	49464,6	RW	Evaporator fans mode	BYTE			num	0...4
FAn	FdC	49261	49465,2	RW	Fan switch-off delay from compressor stoppage	BYTE			min	0...255
FAn	FOn	49262	49465,4	RW	Fans ON time in duty-cycle	BYTE			min	0...255
FAn	FOF	49263	49465,6	RW	Fans OFF time in duty-cycle	BYTE			min	0...255
FAn	SCF	16412	49466	RW	Condenser fans activation Setpoint	WORD		-1	°C/°F	-50.0...150.0
FAn	dCF	16414	49466,2	RW	Condenser fans activation differential	WORD		-1	°C/°F	-30.0...30.0
FAn	tCF	49264	49466,4	RW	Condenser fans switch-on delay after defrost	BYTE			min	0...59
FAn	dCd	49265	49466,6	RW	Condenser fans exclusion during defrost	BYTE			flag	0/1
AL	Att	49266	49467	RW	HAL and LAL parameter mode	BYTE			flag	0/1
AL	AFd	16416	49467,2	RW	Alarm setpoint differential	WORD		-1	°C/°F	0.1...50.0
AL	HAL	16418	49467,4	RW	Maximum alarm	WORD	Y	-1	°C/°F	LA1...302.0
AL	LAL	16420	49467,6	RW	Minimum alarm	WORD	Y	-1	°C/°F	-58.0...HA1
AL	PAO	49267	49468	RW	Alarm exclusion at power-on	BYTE			hours	0...10
AL	dAO	16422	49468,2	RW	Alarm exclusion after defrost	WORD			min	0...255
AL	OAO	49268	49468,4	RW	Alarm signalling delay from door closure	BYTE			hours	0...10
AL	tdO	49269	49468,6	RW	Open door disabling time	BYTE			min	0...255
AL	tAO	49270	49469	RW	Temperature alarms signalling delay	BYTE			min	0...255
AL	dAt	49271	49469,2	RW	Enable alarm at end of defrost	BYTE			flag	0/1
AL	rLO	49272	49469,4	RW	External alarm switches off loads	BYTE			num	0/1/2
AL	AOP	49273	49469,6	RW	Alarm output polarity	BYTE			flag	0/1
AL	PbA	49275	49470,2	RW	Probe enabled to signal temperature alarms (probe 1 and/or 3)	BYTE			num	0...3
AL	SA3	16424	49470,4	RW	Alarm set point related to probe 3	WORD	Y	-1	°C/°F	-50.0...150.0
AL	dA3	16426	49470,6	RW	Probe 3 alarm tripping differential	WORD	Y	-1	°C/°F	-30.0...30.0
AL	tA3	49276	49471	RW	Alarm 3 signalling delay time	BYTE			min	0...59

FOLDER	LABEL	PAR. Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	UM	RANGE
AL	ArE	49277	49471,2	RW	Enables alarm relay in the event of probe 3-related alarms	BYTE			num	0/1/2
AL	Art	16655	49491,4	RW	Regulator alarm type	BYTE			num	0/1
Lit	dSd	49278	49471,4	RW	Enable light relay from door switch	BYTE			flag	0/1
Lit	dLt	49279	49471,6	RW	Light relay deactivation delay	BYTE			min	0...31
Lit	OFL	49280	49472	RW	Light key always disables light relay	BYTE			flag	0/1
Lit	dOd	49281	49472,2	RW	Door switch switches off loads	BYTE			num	0...3
Lit	dAd	49282	49472,4	RW	Delay activating digital inputs DI1, DI2	BYTE			min	0...255
Lit	di3	49283	49472,6	RW	Delay to activate digital input DI3	BYTE			min	0...255
Lit	dOA	49285	49473,2	RW	Action forced by digital input	BYTE			num	0...5
Lit	PEA	49286	49473,4	RW	Select DI for lock/unlock resources function	BYTE			num	0...3
Lit	dCO	49287	49473,6	RW	Evaporator fan compressor activation/switch-off delay	BYTE			min	0...255
Lit	dOC	49260	49465	RW	Compressor switch-off delay from acknowledgement	BYTE			min	0...255
Lit	dFO	49288	49474	RW	Evaporator fan activation/switch-off delay	BYTE			min	0...255
Lit	PEn	49334	49474,2	RW	Number of errors permitted	BYTE			num	0...15
Lit	PEi	49335	49474,4	RW	Error count interval	BYTE			min	1...99
Lit	O1i	16658	49487,2	RW	Delay activating digital input DI1	BYTE			min	0...250
Lit	O2i	16659	49487,3	RW	Delay to activate digital input DI2	BYTE			min	0...250
nAd	d0_E0	49372	--	RW	Enable functions during events day 1 (SUNDAY)	BYTE			num	0...8
nAd	d0_E1_h	49397	--	RW	Event start time (hours) day 1	BYTE			hours	0...23
nAd	d0_E1_m	49396	--	RW	Event start time (minutes) day 1	BYTE			min	0...59
nAd	d0_E2	49380	--	RW	Event duration day 1	BYTE			hours	0...72
nAd	d0_E3	49388	--	RW	Enable defrost weekdays or weekends day 1	BYTE			flag	0...1
nAd	d1_E0	49373	--	RW	Enable functions during events day 2	BYTE			num	0...8
nAd	d1_E1_h	49399	--	RW	Event start time (hours) day 2	BYTE			hours	0...23
nAd	d1_E1_m	49398	--	RW	Event start time (minutes) day 2	BYTE			min	0...59
nAd	d1_E2	49381	--	RW	Event duration day 2	BYTE			hours	0...72
nAd	d1_E3	49389	--	RW	Enable defrost weekdays or weekends day 2	BYTE			flag	0...1
nAd	d2_E0	49374	--	RW	Enable functions during events day 3	BYTE			num	0...8
nAd	d2_E1_h	49401	--	RW	Event start time (hours) day 3	BYTE			hours	0...23
nAd	d2_E1_m	49400	--	RW	Event start time (minutes) day 3	BYTE			min	0...59
nAd	d2_E2	49382	--	RW	Event duration day 3	BYTE			hours	0...72
nAd	d3_E3	49390	--	RW	Enable defrost weekdays or weekends day 3	BYTE			flag	0...1
nAd	d3_E0	49375	--	RW	Enable functions during events day 4	BYTE			num	0...8
nAd	d3_E1_h	49403	--	RW	Event start time (hours) day 4	BYTE			hours	0...23
nAd	d3_E1_m	49402	--	RW	Event start time (minutes) day 4	BYTE			min	0...59
nAd	d3_E2	49383	--	RW	Event duration day 4	BYTE			hours	0...72
nAd	d3_E3	49391	--	RW	Enable defrost weekdays or weekends day 4	BYTE			flag	0...1
nAd	d4_E0	49376	--	RW	Enable functions during events day 5	BYTE			num	0...8
nAd	d4_E1_h	49405	--	RW	Event start time (hours) day 5	BYTE			hours	0...23
nAd	d4_E1_m	49404	--	RW	Event start time (minutes) day 5	BYTE			min	0...59
nAd	d4_E2	49384	--	RW	Event duration day 5	BYTE			hours	0...72
nAd	d4_E3	49392	--	RW	Enable defrost weekdays or weekends day 5	BYTE			flag	0...1
nAd	d5_E0	49377	--	RW	Enable functions during events day 6	BYTE			num	0...8
nAd	d5_E1_h	49407	--	RW	Event start time (hours) day 6	BYTE			hours	0...23
nAd	d5_E1_m	49406	--	RW	Event start time (minutes) day 6	BYTE			min	0...59
nAd	d5_E2	49385	--	RW	Event duration day 6	BYTE			hours	0...72
nAd	d5_E3	49393	--	RW	Enable defrost weekdays or weekends day 6	BYTE			flag	0...1
nAd	d6_E0	49378	--	RW	Enable functions during events day 7 (SATURDAY)	BYTE			num	0...8



FOLDER	LABEL	PAR. ADDRESS Value	Vis. PAR. ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	UM	RANGE
nAd	d6_E1_h	49409	--	RW	Event start time (hours) day 7	BYTE			hours	0...23
nAd	d6_E1_m	49408	--	RW	Event start time (minutes) day 7	BYTE			min	0...59
nAd	d6_E2	49386	--	RW	Event duration day 7	BYTE			hours	0...72
nAd	d6_E3	49394	--	RW	Enable defrost weekdays or weekends day 7	BYTE			flag	0...1
nAd	d7_E0	49379	--	RW	Enable functions during daily event (EVERY DAY)	BYTE			num	0...8
nAd	d7_E1_h	49411	--	RW	Daily event start time	BYTE			hours	0...23
nAd	d7_E1_m	49410	--	RW	Daily event start time (minutes)	BYTE			min	0...59
nAd	d7_E2	49387	--	RW	Duration of daily event	BYTE			hours	0...72
nAd	d7_E3	49395	--	RW	Enable defrost weekdays or weekends daily event	BYTE			flag	0...1
Add	PtS	49289	49474,6	RW	Protocol selection (0: Televis; 1: ModBUS)	BYTE			flag	0/1
Add	dEA	49290	49475	RW	Device address, Micronet	BYTE			num	0...14
Add	FAA	49291	49475,2	RW	Family address, Micronet	BYTE			num	0...14
Add	Adr	49422	49453,6	RW	ModBUS address	BYTE			num	1...255
Add	Pty	49292	49475,4	RW	Parity bit (ModBUS protocol)	BYTE			num	0/1/2
Add	Pty	49293	49475,6	RW	ModBUS stop bit	BYTE			num	0/1
Add	bAU	49421	49454	RW	BaudRate	BYTE			num	0/1/2
diS	LOC	49294	49476	RW	Keypad lock	BYTE			flag	0/1
diS	PS1	16428	49476,2	RW	Password 1	WORD			num	0...999
diS	PS2	16430	49476,4	RW	Password 2	WORD			num	0...999
diS	PS3	16432	49476,6	RW	Password 3	WORD			num	0...999
diS	ndt	49295	49477	RW	Display with decimal point	BYTE			flag	0/1
diS	CA1	16434	49477,2	RW	Calibration Pb1	WORD	Y		°C/°F	-30.0...30.0
diS	CA2	16436	49477,4	RW	Calibration Pb2	WORD	Y		°C/°F	-30.0...30.0
diS	CA3	16438	49477,6	RW	Calibration Pb3	WORD	Y		°C/°F	-30.0...30.0
diS	CA	49296	49478	RW	Calibration operation	BYTE			num	0/1/2
diS	LdL	16440	49478,2	RW	Minimum possible value	WORD	Y		°C/°F	-58.0...HdL
diS	HdL	16442	49478,4	RW	Maximum possible value	WORD	Y		°C/°F	LdL...302
diS	ddL	49297	49478,6	RW	Lock display during defrost	BYTE			num	0/1/2
diS	Ldd	49298	49479	RW	Unlock timeout "ddL"	BYTE			minutes	0...255
diS	dro	49299	49479,2	RW	°C/°F selection. (0=°C, 1=°F)	BYTE			flag	0/1
diS	ddd	49300	49479,4	RW	Selection of main display value 1	BYTE			num	0/1/2
diS	dd2	49420	49491,2	RW	Selection of main display value 2	BYTE			flag	0/1
HAC	SHi	16444	49479,6	RW	Maximum HACCP alarm threshold, no delay	WORD	Y	-1	°C/°F	SHH...150.0
HAC	SLi	16446	49480	RW	Minimum HACCP alarm threshold, no delay	WORD	Y	-1	°C/°F	-50.0...SLH
HAC	SHH	16448	49480,2	RW	Maximum HACCP alarm threshold	WORD	Y	-1	°C/°F	SLH...150.0
HAC	SLH	16450	49480,4	RW	Minimum HACCP alarm threshold	WORD	Y	-1	°C/°F	50.0...SHH
HAC	drA	49301	49480,6	RW	Minimum dwelling time in critical area before alarm signalling	BYTE			min	0...99
HAC	drH	49302	49481	RW	HACCP alarm reset time from last manual reset	BYTE			hours	0...255
HAC	H50	49303	49481,2	RW	Enable HACCP alarms storage with/without alarm relay enabling	BYTE			num	0/1/2
HAC	H51	49304	49481,4	RW	HACCP alarms storage disabling time (key or digital input)	BYTE			min	0...255
HAC	H52	49305	49481,6	RW	Probe enabled to signal HACCP alarms	BYTE			flag	1/3
CnF	H00	49306	49482	RW	Probe type Pb1-Pb2-Pb3 (1=NTC, 0=PTC)	BYTE			flag	0/1
CnF	H01	49307	49482,2	RW	Enable deep cooling	BYTE			flag	0/1
CnF	H02	49308	49482,4	RW	Key activation time	BYTE			s	0...15
CnF	H06	49309	49482,6	RW	Key or auxiliary digital input/light on with device Off	BYTE	Y		flag	0/1
CnF	H08	49310	49483	RW	Stand-by mode	BYTE			num	0...3
CnF	H11	16452	49483,2	RW	DI1 input configuration	BYTE	Y		num	-22...22

FOLDER	LABEL	PAR. Value ADDRESS	Vis. PAR.ADDRESS	R/W	DESCRIPTION	DATA SIZE	CPL	EXP	UM	RANGE
CnF	H12	16454	49483,4	RW	DI2 input configuration	BYTE	Y		num	-22...22
CnF	H13	16456	49483,6	RW	DI3 input configuration	BYTE	Y		num	-22...22
CnF	H21	49311	49484,2	RW	Configuration relay 1	BYTE			num	0...13
CnF	H22	49312	49484,4	RW	Configuration Relay 2	BYTE			num	0...13
CnF	H23	49313	49484,6	RW	Configuration Relay 3	BYTE			num	0...13
CnF	H24	49314	49485	RW	Configuration Relay 4	BYTE			num	0...13
CnF	H25	49315	49485,2	RW	Configuration Relay 5	BYTE			num	0...13
CnF	H28	49318	49486	RW	Enable buzzer	BYTE			flag	0/1
CnF	H32	49320	49486,4	RW	Configuration of DOWN key	BYTE			num	0...15
CnF	H33	49321	49486,6	RW	ESC key configuration	BYTE			num	0...15
CnF	H34	49322	49487	RW	ON/OFF key configuration	BYTE			num	0...15
CnF	H35	49323	49487,2	RW	LIGHT key configuration	BYTE			num	0...15
CnF	H41	49327	49488,2	RW	Pb1 input configuration	WORD			flag	0/1
CnF	H42	49328	49488,4	RW	Pb2 input configuration	WORD			flag	0/1
CnF	H43	49329	49488,6	RW	Pb3 input configuration	WORD			num	n, y, 2EP, 3-1
CnF	H44	49330	49489	RW	Setpoint for Pb3-Pb1 temperature differential	WORD			num	0...255
CnF	H45	49331	49489,2	RW	Start defrost mode for applications with double evaporator	WORD			num	0...2
CnF	H48	49332	49489,4	RW	Clock presence	WORD			flag	0/1
CnF	H60	49333	49489,6	R	Preset selection (Parameters vector selector)	WORD			num	0...8
CnF	rEL	---	---	R	Device version	WORD			num	0...3
CnF	tAb	---	---	R	Map code	WORD			num	0...3
FrH	HOn	49336	49490,4	RW	Frame Heater regulator output On time	BYTE			min	0...255
FrH	HOF	49337	49490,6	RW	Frame Heater regulator output Off time	BYTE			min	0...255
FrH	dt3	49338	49491	RW	Frame Heater regulator time standard unit of measurement	BYTE			num	0/1/2
FPr	UL	--	--	--	Parameter transfer function visibility (Controller -> UNICARD / Copy Card)	2 BIT			num	0...3
FPr	dL	--	--	--	Parameter transfer function visibility (UNICARD / Copy Card -> Controller)	2 BIT			num	0...3
FPr	Fr	--	--	--	UNICARD / Copy Card formatting function visibility	2 BIT			num	0...3

### 9.3.8. PARAMETER/VISIBILITY H60 table

LABEL	PAR. Value ADDRESS	Vis. PAR. ADDRESS	R/W	DESCRIPTION	DATA SIZE	UM	RANGE
V0-SEt	16752	--	RW	Regulation set point	WORD	°C/°F	LSE...HSE
V0-diF	16754	--	RW	Setpoint differential	WORD	°C/°F	0.1...30.0
V0-LSE	16756	--	RW	Minimum setpoint value that can be set	WORD	°C/°F	LSE...HdL
V0-HSE	16758	--	RW	Maximum setpoint value that can be set	WORD	°C/°F	LdL...HSE
V0-dSt	16760	--	RW	Defrost end temperature	WORD	°C/°F	-58.0...302.0
V0-FSt	16762	--	RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0...150.0
V0-dty	49532	--	RW	Defrost mode	BYTE	num	0/1/2
V0-dit	49533	--	RW	Interval between defrost cycles	BYTE	min	0...255
V0-dCt	49534	--	RW	Defrost interval count mode	BYTE	num	0...3
V0-dOH	49535	--	RW	Defrost cycle enabling delay from request	BYTE	min	0...59
V0-dEt	49536	--	RW	Defrost timeout	BYTE	hrs/min/s	1...255
V0-Fdt	49537	--	RW	Evaporator fans delay after defrost cycle	BYTE	min	0...255
V0-dt	49538	--	RW	Dripping time	BYTE	min	0...255
V0-dPO	49539	--	RW	Defrost enabling request from power-on	BYTE	flag	0/1
V0-ddL	49540	--	RW	Lock display during defrost mode	BYTE	num	0/1/2
V0-dFd	49541	--	RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V1-SEt	16774	--	RW	Regulation set point	WORD	°C/°F	LSE...HSE
V1-diF	16776	--	RW	Setpoint differential	WORD	°C/°F	0.1...30.0
V1-LSE	16778	--	RW	Minimum setpoint value that can be set	WORD	°C/°F	LSE...HdL
V1-HSE	16780	--	RW	Maximum setpoint value that can be set	WORD	°C/°F	LdL...HSE
V1-dSt	16782	--	RW	Defrost end temperature	WORD	°C/°F	-58.0...302.0
V1-FSt	16784	--	RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0...150.0
V1-dty	49554	--	RW	Defrost mode	BYTE	num	0/1/2
V1-dit	49555	--	RW	Interval between defrost cycles	BYTE	min	0...255
V1-dCt	49556	--	RW	Defrost interval count mode	BYTE	num	0...3
V1-dOH	49557	--	RW	Defrost cycle enabling delay from request	BYTE	min	0...59
V1-dEt	49558	--	RW	Defrost timeout	BYTE	hrs/min/s	1...255
V1-Fdt	49559	--	RW	Evaporator fans delay after defrost cycle	BYTE	min	0...255
V1-dt	49560	--	RW	Dripping time	BYTE	min	0...255
V1-dPO	49561	--	RW	Defrost enabling request from power-on	BYTE	flag	0/1
V1-ddL	49562	--	RW	Lock display during defrost mode	BYTE	num	0/1/2
V1-dFd	49563	--	RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V2-SEt	16796	--	RW	Regulation set point	WORD	°C/°F	LSE...HSE
V2-diF	16798	--	RW	Setpoint differential	WORD	°C/°F	0.1...30.0
V2-LSE	16800	--	RW	Minimum setpoint value that can be set	WORD	°C/°F	LSE...HdL
V2-HSE	16802	--	RW	Maximum setpoint value that can be set	WORD	°C/°F	LdL...HSE
V2-dSt	16804	--	RW	Defrost end temperature	WORD	°C/°F	-58.0...302.0
V2-FSt	16806	--	RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0...150.0
V2-dty	49576	--	RW	Defrost mode	BYTE	num	0/1/2
V2-dit	49577	--	RW	Interval between defrost cycles	BYTE	min	0...255
V2-dCt	49578	--	RW	Defrost interval count mode	BYTE	num	0...3
V2-dOH	49579	--	RW	Defrost cycle enabling delay from request	BYTE	min	0...59
V2-dEt	49580	--	RW	Defrost timeout	BYTE	hrs/min/s	1...255
V2-Fdt	49581	--	RW	Evaporator fans delay after defrost cycle	BYTE	min	0...255
V2-dt	49582	--	RW	Dripping time	BYTE	min	0...255
V2-dPO	49583	--	RW	Defrost enabling request from power-on	BYTE	flag	0/1
V2-ddL	49584	--	RW	Lock display during defrost mode	BYTE	num	0/1/2

LABEL	PAR. Value ADDRESS	Vis. PAR. ADDRESS	R/W	DESCRIPTION	DATA SIZE	UM	RANGE
V2-dFd	49585	--	RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V3-SEt	16818	--	RW	Regulation set point	WORD	°C/°F	LSE...HSE
V3-diF	16820	--	RW	Setpoint differential	WORD	°C/°F	0.1...30.0
V3-LSE	16822	--	RW	Minimum setpoint value that can be set	WORD	°C/°F	LSE...HdL
V3-HSE	16824	--	RW	Maximum setpoint value that can be set	WORD	°C/°F	LdL...HSE
V3-dSt	16826	--	RW	Defrost end temperature	WORD	°C/°F	-58.0...302.0
V3-FSt	16828	--	RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0...150.0
V3-dty	49598	--	RW	Defrost mode	BYTE	num	0/1/2
V3-dit	49599	--	RW	Interval between defrost cycles	BYTE	min	0...255
V3-dCt	49600	--	RW	Defrost interval count mode	BYTE	num	0...3
V3-dOH	49601	--	RW	Defrost cycle enabling delay from request	BYTE	min	0...59
V3-dEt	49602	--	RW	Defrost timeout	BYTE	hrs/min/s	1...255
V3-Fdt	49603	--	RW	Evaporator fans delay after defrost cycle	BYTE	min	0...255
V3-dt	49604	--	RW	Dripping time	BYTE	min	0...255
V3-dPO	49605	--	RW	Defrost enabling request from power-on	BYTE	flag	0/1
V3-ddL	49606	--	RW	Lock display during defrost mode	BYTE	num	0/1/2
V3-dFd	49607	--	RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V4-SEt	16840	--	RW	Regulation set point	WORD	°C/°F	LSE...HSE
V4-diF	16842	--	RW	Setpoint differential	WORD	°C/°F	0.1...30.0
V4-LSE	16844	--	RW	Minimum setpoint value that can be set	WORD	°C/°F	LSE...HdL
V4-HSE	16846	--	RW	Maximum setpoint value that can be set	WORD	°C/°F	LdL...HSE
V4-dSt	16848	--	RW	Defrost end temperature	WORD	°C/°F	-58.0...302.0
V4-FSt	16850	--	RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0...150.0
V4-dty	49620	--	RW	Defrost mode	BYTE	num	0/1/2
V4-dit	49621	--	RW	Interval between defrost cycles	BYTE	min	0...255
V4-dCt	49622	--	RW	Defrost interval count mode	BYTE	num	0...3
V4-dOH	49623	--	RW	Defrost cycle enabling delay from request	BYTE	min	0...59
V4-dEt	49624	--	RW	Defrost timeout	BYTE	hrs/min/s	1...255
V4-Fdt	49625	--	RW	Evaporator fans delay after defrost cycle	BYTE	min	0...255
V4-dt	49626	--	RW	Dripping time	BYTE	min	0...255
V4-dPO	49627	--	RW	Defrost enabling request from power-on	BYTE	flag	0/1
V4-ddL	49628	--	RW	Lock display during defrost mode	BYTE	num	0/1/2
V4-dFd	49629	--	RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1
V5-SEt	16862	--	RW	Regulation set point	WORD	°C/°F	LSE...HSE
V5-diF	16864	--	RW	Setpoint differential	WORD	°C/°F	0.1...30.0
V5-LSE	16866	--	RW	Minimum setpoint value that can be set	WORD	°C/°F	LSE...HdL
V5-HSE	16868	--	RW	Maximum setpoint value that can be set	WORD	°C/°F	LdL...HSE
V5-dSt	16870	--	RW	Defrost end temperature	WORD	°C/°F	-58.0...302.0
V5-FSt	16872	--	RW	Evaporator fans status with OFF compressor output	WORD	°C/°F	-50.0...150.0
V5-dty	49642	--	RW	Defrost mode	BYTE	num	0/1/2
V5-dit	49643	--	RW	Interval between defrost cycles	BYTE	min	0...255
V5-dCt	49644	--	RW	Defrost interval count mode	BYTE	num	0...3
V5-dOH	49645	--	RW	Defrost cycle enabling delay from request	BYTE	min	0...59
V5-dEt	49646	--	RW	Defrost timeout	BYTE	hrs/min/s	1...255
V5-Fdt	49647	--	RW	Evaporator fans delay after defrost cycle	BYTE	min	0...255
V5-dt	49648	--	RW	Dripping time	BYTE	min	0...255
V5-dPO	49649	--	RW	Defrost enabling request from power-on	BYTE	flag	0/1
V5-ddL	49650	--	RW	Lock display during defrost mode	BYTE	num	0/1/2
V5-dFd	49651	--	RW	Evaporator fans disabling during defrost time	BYTE	flag	0/1

### 9.3.9. FOLDER VISIBILITY TABLE

LABEL	ModBUS ADDRESS	R/W	DESCRIPTION	DATA SIZE	RANGE	UM
vis_CPr	49450	RW	Folder visibility	2 bit	0...3	num
vis_dEF	49450,2	RW	Folder visibility	2 bit	0...3	num
vis_FAn	49450,6	RW	Folder visibility	2 bit	0...3	num
vis_ALr	49451	RW	Folder visibility	2 bit	0...3	num
vis_Lit	49451,2	RW	Folder visibility	2 bit	0...3	num
vis_nAd	49450,4	RW	Folder visibility	2 bit	0...3	num
vis_Add	49451,4	RW	Folder visibility	2 bit	0...3	num
vis_diS	49451,6	RW	Folder visibility	2 bit	0...3	num
vis_HAC	49452	RW	Folder visibility	2 bit	0...3	num
vis_CnF	49452,2	RW	Folder visibility	2 bit	0...3	num
vis_FrH	49452,4	RW	Folder visibility	2 bit	0...3	num
vis_FPr	49452,6	RW	Folder visibility	2 bit	0...3	num

### 9.3.10. RESOURCES Table

**NOTE:** ModBUS read command: 03 (0x03) and ModBUS write command: 16 (0x10)

LABEL	ADDRESS	R/W	DESCRIPTION	DATA-SIZE	RANGE	UM
AI1	337		Analogue input (display) 1	WORD	-58.0...302.0	°C/°F
AI2	339		Analogue Input (display) 2	WORD	-58.0...302.0	°C/°F
AI3	341		Analogue Input (display) 3	WORD	-58.0...302.0	°C/°F
ValSondeReg[0]	345		Analogue input (regulation) 1	WORD	-58.0...302.0	°C/°F
ValSondeReg[1]	347		Analogue input (regulation) 2	WORD	-58.0...302.0	°C/°F
ValSondeReg[2]	349		Analogue input (regulation) 3	WORD	-58.0...302.0	°C/°F
DI1	33130,4		Digital input 1	1 bit	0...1	flag
DI2	33130,3		Digital input 2	1 bit	0...1	flag
DI3	33130,2		Digital input 3	1 bit	0...1	flag
DI4	33130,1		Digital input 4	1 bit	0...1	flag
HA1	33085,5		Analogue input 1 high threshold exceeded	1 bit	0...1	flag
LA1	33085,6		Analogue input 1 low threshold exceeded	1 bit	0...1	flag
HA3	33085		Analogue input 3 high threshold exceeded	1 bit	0...1	flag
LA3	33085,3		Analogue input 3 low threshold exceeded	1 bit	0...1	flag
EAL	33085,4		External	1 bit	0...1	flag
PA	33084,7		Pressure switch	1 bit	0...1	flag
OPd	33085,7		Door open	1 bit	0...1	flag
Pan	33084,1		Man in cold room alarm	1 bit	0...1	flag
LPA	33084,2		Low pressure switch	1 bit	0...1	flag
HPA	33084,3		High pressure switch	1 bit	0...1	flag
E10	33084,6		Clock error alarm	1 bit	0...1	flag
Ad2	33160		Defrost timeout	1 bit	0...1	flag
Prr	33099,2		Preheat input regulator	1 bit	0...1	flag
E1	33085,1		Analogue input 1 error	1 bit	0...1	flag
E2	33085,2		Analogue input 2 error	1 bit	0...1	flag
ALd	33084,4		Refrigerant leak alarm	1 bit	0...1	flag
E3	33084,5		Analogue input 3 error	1 bit	0...1	flag
HACCP	33163,2		HACCP alarm	1 bit	0...1	flag
OnOff	33089,1		Device status	1 bit	0...1	flag
dEF_1	33092,4		Defrost 1	2 bit	0...1	flag
dEF_2	33100,2		Defrost 2	2 bit	0...1	flag
OSP	33089		Economy	1 bit	0...1	flag
AUX	33089,4		Auxiliary	1 bit	0...1	flag
FrameH	33101,6		Demisting heaters	1 bit	0...1	flag
LIGHT	33089,2		Light	1 bit	0...1	flag
Maintenance	33090,4		Maintenance	1 bit	0...1	flag

LABEL	ADDRESS	R/W	DESCRIPTION	DATA-SIZE	RANGE	UM
COMP1	33092,3		Compressor 1	1 bit	0...1	flag
COMP2	33099,4		Compressor 2	1 bit	0...1	flag
FAN_EVAP	33094,7		Evaporator fans 1	1 bit	0...1	flag
FAN_COND	33102,7		Condenser 1 fans	1 bit	0...1	flag
DOOR	33096,3		Door status	1 bit	0...1	flag
Alarm	33097,5		Alarm status	1 bit	0...1	flag
Deep Cooling	33102,5		Deep Cooling	1 bit	0...1	flag
Pump Down	33102,4		Pump Down	1 bit	0...1	flag
LIGHT_ON	33057		Lights on	1 bit	0...1	num
LIGHT_OFF	33057,1		Light off	1 bit	0...1	num
OSP_ON	33057,2		Economy mode On	1 bit	0...1	num
OSP_OFF	33057,3		Economy mode Off	1 bit	0...1	num
AUX_ON	33057,4		Auxiliary output On	1 bit	0...1	num
AUX_OFF	33057,5		Auxiliary output Off	1 bit	0...1	num
ON	33057,6		Device on	1 bit	0...1	num
OFF	33057,7		Device off	1 bit	0...1	num
SILENT	33058		Alarm acknowledgement	1 bit	0...1	num
DEF	33058,1		Manual defrost activation	1 bit	0...1	num
NIGHTDAY_OFF	33058,5		Disable Night & Day function	1 bit	0...1	num
NIGHTDAY_ON	33058,6		Enable Night & Day function	1 bit	0...1	num
LOCK_KBD	33059		Keypad lock	1 bit	0...1	num
UNLOCK_KBD	33059,1		Unlock keypad	1 bit	0...1	num
RST_HACCP	33059,2		Reset HACCP alarms	1 bit	0...1	num
RST_PRESS	33059,3		Reset Pressure switch alarms	1 bit	0...1	num
FRAMEHEATER_ON	33059,4		Frame Heater regulator activation	1 bit	0...1	num
FRAMEHEATER_OFF	33059,5		Frame Heater regulator deactivation	1 bit	0...1	num
HACCP_OFF	33059,6		Disables HACCP alarm recording	1 bit	0...1	num
HACCP_ON	33059,7		Enable HACCP alarm recording	1 bit	0...1	num
DEEP_COOL	33060		Deep Cooling regulator activation	1 bit	0...1	num

## 10. ADVANCED FUNCTIONS - NIGHT AND DAY

---

Events and cycles can be programmed at set times during the week using the Night&Day regulator algorithm. The parameters concerned are contained in folder **nAd** / subfolders **d0...d6**, **Ed**

**NOTA:** do not confuse labels **E0 ... E3** with probe error messages **E1 ... E2...**

**NOTE:** be careful as to how **E0 = 3** (stand-by regulator) is used. You may not have access to the device for the duration of the event set in **E2**.

### 10.1. DAY/NIGHT REGULATOR OPERATION

Different events for days of the week

For each day of the week, indicated by parameters/(sub-folders) **d0 ... d6**, you can set:

- a time for the start of the event (**E1**, in format **HH:mm**)
- the duration (**E2**)
- which functions to enable (**E0**) for the event
- which defrost group to enable (parameters **dE1..dE8 weekdays** or **F1...F8 weekends/holidays**) (**E3**).

Parameters **E0 ... E3**, can be different for each day.

According to the time set, E1 is the start time, usually set for the Reduced set (Economy) function ("NIGHT" mode). The duration is determined by parameter E2. In this mode, parameter E0 allows you to:

- Activate the reduced set functions.
- Activate the light regulator.
- Activate the aux regulator.
- Activate the stand-by regulator.

You can also decide whether to enable defrost during weekdays (**E3 = 0**) and weekends/public holidays (**E3 = 1**).

**NOTE** that parameter **E3** has no effect on the daily event settings.

#### Daily event

Using the same parameters, E0 ... E3 in the (sub-)folder Ed, you can also program a daily event, i.e. one that runs every day. Defrosts cannot be managed with this function. Hence parameter E3 in (sub-) folder d7 is not listed.

Daily or weekly events all have the same priority.

Days of the week correspond to these parameters:

Par.	Day of week	Day #
<b>d0</b>	Sunday	day 1
<b>d1</b>	Monday	day 2
<b>d2</b>	Tuesday	day 3
<b>d3</b>	Wednesday	day 4
<b>d4</b>	Thursday	day 5
<b>d5</b>	Friday	day 6
<b>d6</b>	Saturday	day 7
<b>d7</b>	Daily event (Every Day)	Daily event (Every Day)

---

## 10.2. OPERATION WITH DEFROST GROUP

If E0 is not equal to 0, the meaning of weekday parameters dE1...dE8 shifts from:  
Defrost group valid EVERY day (see Automatic defrost with Real Time Clock.)  
to:

Defrost group applicable only to weekdays.

The weekday parameters dE1...dE8 are supplemented with the management of weekend/public holiday parameters F1...F8.

Both folders still make use of the conditions for defrost at a pre-established time.

Hence for each day d0...d6 we can determine whether:

- E3 = 0, so that defrosts run at the times set in dE1...dE8.
- E3 = 1, so that defrosts run at the times set in F1...F8.

### Example

Supposing you set these time configurations:

- 3 “weekend” defrosts (when the refrigerated cabinet is not being intensively used)
  - 2 am (F1=> h02 ‘00)
  - 10 am (F2=> h10 ‘00)
  - 6 pm (F3=> h18 ‘00)
- 4 defrosts on “weekdays” (or days when the refrigerated cabinet is used intensively)
  - 5 am (dE1=> h05 ‘00)
  - 11 am (dE2=> h11 ‘00)
  - 5 pm (dE3=> h17 ‘00)
  - 11 pm (dE4=> h23 ‘00)

if the days considered as weekends/holidays are Sunday and Monday, this means the day settings will be:









- d0 / E3 = 1 (Sunday = “weekend” day)
- d1 / E3 = 1 (Monday = “weekend” day)
- d2 / E3 = 0 (Tuesday = “weekday”)
- d3 / E3 = 0 (Wednesday = “weekday”)
- d4 / E3 = 0 (Thursday = “weekday”)
- d5 / E3 = 0 (Friday = “weekday”)
- d6 / E3 = 0 (Saturday = “weekday”)

## 10.3. DAY/NIGHT REGULATOR DURING A BLACKOUT

- If a blackout occurs during day/night status activation (i.e. caused by a day/night event), and power is restored:
  - during this event, the instrument will return to the status implemented at the time of the blackout, before disabling the event at the programmed time.
  - If it occurs after this event but before the next day/night event, the device starts up as if it has disabled the day/night event during which the blackout occurred.
  - If it occurs after this event but during the next day/night event, the device starts up as if it has disabled the day/night event during which the blackout occurred, before switching to the status requested by the day/night event underway when power was restored.
- Manual events (key or digital input) have priority over the day/night status until the next day/night event (event that either disables the current status or activates the next one) if the power supply is uninterrupted.
- If a manual event inverts the status set by the day/night function within the day/night status activation period and this is followed by a blackout, and power is restored:
  - During the same day/night status activation, the controller will return to the status set by the manual event before disabling the event at the programmed time.
  - If it occurs after this event, the device starts in the status set by the manual event.
  - If it occurs after this event but during the status activation of the next day/night event, the controller switches to the status requested by the day/night event concerned before disabling the event at the programmed time.



## 10.4. OPENING FOLDER NAD - DAY/NIGHT

Display	description
	<p>Press SET for 3 seconds</p>
	<p>Folder USr appears Use the UP &amp; DOWN keys to search for the InS folder Press and release the SET key</p>
	<p>Use the UP &amp; DOWN keys to search for the nAd folder</p>
	<p>Press and release the SET key. Press and release the SET key to open the folder</p>
	<p>The first day, d0, appears Scroll using 'UP' and 'DOWN' to access the other days d1...d6 and Every Day d7 Press and release the SET key</p>
	<p>The first parameter E0 appears Press and release the SET key to modify it The E0 label will blink Use the UP &amp; DOWN keys to adjust its value</p>
	<p>The first parameter E0 appears Press and release the SET key to modify it The E0 label will blink Use the UP &amp; DOWN keys to adjust its value</p>
	<p>Press the ESC key several times to return to the normal display, or repeat the procedure to modify another parameter</p> <p>NOTE: in the case of parameter E1, the clock icon will appear. Modification takes place in the same way as the time setting procedure (see User Interface)</p>

## 11. ADVANCED FUNCTIONS - HACCP

---

To meet the minimum requirements prescribed in HACCP regulations, there is a set of dedicated parameters. These parameters can be viewed and configured in folder:

### HACCP (folder with label "HAC")

The recording of HACCP alarms can be enabled in parameter H50≠0

**NOTE. SWITCH THE INSTRUMENT OFF AND ON AGAIN AFTER MODIFYING PARAMETER H50**

HACCP alarm START and storing begins every time the alarms are cleared - see paragraph  
Deleting HACCP alarms

These parameters record and file the high and low temperature alarms for cold room probe Pb1 or display probe Pb3, as well as any instrument power failures.

In addition to alarms, these parameters also record any controller blackouts, saving the number of blackouts that have occurred since the last time the machine was stopped.

Alarms for the HACCP function are managed independently from the rest of the regulators.

Each HACCP alarm consists of a folder containing the following information:

- alarm number: up to 40 alarms can be saved: 20 for high/low temperature and 20 for power failure
- type of alarm: Ht (high temperature), Lt (low temperature) and PF (Power failure)
- time/date and duration of all alarms
- maximum or minimum temperature, with corresponding time/date, reached during the event

### **SLi, SHi parameters Instant HACCP alarm**









When a temperature value exceeds the range defined by parameters SLi and SHi, an HACCP alarm is signalled and recorded.

This threshold indicates the limit beyond which the food concerned would deteriorate irreparably, even for brief periods of time.

### **SLL, SHH parameters HACCP alarm**

When a temperature value exceeds the range defined by parameters SLL and SHH for a time greater than the drA parameter, an HACCP alarm is signalled and displayed

## 11.1. DISPLAYING HACCP ALARMS

Display	description
	<p>The red HACCP icon will remain permanently on to indicate an HACCP alarm has occurred Press and release the UP key</p> <p>The top display will show ALr If HACCP alarms have occurred the bottom display will show HACCP Press and release the SET key</p>
	<p>To access the information contained within each AHC folder, press the 'set' key</p>
	<p>The clock icon will be steadily on</p> <p>In fact, label StA will be shown on the top display, while the alarm start time will appear on the bottom display</p> <p>Use the DOWN key to scroll through the other alarm data</p>
	<p>The date icon will be steadily on</p> <p>In fact, label StA will be shown on the top display, while the alarm activation date will appear on the bottom display</p> <p>Use the DOWN key to scroll through the other alarm data</p>
	<p>Label dur will be shown on the top display, while the alarm duration will appear on the bottom display</p> <p>In HH:mm If --:-- appears the alarm is still active</p> <p>Use the DOWN key to scroll through the other alarm data</p>
	<p>The clock icon will be steadily on</p> <p>...and the maximum temperature measured by the probe during the alarm (on the top display) will be displayed along with the relative time (on the bottom display). Use the DOWN key to scroll through the other alarm data</p>
	<p>The clock icon will be steadily on</p> <p>...and the maximum temperature measured by the probe during the alarm (on the top display) will be displayed along with the relative date (bottom display). Use the DOWN key to scroll through the other alarm data</p>
	<p>To return to the alarm display screen (label AHC) press the ESC key once</p> <p>Press the ESC key several times to return to the normal display</p>

**Eliwell Controls s.r.l.**

Via dell'Industria, 15 • Z.I. Paludi  
32016 Alpago (BL) ITALY  
T +39 0437 986 111  
[www.eliwell.com](http://www.eliwell.com)

**Technical Customer Support**

T +39 0437 986 300  
E [techsuppeliwell@se.com](mailto:techsuppeliwell@se.com)

**Sales**

T +39 0437 986 100 (Italy)  
T +39 0437 986 200 (other countries)  
E [saleseliwell@se.com](mailto:saleseliwell@se.com)